

# **SINUMERIK 805 Software Version 3**

**Operator's Guide**

**User Documentation**

**January 1991 Edition**

## Printing history

Brief details of this edition and previous editions are listed below.

The status of each edition is shown by the code in the "Remarks" column.

*Status code in "Remarks" column:*

**A** . . . New documentation            **B** . . . Unrevised reprint with new Order No.  
**C** . . . Revised edition with new status. If factual changes have been made on the page since the last edition, this is indicated by a new edition coding in the header on that page.

<b>Edition</b>	<b>Order No.</b>	<b>Remarks</b>
06.90	6ZB5 410-0EE02-0BA0	<b>A</b>
01.91	6ZB5 410-0EE02-0BA1	<b>C</b>

Other functions not described in this documentation might be executable in the control. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

This publication was produced on the Siemens 5800 Office System.  
Subject to change without prior notice.

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

# Preliminary Remarks

## Reading comments

This document has been written for machine tool users.

The user documentation for SINUMERIK 805 is divided into two parts:

- Operator's Guide
- Programming Guide

The Operator's Guide is divided into three parts:

- **BASICS:** Section 1-3
- **APPLICATIONS:** Section 4-5
- **REFERENCES:** Section 6-9

If this is your first contact with SINUMERIK 805, please start with **BASICS**:

**Section 1: General Comments**  
describes

- the SINUMERIK 805 components,
- how to switch SINUMERIC 805 on and off.

**Section 2: Description of Operator Controls and Areas**  
explains

- the operator controls and their functions,
- the elements and hierarchical structures contained in the menus in the machine and data areas.

**Section 3: Operating Mode Description**  
describes

- how to select the operating modes,
- the components of the operating modes.

The **APPLICATIONS** section contains information about data input, control preparation and operation during the processing phase.

**Section 4: Data Input**  
describes

- data input for programs, parameters, tool offsets, zero shifts, data transfer and diagnostics.



General Comments

---

1

Description of Operator Controls and Areas

---

2

Operating Mode Description

---

3

Data Input

---

4

Operating Sequences

---

5

Data Interfaces

---

6

Maintenance

---

7

Monitoring

---

8

Appendix

---

9

# Contents

	Page
<b>BASICS</b>	
<b>1</b>	<b>General Comments</b> ..... 1-1
1.1	Product ..... 1-2
1.2	Switching the control on and off ..... 1-3
<b>2</b>	<b>Description of Operator Controls and Areas</b> ..... 2-1
2.1	Operating elements of the operator keyboard ..... 2-1
2.1.1	Explanation of the operating elements of the operator keyboard ..... 2-2
2.2	Operating elements of the Hand-held unit ..... 2-17
2.2.1	Explanation of operating elements of hand-held unit ..... 2-18
2.3	Division of the screen, softkeys ..... 2-25
2.4	Operating area, menu tree ..... 2-27
2.4.1	Branching within a menu tree ..... 2-28
2.4.2	Machine area menu tree ..... 2-29
2.4.2.1	JOG mode menu tree ..... 2-29
2.4.2.2	MDA mode menu tree ..... 2-30
2.4.2.3	AUTOMATIC mode menu tree ..... 2-31
2.4.3	Data storage area menu tree ..... 2-32
2.4.4	Entries in Input fields ..... 2-34
2.4.5	Calculator function ..... 2-35
<b>3</b>	<b>Operating Mode Description</b> ..... 3-1
3.1	General ..... 3-1
3.1.1	Operating modes - overview ..... 3-1
3.1.2	Operating mode selection ..... 3-2
3.1.3	RESET with change of operating mode ..... 3-4
3.2	JOG mode ..... 3-5
3.2.1	JOG basic display ..... 3-5
3.2.2	Notes on JOG basic display ..... 3-6
3.3	JOG-INC submode ..... 3-8
3.3.1	JOG-INC basic display ..... 3-8
3.3.2	Notes to JOG-INC basic display ..... 3-9
3.4	JOG-REPOS submode ..... 3-10
3.4.1	JOG-REPOS basic display ..... 3-10
3.4.3	Notes on JOG-REPOS basic display ..... 3-10
3.5	JOG-REF submode ..... 3-11
3.5.1	JOG-REF basic display ..... 3-11
3.5.2	Notes on JOG REF basic display ..... 3-11

	Page
3.6	MDA mode ..... 3-12
3.6.1	MDA basic display ..... 3-12
3.6.2	Notes on MDA basic menu ..... 3-13
3.7	AUTOMATIC mode ..... 3-14
3.7.1	AUTOMATIC basic display ..... 3-14
3.7.2	Notes on AUTOMATIC basic menu display ..... 3-15
3.8	TEACH-IN mode ..... 3-17

## APPLICATIONS

<b>4</b>	<b>Data Input</b> ..... 4-1
4.1	General comments ..... 4-1
4.2	Data area basic display ..... 4-2
4.3	Program ..... 4-3
4.3.1	Program editing ..... 4-4
4.3.1.1	OPERATOR PROMPTING in edit mode ..... 4-7
4.3.2	Create new program ..... 4-11
4.3.3	Part program selection for program execution ..... 4-13
4.3.4	Memory allocation of the part program memory ..... 4-14
4.3.5	Display of MAIN PROGRAM DIRECTORY or SUBROUTINE DIRECTORY ..... 4-15
4.3.6	Selecting a program in the overview ..... 4-17
4.3.7	Copy part programs ..... 4-19
4.3.8	Delete part program ..... 4-20
4.3.9	Rename part program ..... 4-21
4.3.10	Relocate part program ..... 4-22
4.3.11	Reorganize part program memory ..... 4-22
4.4	Data/Parameters ..... 4-23
4.4.1	R parameters ..... 4-24
4.4.2	Setting data ..... 4-29
4.4.3	NC-MD values ..... 4-31
4.4.4	NC-MD BITS ..... 4-35
4.4.5	PLC-MD ..... 4-38
4.5	Tool offset ..... 4-41
4.5.1	Selecting the tool offset numbers ..... 4-42
4.5.3	Deleting/altering a tool parameter ..... 4-42
4.6	Zero offset ..... 4-38
4.7	Data transfer ..... 4-40
4.8	Diagnostics ..... 4-46
4.8.1	PLC status ..... 4-48
4.8.2	Service ..... 4-52

	Page
<b>5</b>	<b>Operating Sequences</b> . . . . . 5-1
5.1	Preliminary remarks . . . . . 5-1
5.2	Preparation . . . . . 5-2
5.2.1	Switching on . . . . . 5-2
5.2.2	Approach reference point ("REFPOINT") . . . . . 5-2
5.2.3	Automatic drift compensation . . . . . 5-4
5.2.4	Tool compensation . . . . . 5-5
5.2.4.1	Description of tool parameters . . . . . 5-7
5.2.5	R parameters . . . . . 5-11
5.2.6	Zero offset . . . . . 5-13
5.2.6.1	Selecting zero point offsets . . . . . 5-15
5.2.7	Setting data . . . . . 5-17
5.2.7.1	Setting data selection . . . . . 5-17
5.2.8	Program input . . . . . 5-19
5.2.8.1	Program input with the keyboard . . . . . 5-19
5.3	Operation . . . . . 5-20
5.3.1	Starting a part program . . . . . 5-20
5.3.2	Calling ACTUAL PROGRAM or ACTUAL BLOCK in AUTOMATIC mode . . . . . 5-22
5.3.3	Program interrupt . . . . . 5-25
5.3.4	BLOCK SEARCH function . . . . . 5-26
5.3.5	PROGRAM CONTROL function . . . . . 5-28
5.3.6	Program control in AUTOMATIC mode . . . . . 5-33
5.3.7	DRF function . . . . . 5-34
5.3.8	Traversing in the JOG mode . . . . . 5-36
5.3.9	Traversing in the JOG-INC mode . . . . . 5-39
5.3.10	Traversing in JOG-REPOS mode . . . . . 5-42
5.3.11	MDA mode . . . . . 5-44
5.3.11.1	OPERATOR PROMPTING in MDA mode . . . . . 5-46
5.3.12	OVERSTORE function . . . . . 5-50
5.3.13	PRESET function (set actual value) . . . . . 5-52
5.3.14	OVERRIDE BLOCK function . . . . . 5-55
5.3.15	SPEED OVERLAY VIA HANDWHEEL PULSES . . . . . 5-57
5.3.16	Scratch . . . . . 5-58

## REFERENCES

<b>6</b>	<b>Data Interfaces</b> . . . . . 6-1
6.1	General . . . . . 6-1
6.2	Data read-in via RS 232 C interface . . . . . 6-2
6.3	Data read-out via RS 232 C interface . . . . . 6-6
6.4	Interface parameters for various peripheral devices . . . . . 6-9
6.5	PLC program, read-in/read-out . . . . . 6-12
6.6	Setting data for defining interfaces . . . . . 6-15
6.7	Assignment of the setting data for the connection of peripheral devices . . . . . 6-17
6.8	Device connection data . . . . . 6-19



	Page
<b>7</b>	<b>Maintenance</b> ..... 7-1
7.1	Operating data ..... 7-1
7.2	Battery submodule ..... 7-2
7.2.1	Replacing the battery ..... 7-3
7.3	CRT display ..... 7-4
7.4	Cleaning ..... 7-4
<b>8</b>	<b>Monitoring</b> ..... 8-1
8.1	General ..... 8-1
8.2	Alarm numbers and groups/clearing alarms ..... 8-1
8.3	Monitoring display on the screen ..... 8-3
8.3.1	Message line for NC and PLC alarms and messages ..... 8-3
8.3.2	List of active alarms and signals ..... 8-3
8.3.3	List of alarms ..... 8-5
<b>9</b>	<b>Appendix</b> ..... 9-1
9.1	Softkey function dictionary ..... 9-1
9.2	Index ..... 9-5
9.2.1	Abbreviations ..... 9-5
9.2.2	Useful definitions ..... 9-7

# 1 General Comments

This Operator's Guide explains the configuration of the SINUMERIK 805 as well as its operation.

**You will be introduced to the following components:**

- Screen
- Operator keyboard
- Hand-held unit


This guide has been devised for the maximum scope of functions offered by the SINUMERIK 805.

Any required options are to be found in the catalog: NC 34/Options.

## Technical comments




*In parts of this documentation you will see the symbol shown on the left and a comment referring to an ordering data option. This symbol is intended to point out that the described function is executable only if the control includes the designated option.*



*The symbol shown here appears in this documentation wherever the machine tool manufacturer can influence or modify the described function by changing a machine data (MD).*

*Please consult the machine tool manufacturer's documentation.*




- Other functions which are not described in this documentation can possibly also be performed in the control.
- However, the customer is not entitled to demand these functions when new equipment is supplied or when servicing is carried out.


***This Operator's Guide is valid for:  
SINUMERIK 805, Software version 3.***

## 1.1 Product

The SINUMERIK 805 is a microprocessor-controlled CNC continuous-path control system for machine tools and automation tasks with the following operator control and display elements:




- **Screen displays** provide information on:
  - active operating modes and program modification
  - setpoint/actual values
  - NC and PLC alarms etc.
- The **operator keyboard** is a full keyboard offering (with) the following features:
  - 7 softkeys for selecting various menus in 2 operating areas
  - Key selection of operating modes
  - Cursor keys, numeric keys and double assignment (SHIFT) keys.
- Using the **hand-held unit**
  - JOG and AUTOMATIC modes can be selected
  - the axes can be traversed in jog mode
  - the axes can be traversed using the handwheel.
- In addition:
  - the actual position of the selected axis and
  - the active key function are displayed by means of LED.



## 1.2 Switching the control on and off


### Switching on SINUMERIK 805

There are various ways of switching the control or whole system on, therefore:



In principle it can be said that: the control is switched on when the input voltage applies to the power supply unit of the central controller.

When the control has been switched on, the following system screen appears for approx. 5 seconds, followed by the JOG mode basic display.



*Start display after switching on control*

**Comments on system screen:**

The system screen gives information to the operator regarding the installed software.

- 6FX 1866 0BX03-3B : Order number of the installed system software
- Language: German/English : Plaintext comments on installed language software
- Software version: 3.1 : Plaintext comments on installed software version

**Note:**

The system screen can also be called up during operation using the **following sequence of keys:**



Press the operating area key



Press in the following sequence:      DIAGNOSTICS softkey



menu expansion key




VERSION softkey



The VERSION display is deselected by pressing the RECALL key.


The control is switched on and ready for operation.



Basic display for JOG mode

### Switching off SINUMERIK 805


The following applies when switching off the control or the whole system:



In principle it can be said that: the control is switched off by switching off the input voltage of the power supply unit of the central controller.

## 2 Description of Operator Controls and Areas

### 2.1 Operating elements of the operator keyboard




#### Key groups - functions:

- |   |   |
|---|---|
| 1 | Softkeys with menu control keys                     |
| 2 | Machine function keys with operating area key       |
| 3 | Address keys  |
| 4 | Numeric keys  |
| 5 | Edit and input keys                                 |
| 6 | Arithmetic keys                                     |
| 7 | Cursor keys with decrement, increment and page keys |

## 2.1.1 Explanation of the operating elements of the operator keyboard

### Softkeys with menu control keys

1



Softkeys with text bar

#### Softkey



Press one of the seven softkeys (a softkey is a key without a fixed function) select the softkey function offered in the text bar.

#### Softkey text



In the text bar the softkey function of the softkey below is displayed.

#### Note:

In the text the pictogram  is used if pressing a key is necessary.

#### MORE key for menu control/extension of the text bar in the same menu



Pressing this key allows you to view additional softkey functions (if available) from the same menu in the text bar.

#### RECALL key for menu control/return to the text bar in the higher-level menu






- By pressing this key, you move back to the higher-level menu.
- In addition, you can also close an opened window, e.g. "INPUT VALUE TOO LARGE" or "SEARCH", with this key.



**Machine function keys with operating area key**

2

**RESET**


Pressing the RESET key causes the following:

- Termination of the active part program execution
- Acknowledgement (deletion) of alarms 100\* to 196\*, 2000 to 2999
- RESET state of the control (display on screen)
  - The axes remain synchronized with the machine.
  - The buffer and user memory are erased.
  - The control is ready to execute a new program.

**Actual position with double-height characters**



If you operate this key in the machine area of the control, the actual positions of the axes concerned are displayed in double-height characters.




Further information from the previous display is faded out. Operating the key again returns the previously displayed menu to the screen.

## Operating area key



This key is used to switch between the two operating areas of the SINUMERIK 805, the machine area and the operating area.

Termination of active part program execution.



- You are located in the machine area with the functions which are dependent on the type of mode (LED not on):  
Using this key, it is possible to branch to the basic menu from any menu in this area.
- You are located in the data area with functions for displaying and changing data (R parameters etc.) and NC programs (LED on):  
Using this key, it is possible to branch to the basic menu of the selected mode from any menu in this area.

## JOG-Taste



When you operate this key, you can select the JOG mode from the machine area or the data area. The LED assigned to the key is on for as long as the mode is selected. The selected mode is also displayed in the working field on the screen.

**TEACH-IN key**

(Available soon)

**MDA key**

When you operate this key, you can select MDA mode in the machine area and data area. The LED assigned to the key is on for as long as the MDA mode is selected. The selected mode is also displayed in the working field on the screen.

**AUTOMATIC key**

When you operate this key, you can select AUTOMATIC mode in the machine area and data area. The LED assigned to the key is on for as long as the AUTOMATIC mode is selected. The selected mode is also displayed in the working field on the screen.

**SINGLE BLOCK key**

This key offers you the possibility of executing a part program block by block in the AUTOMATIC mode. Repeated operation of this key switches the function on and off.

- LED not on:      single-block execution inactive
- LED on:            single-block execution active
  - STOP: SINGLE BLOCK appears on the screen
  - When the NC start key has been pressed the active block is processed, the screen display STOP: SINGLE BLOCK disappears whilst the block is processed.
  - Once the block has been processed, the STOP: SINGLE BLOCK again appears on the screen
  - The next block is processed when the NC start key is pressed, etc.

**NC STOP key**

By pressing this key, you can interrupt the execution of the current part program in the AUTOMATIC mode. During this interruption, the LED assigned to this key is on and STOP:AUTO-Interruption is displayed on the screen. Processing of the program from the point of interruption can be reinitiated by operating the NC start key.


The LED and display mentioned above then go out.

**NC START key**

- **AUTOMATIC mode:**  
The part program which has been called up is initiated with the active block. Whilst the program is being executed, the LED assigned to this key is on and PROGRAM RUN is displayed on the screen.
- **MDA mode:**  
You press this key to start execution of the entered NC block.

Address keys

3

% <sup>(</sup>	/ <sup>)</sup>	N	G	= <sup>&amp;</sup>
X <sup>U</sup>	Y <sup>V</sup>	Z <sup>W</sup>	C	@
I <sup>E</sup>	J <sup>O</sup>	K <sup>Q</sup>	A <sup>B</sup>	P
F	D	L	H	R
	M	S	T	LF <sup>⏏</sup>

Key shift



When this key is operated, the **second function** becomes active for keys with a double assignment.

- The yellow LED is on:  
The **second function** (upper symbol) is active.
- The yellow LED is not on:  
The **first function** is active.



Symbol: open parenthesis

---

Sign for "program start"



Symbol: closed parenthesis

---

Sign for "skip block"



Address for "block number": N...



Address for "preparatory function": G...



Ampers and

---

Equals sign



Letter U

---

Address for "path information" of the X axis



Letter V

---

Address for "path information" of the Y axis



Letter W

---

Address for "path information" of the Z axis



Letter C



Address for "programm control functions"



Letter E

---

Address for "interpolation parameter" I



Letter O

---

Address for "interpolation parameter" J



Letter Q

---

Address for "interpolation parameter" K



Address for "radius"/letter B

---

Address for "angle"/letter A



Address for "subroutine pass count"



Address for "feedrate"/letter F

## 2.1.1 Explanation of the operating elements of the operator keyboard

<b>D</b>	Address for "tool offset number"/letter d
<b>L</b>	Address for "subroutine number"
<b>H</b>	Address for "auxiliary functions"
<b>R</b>	Address for "parameters"
<b>M</b>	Address for "additional functions"
<b>S</b>	Address for "spindle speed"
<b>T</b>	Address for "tool number"
<b>LF</b>	Blank
	Sign for "block end" (Line Feed)



The following characters are not marked on the keyboard, as they are only used to enter @ commands for the creation of cycles (second functions).

"a" is to be found by shift + F key



"b" is to be found by shift + D key



"c" is to be found by shift + L key



"d" is to be found by shift + H key



"e" is to be found by shift + R key



"f" is to be found by shift + M key



**Numeric keys**

4

7	8	9
4	5	6
1	2	3
+/-	0	•

**Numeric keys**

0

...

9

Numbers 0 ... 9

**Plus/minus key**

+/-

- By operating this key you reverse the sign in front of the word in the opened input field:  
+ - / - + .
- Additionally, you can activate or deactivate functions selected with the cursor in certain menus.


**Decimal point key**

•

Decimal point

## Edit and input keys

5

**DELETE key****Delete character**

With this key you delete characters in the opened input field

- you delete the character selected by the cursor if the key is pressed once
- continuous operation of the key deletes all successive characters from the selected character towards the right.

**CANCEL key****Delete input field**

You delete the contents of the opened input field with this key.

**EDIT key****Open input field**

- With this key you open the input field selected by the cursor. The input field must be opened before an entry can be made.
- If you conclude an input with this key, the input value is not accepted and the previous value is the value in the closed input field.


**Entry key**

The input is concluded with this key:

- The value in the edited input field is entered accordingly.

**Arithmetic keys**

6



SINUMERIK 805 offers the following arithmetic functions:



Division key



Multiplication key




Subtraction key



Addition key

**Cursor keys with decrement, increment and page keys**

7

**Cursor left/right movement key**

Using these keys, you move the cursor on the screen to the left and to the right.

**Cursor up/down movement key**

Using these keys, you move the cursor on the screen up and down.

**Home key**

Operating this key positions the cursor in the top left input field.

### Increment/Decrement key



- Operation of these keys changes increment, decrement the incremental dimension of the field selected by cursor (JOG-INC or HANDWHEEL) in the JOG, JOG-INC AND JOG-REPOS modes.



Areas: JOG-INC: 1, 10, 100, 1000, 10000 [unit/IS]  
HANDWHEEL: 1, 10, 100 [unit/IS]

- You increment/decrement the selected operands in the DIAGNOSIS window.

### Page up/down key

By operating either of these keys, you can change the active screen display if further displays are available.





You page one display back.



You page one display forward.

## 2.2 Operating elements of the Hand-held unit




### Explanation of operating elements:

- 1** EMERGENCY STOP switch
- 2** Feedrate/rapid traverse override switch
- 3** Axis actual position and distance to go display
- 4** Key group with LED display (STANDARD labelling)
- 5** Handwheel
- 6** Keyswitch

## 2.2.1 Explanation of operating elements of hand-held unit

### Emergency stop switch


1




The red switch is operated in **emergency situations**:

- when there is a danger to life
- when there is a danger that the machine or workpiece could be damaged.

Operation of the "emergency stop" switch generally brakes all drives with maximum breaking power to a defined state.




*For further or other reactions to "emergency stop":  
See machine tool manufacturer's documentation!*



### Feedrate/rapid traverse override switch

2




The rotary switch with 23 latched positions, enables you to decrease or increase the **programmed** feedrate value "F" (corresponds to 100%).


The set feedrate value "F" is displayed on the screen in %.

Control range: 0% . . . . . 120% of the **programmed** feedrate.  
In rapid traverse, the 100% value is not exceeded.


Step value: 0%, 1%, 2%, 4%, 6%, 8%, 10%,  
20%, 30%, 40%, 50%, 60%, 70%,  
75%, 80%, 85%, 90%, 95%, 100%,  
105%, 110%, 115%, 120%



*The given increment and control range are valid for  
standard machine data.  
This MD is user-specific and may be altered by the  
machine tool manufacturer!*





**Axis actual position and distance to go display****3**


Depending on the selected axis and function, the actual position or distance to go of each axis is displayed.

**Note:**

The display remains dark if no axis is selected via PLC-NC interface.

**Keys with LED display****4**

The key group consists of 25 keys of which 16 are equipped with key LEDs.

**Jog key**

JOG mode is selected with this key.


**Automatic key**

AUTOMATIC mode is selected with this key.

When JOG or AUTOMATIC modes are selected, the corresponding LED keys turn on. The selected mode is additionally displayed in the operating mode field on the screen.

The modes can also be selected with the appropriate keys on the operator keyboard.

### Feedrate stop / Feedrate start keys



You operate the  
FEEDRATE STOP key.



- The program being processed is stopped.
- The feed drives are brought to a controlled stop.
- The FEEDRATE START key LED goes out.
- The FEEDRATE STOP key LED is on.
- The status display for FEEDRATE STOP (FST) is displayed in reverse video.


#### Examples for the use of FEEDRATE STOP

- when a fault is discovered whilst processing a block during operation in MDA mode,
- in JOG, JOG-INC and JOG-REPOS modes, e.g. during return to the contour,
- to change a tool,
- to input S, T, H and M functions during setting up (overstore).

You operate the  
FEEDRATE START key.




- the part program continues in the active block,
- the feedrate is increased to the value given in the program,
- the LED of the FEEDRATE STOP key goes out.
- the LED of the FEEDRATE START key is on.




**The following values are specified in the machine data:**

- the feed and rapid traverse rates
- the values for the feedrate override switch positions
- whether the feedrate override switch is also active for rapid traverse.

**(See the machine tool manufacturer's documentation.)**



### Spindle Stop / Spindle Start keys



You operate the  
SPINDLE STOP key.



- The spindle is brought to a standstill.
- The LED of the SPINDLE START key goes out.
- The LED of the SPINDLE STOP key is on.



### Example for the use of SPINDLE STOP

- a block with a fault is discovered during operation in MDA mode,
- in JOG, JOG INC, JOG REPOS modes (e.g. during return to the contour),
- to change a tool,
- to input S, T, H and M functions during setting up (OVERSTORE).


You operate the  
SPINDLE START key.



- the spindle speed is accelerated to the value specified in the program.
- the LED of the SPINDLE STOP key goes out.
- the LED of the SPINDLE START key is on.

	<p><b><i>The following values are specified in machine data:</i></b></p> <ul style="list-style-type: none"> <li>- <b><i>the max. spindle speed</i></b></li> <li>- <b><i>the values for the spindle speed override switch positions</i></b></li> </ul> <p><b><i>(see the machine tool manufacturer's documentation)</i></b></p>	
---	--	---

## NC stop / NC start keys



You operate the NC-STOP key.



- the part program being processed is stopped.
- "STOP: AUTO-INTERRUPTION" is shown on the display.
- The LED of the NC START key goes out.
- The LED of the NC STOP key is on.

You operate the NC START key in the selected mode AUTOMATIC.



- The part program called is started and/or continued at the active block.
- "PROGRAM RUNNING" is displayed.
- the LED of the NC STOP key goes out.
- the LED of the NC START key is on.

NC STOP and NC START commands can also be given from the operator keyboard.

## Axis selection keys

The required axis is selected with these keys:



- The actual position of the selected axis is given in the axis actual position display.



- One of the four key LEDs lights up, showing the selected axis.



- After switching on, the axis is selected.



### Axis direction key



Operation of the AXIS DIRECTION PLUS KEY and/or AXIS DIRECTION MINUS KEY results in the following:

- JOG mode selected:  
You traverse the selected axis in the required direction.
- Submode JOG INC selected:  
Each time one of these keys is pressed, the selected axis traverses by the set increment in the appropriate direction.

### Rapid traverse override key



If you press the RAPID TRAVERSE OVERRIDE key

together with the





or



key.

The selected axis is traversed at "rapid traverse" in the appropriate direction.

	<p><b><i>The following is specified in machine data:</i></b></p> <ul style="list-style-type: none"> <li>• <i>the feedrate,</i></li> <li>• <i>the rapid traverse speed,</i></li> <li>• <i>the incremental speed.</i></li> </ul>	
---	--	---


### Handwheel function key



The function is activated/deactivated each time the HANDWHEEL key is pressed. When the handwheel is selected, the appropriate key LED lights up. The HANDWHEEL function effects the selected axis.

## Handwheel

5



You operate the HANDWHEEL key (key LED lights up). Using the handwheel, you can now traverse the selected axis incrementally in JOG mode or JOG INC or JOG REPOS submodes.

## Keyswitch

6


The input of data, number of functions etc. can be protected using the keyswitch.




The key can be removed. All disabled functions can no longer be carried out.




The key **cannot** be removed. Disable no longer effective.



*Whether the input disable in your control is active or not, depends on the machine data (see the machine tool manufacturer's documentation).*



## 2.3 Division of the screen, softkeys



SINUMERIK 805 uses a 12" monochrome screen with a resolution of 640 x 480 pixels. The following table gives an explanation of the display functions of each of the fields:

**1** Operating mode field, displays selected mode or submode.

- 2** Display field for program modification (Section 5.3.6)
  - STOP: AUTO interruption
  - STOP: Single block mode
  - STOP: Program STOP M00/M01
  - STOP: Read-in enable
  - STOP: Dwell time
  
- 3** Control display for (light background= active):
  - SKP Skip block
  - DRY Dry run
  - ROV Rapid traverse override
  - DBL Decode single block
  - DRF Offset
  - M01 Programmed stop
  
- 4** Status display for FEEDRATE STOP (FST: FEED STOP)  
(light background= active)
  
- 5** Program number of selected part program display
  
- 6** Display field for operating status
  - RESET
  - Program running
  - Program interrupted
  
- 7** Display field for the number of the selected NC  
(for details see Interface Part 1, Signals Flag Byte 99)
  
- 8** Area for NC displays: texts, graphics
  
- 9** Text bar with 7 softkey functions
  
- 10** Message line for NC and PLC alarms and messages  
(only the alarm with highest priority is displayed= alarm with the lowest number).




## 2.4 Operating area, menu tree

Operation of the SINUMERIK 805 is divided into two areas, the machine area with functions which are dependent on the type of mode and the data storage area sporting functions for data and NC program display and modification.

Operation within each area is menu controlled, i.e. the functions shown in the text bar on screen can be selected by means of the function keys (softkeys). As soon as a function has been selected, the control reacts by displaying new functions in the text bar etc.

Menu trees with several branches result.



Using the operating area key, it is possible to branch to the data area **basic menu** from any menu in the machine area.

Conversely, it is possible to branch from any data area menu to the basic menu of the selected operating mode, using the operating area key.

### Comments:

- The key LED lights up to show that the data area has been selected.
- Contrary to the other functions, the function selected by means of softkey is displayed in reverse video in the text bar.

### 2.4.1 Branching within a menu tree


You wish to return to the higher-level menu after repeated branching.

You operate this key:



After operating this key once, the next immediate higher-level menu is displayed along with operating functions in the text bar.

- Basic menu of data area
- Basic menu of AUTOMATIC, MDA or JOG modes



You wish to refer to additional operating functions in the same menu (only if additional text bar is available).


You operate the following key:




## 2.4.2 Machine area menu tree

The machine area menu tree is subdivided into menu trees for JOG, AUTOMATIC and MDA modes.


### 2.4.2.1 JOG mode menu tree




### 2.4.2.2 MDA mode menu tree




### 2.4.2.3 AUTOMATIC mode menu tree



### 2.4.3 Data storage area menu tree






## 2.4.4 Entries in Input fields

The input field of the SINUMERIK 805 is marked dark on the screen. You can enter and/or change values in the input fields by operating in the following sequence:

### Sequence of operation when modifying values in the input field



Using the cursor keys, you move the dark input field to the desired position within a selected menu.



Operation of the EDIT key opens the input field for the input of a value or modification of the original value.



Using the cursor keys, you can select any of the numbers in the opened input field.



Operate CHARACTER DELETE key to delete a character.



Operate INPUT FIELD DELETE to delete the whole input field.



Key in the desired value.



You enter the keyed-in value with the INPUT key.

#### Note:

By operating the EDIT key when the input field is open, you close the input field. The original value is maintained.



## 2.4.5 Calculator function

The calculator function in the SINUMERIK 805 can be applied to all input fields. It features the following arithmetical functions:

- division
- multiplication
- subtraction and
- addition


### Arithmetic operation sequence

#### Prerequisite:


You wish to execute an arithmetic operation with the value entered in the input field by means of cursor, page key, or the SEARCH softkey.




Press EDIT to open the selected input field. The value in the field is the 1st operand. You can modify the 1st operand via the numeric keyboard.



You use the cursor keys and




edit keys to edit.




You select one of the four arithmetical keys depending on the desired operation.

Now key in the 2nd operand using the numeric keys.



You use the cursor and



edit keys to edit.



To execute the arithmetical operation, press the INPUT key.  
The result is given in the closed input field.

**Notes:**

- The sign before the operand is reversed by operating the PLUS/MINUS key, + - and - + after entering the amount.
- The arithmetical operation is also executed by pressing the EQUALS sign. The result is given in the open input field and is the 1st operand for the next arithmetical operation.
- If you close the opened input field using the EDIT key, the original value is maintained.

## 3 Operating Mode Description

### 3.1 General

On a machine tool an NC controls

- the motion of the tool
- the motion of the workpiece

by means of a set program (part program).

Further preparations have to be carried out to the machine tool before the actual machining process can be started.

For these preparations, the control has to be set to certain operating states to prepare for certain operations.

**These include:**

- Traversing the tools or the workpiece to the start position required in the setting up plan
- Loading the part program into the memory of the control
- Checking and entering the zero offsets
- Checking and entering the tool offsets

#### 3.1.1 Operating modes - overview

The SINUMERIK 805 offers 4 operating modes to bring the control into the desired state.

The following operating modes can be selected directly by operating the relevant key on the operator keyboard:

- JOG (manual operation)
- TEACH IN (available soon)
- MDA (manual input - automatic)
- AUTOMATIC

Additionally, the following submodes can be selected in JOG mode using the softkeys:

- JOG-INC (increment)
- JOG-REPOS (repositioning)
- JOG-REF (approach reference point)

The SINUMERIK 805 modes and submodes are therefore:

- JOG
- JOG-INC
- JOG-REPOS
- JOG-REF
- TEACH IN
- MDA
- AUTOMATIC

### 3.1.2 Operating mode selection

In the case of SINUMERIK 805, operating modes can be selected in the machine area and data area.

In this section it is assumed that the machine area has been selected.

The selected mode is displayed in the operating mode field.

To select one of the following modes:

- JOG
- TEACH-IN (available soon)
- MDA
- and AUTOMATIC

select one of the following keys on the operator keyboard:



JOG



TEACH-IN (available soon)



MDA



AUTOMATIC

The key LED lights up on the operating mode key selected. The basic display of the selected mode appears on the screen.



To select the submodes

- JOG-INC
- JOG-REPOS
- JOG-REF

you operate this key:



In the JOG mode basic display you can then select the desired submode by operating one of the following softkeys:



You operate one of these softkeys.

Mode JOG-INC, JOG-REPOS or JOG-REF appears on the screen.  
You return to the JOG mode basic display by operating the JOG softkey.

### 3.1.3 RESET with change of operating mode

When changing from one selected operating mode to another, a RESET can be generated by the control, depending on the selected operating mode. The following table shows for which operating mode changes a RESET is generated:

	MDA	AUTO-MATIC	JOG	JOG REPOS	JOG INC	JOG REF
MDA		+	+	+	+	+
AUTO-MATIC	+		0	0	0	+
JOG	+	0		0	0	+
JOG REPOS	+	0	0		0	+
JOG INC	+	0	0	0		+
JOG REF	+	+	+	+	+	

*RESET with change of operating mode*

**Notes:**

- +  $\hat{=}$  RESET is generated
- 0  $\hat{=}$  RESET is not generated
- The RESET generated by the control when changing the operating mode has the same effect as operating the RESET key on the operator keyboard.

**Examples:**

1. When changing from AUTOMATIC to JOG mode, no RESET is generated by the control.
2. When changing from JOG to JOG REF, a RESET is generated by the control.

## 3.2 JOG mode

In this mode the individual axes can be traversed using the direction keys and the set feedrate value.

After a program interruption in the AUTOMATIC mode, the path traversed by each axis in the JOG mode referred to the point of interruption, is displayed in the OFFSET VALUE column.

### 3.2.1 JOG basic display


After switching on or after selection of the JOG mode in the machine area by means of this key:




the following display appears:

<b>JOG</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%28
					RESET				
X Y Z	<b>ACTUAL POSITION</b>	<b>OFFSET VALUE</b>				<b>FEEDRATE</b>			
	0.000	0.000				Command	0.000	100%	
	0.000	0.000				Actual	0.000	[mm/min]	
	0.000	0.000				<b>SPINDLE</b>			
							Command	0	100%
							Actual	0	
<b>VAR. INCREMENTAL</b>					<b>TOOL</b>				
HANDWHEEL					AUX./MISC. FUNCTIONS:				
					D M				
					T H				
					<b>CURRENT G FUNCTION:</b>				
OVERSTORE	PRESET	JOG	JOG-INC	JOG-REPOS	JOG-REF				


### 3.2.2 Notes on JOG basic display




Display of addresses of each of the axes. After an axis has been referenced, the appropriate field is darkened.




The actual position of each of the axes is shown in these fields.




After interruption of a program in AUTOMATIC mode using the NC-STOP key, the path traversed by each axis in JOG mode referred to the point of interruption is displayed here.



Movement of an axis in a positive or negative direction is indicated by a plus or minus sign in the appropriate field.




Display of the command and actual value for the feed rate and type of feed rate and position of the feedrate/rapid traverse override switch.




Display of spindle speed command and actual value and spindle override switch position.





This value will be the weighting for the handwheel increment value (possible values: 1, 10, 100) when the axis is traversed using the handwheel. This value can be modified by operating the following keys:



Increment/Decrement key

#### Short description of the softkey functions:


- OVERSTORE : Entry of auxiliary functions (s. Section 5.3.12)
- PRESET : Set actual value (s. Section 5.3.13)
- JOG : Select JOG mode (s. Section 3.2.1)
- JOG-INC : Select JOG-INC submode (s. Section 3.3)
- JOG-REPOS : Select JOG-REPOS submode (s. Section 3.4)
- JOG-REF : Select JOG-REF submode (s. Section 3.5)

### 3.3 JOG-INC submode


In this case, machining is carried out with the NC in the jog mode (by hand). Each time you operate the direction key, the selected axis is traversed by the set increments in the appropriate direction.

#### 3.3.1 JOG-INC basic display

When you are located in the JOG basic display, you can select the JOG-INC submode by operating the JOG-INC softkey. After selection, the following basic display appears:



### 3.3.2 Notes to JOG-INC basic display



If an axis is traversed using the +/- key on the hand-held unit or using the handwheel, the selected axis is traversed by the set number of increments each time the key is pressed or for each handwheel pulse.

Possible values:



JOG-INC: 1, 10, 100, 1000, 10000  $\mu\text{m}$  or variable between 0 and 10000.

Handwheel: 1, 10, 100  $\mu\text{m}$


Modifications to VAR. INCREMENTAL weighting:

JOG INC input field:

- 1) You enter any value between 1 and 10000, as described in Section 2.4.4 (Input field entries).

- 2) You operate key  or  to select the five values (1, 10, 100, 10000) in ascending or descending order.

HANDWHEEL input field:

You operate key  or  to select the three values (1, 10, 100) in ascending or descending order.

Explanations  
to all other fields:

S. Section 3.2.2.

### 3.4 JOG-REPOS submode


After a program interruption, you can move away from the contour, for example, by switching to JOG mode. In the JOG-REPOS mode you move the tool back to the point of interruption by means of the direction keys and the set feedrate value.

The OFFSET VALUE display shows the distance from the actual position to the point of interruption with the correct sign.

When the point of interruption is reached, the "OFFSET VALUE" display is zero and the direction keys are no longer active.

#### 3.4.1 JOG-REPOS basic display

The following display appears after you have operated the JOG-REPOS softkey in the JOG mode basic menu:



#### 3.4.2 Notes on JOG-REPOS basic display

The explanation of the fields given in Section 3.2.2 applies here.

### 3.5 JOG-REF submode

The control and the machine are synchronized in this mode after the control has been switched on. The reference point is approached with each of the axes, one after the other.

When the reference point is reached, the reference point value for the axis concerned stored in the machine data is displayed as the actual position, and the corresponding axis name field is darkened.

#### 3.5.1 JOG-REF basic display

You are located in the JOG mode basic menu and select JOG REF mode by operating the softkey concerned. The following display appears:

ACTUAL POSITION		REF. POINT		FEEDRATE	
X	0.000	0.000	Command	0.000	100%
Y	0.000	0.000	Actual	0.000	[mm/min]
Z	0.000	0.000			

#### 3.5.2 Notes on JOG REF basic display

The explanation of the fields given in Section 3.2.2 applies here.

### 3.6 MDA mode


It is in this mode that the individual part program blocks can be entered in the buffer storage of the control using the operator keyboard. The control processes the entered block when the NC START key is pressed and clears the buffer memory for new entries.

#### 3.6.1 MDA basic display

After selecting the MDA mode in the machine area by means of the following key:




the following basic display appears:




#### Short explanation of softkeys:

- OVERSTORE : Entry of auxiliary functions (s. Section 5.3.12)
- PRESET : Set actual value (s. Section 5.3.13)
- PROGRAM CONTROL : Modify sequence of a part program (s. Section 5.3.5)
- OPERATOR PROMPTING : Parameter support for subroutine programs (s. Section 5.3.11.1)


### 3.6.2 Notes on MDA basic display




Display of the addresses of each of the axes. After the reference point of an axis has been set, the appropriate field is darkened.




The actual position of each of the axes is shown in these fields.




The distance to go produced during the processing of the commenced NC block, is displayed here.




Movement of an axis in a positive or negative direction is indicated by a plus or minus sign in the appropriate field.



Display of the feedrate set and actual value, type of feedrate and position of the feedrate/rapid traverse override switch.



Display of spindle speed set as well as position of spindle speed override switch.



You enter the NC block to be processed in this input field. After the block has been processed, this field is cleared.



### 3.7 AUTOMATIC mode

The previously selected part program is executed in this mode. A part program (e.g. on punched tape) entered via the universal interface or directly through the operator keyboard. Other programs can be edited whilst a part program is being executed.

#### 3.7.1 AUTOMATIC basic display

After AUTOMATIC mode has been selected using the following key:




the following basic display appears:


<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%50					
					RESET									
<b>ACTUAL POSITION</b>		<b>REMAINING DIST.</b>		↓		<b>FEEDRATE</b>								
X	0.000	0.000			Command	0.000	100%							
Y	0.000	0.000			Actual	0.000	[mm/min]							
Z	0.000	0.000			<b>SPINDLE</b>									
					Command	0	100%							
					Actual	0								
<b>ACTIVE PROGRAM</b>					<b>TOOL</b>					<b>AUX/MISC. FUNCTIONS</b>				
%50 1 → 2 → 3 →					D _____ M _____ T _____ H _____					<b>CURRENT G FUNCTION</b>				
OVERSTORE		PRESET		MODIFY PROGRAM		BLOCK SEARCH		ACTUAL BLOCK		SELECT PROGRAM				




### 3.7.2 Notes on AUTOMATIC basic display




Display of the addresses of each of the axes. After the reference point of an axis has been set, the appropriate field is darkened.




The actual position of each of the axes is shown in these fields.




The distance to go arising during the processing of the commenced NC block, is displayed here.







Movement of an axis in a positive or negative direction is indicated by a plus or minus sign in the appropriate field.



Display of the command and actual value of the feed rate and feed rate type as well as the position of the feedrate/rapid traverse override switch.



Display of spindle speed set and actual value as well as position of spindle speed override switch.

ACTIVE PROGRAM			
 %66 N60			
1	 L471	P1	N5
2			
3			

The number of the block now to be processed is displayed in this window. In this example, the block to be processed is block N5 from subroutine L471. Subprogram L471 has been called up from the main program %66 in block N60.

TOOL		AUX. MISC. FUNCTIONS	
D	0	M	3
T	0	H	0

The active tool number (T) and the override number (D) as well as the M and H functions last programmed are displayed here.

ACTIVE G FUNCTIONS					
G00	G16	G40	G54		
G60	G71	G80	G90	G91	
G50					

This field displays the G functions which are currently valid or programmed.

**Short description of softkeys:**

- OVERSTORE : Entry of auxiliary functions (s. Section 5.3.12)
- PRESET : Set actual value (s. Section 5.3.13)
- PROGRAM CONTROL : Modify sequence of a part program
- BLOCK SEARCH : Program begin at the relevant point of the part program (s. Section 5.3.4)
- ACTIVE BLOCK : Display of the active block contents (s. Section 5.3.2)
- SELECT PROGRAM : Selection of part program for execution (s. Section 5.3.1)
- OVERRIDE BLOCK : Display of part program block with possibility for editing (s. Section 5.3.14)

### **3.8 TEACH IN mode**

For software version 3 the TEACH IN mode is not yet available.


## 4 Data Input

### 4.1 General comments

In the previous sections the functions of operator controls (Section 4) and operating modes (Section 3) are described.



Section 4 explains the input of data for programs, parameters, tool offsets, zero offsets, data transfers and diagnostics.

Section 4 structure follows the menu tree structure "data area":




Section 4 and 5 inform about SINUMERIC 805 operation.

They explain:



## 4.2 Data area basic display

The following display appears when the data storage area is selected using the operating area key on the SINUMERIK 805.




### Notes:

- The key LED on the data area key lights up when the data area has been selected.
- The menu tree is shown in Section 2.4.2.
- See also Section 2.4 (Operating areas, menu tree).

## 4.3 Program

When the "PROGRAM" softkey in the data storage area basic display is operated, the following display appears:



### Short description of the softkey bar:

MODIFY PROGRAM	Edit the program selected by cursor. (Section 4.3.1)
NEW PROGRAM	Create a new part program. (Section 4.3.2)
SELECT PROGRAM	When this softkey is operated, the program selected by means of cursor is selected for processing by the control. (Section 4.3.3)
MEMORY ALLOCATION	Indicates the user memory size (part program memory), the free and allocated user memory space. (Section 4.3.4)
SUBROUTINE PROGRAMS	Switchover to the MAIN PROGRAM DIRECTORY. (Section 4.3.5)
SEARCH	Direct input of the program number of the part program being searched for. (Section 4.3.6)


**Softkeys in the menu extension bar:**

- COPY : Copy the selected program onto a new program number (Section 4.3.7).
- DELETE : The program selected by cursor or by entering the program number can be deleted (Section 4.3.8).
- RENAME : The selected program is given another number (Section 4.3.9).
- RELOCATE : The selected program is pushed to the end of the memory for editing (Section 4.2.10)
- REORGANIZE : The part program memory is reorganized (Section 4.3.11).

**4.3.1 Program editing**

Sequence of operation


**Prerequisite::** The desired program is selected in the OVERVIEW MAIN PROGRAMS/SUBROUTINES (s. Section 4.2.3).




Operate the PROGRAM EDIT key. If %50 is selected, for example, the following display appears:

**Note:**

Simultaneous to a running program (in this example %28) you can edit another program (in this example %50).





Use the page or cursor keys to move the cursor to the part of the part program which is to be modified.



You can delete the character selected by the cursor with the DELETE key.



Insert a new block after the block selected by the cursor.




Delete the block selected by the cursor.



Alternate between insert and replace mode.

Insert mode : The keyed in characters are inserted in the part program in front of the point where the cursor is positioned.

Overwrite mode : The keyed in characters overwrite those already contained in the part program from the point where the cursor is positioned.



The most recent modifications in the text are reversed. This is only possible if the INPUT key has not been operated.




Use the INPUT key to transfer the modification of the block into memory.





When the SEARCH key is operated, the following window appears:




The character string being searched is keyed in via the keyboard.



When the INPUT key is operated, the entry is entered into the control and the cursor positioned on the character string being searched for.

### 4.3.1.1 OPERATOR PROMPTING in edit mode



This function is a user input support for parameter assignment at Siemens Standard Cycles and User Cycles.

For each subroutine programmable with R parameter the user can install OPERATOR PROMPTING function (see Programming Guide, Section 12). The OPERATOR PROMPTING can be called in MDA and in edit mode.

#### a) Manual subroutine selection


Sequence of operation

#### Prerequisite::

Edit mode has been selected (Section 4.3.1 resp. 4.3.2)

OPERATOR  
PROMPTING

Operation of OPERATOR PROMPTING softkey opens a window listing all subroutines fitted out with operator prompting.





Exist more than 6 subroutines with operator prompting they can be displayed by operating PAGE UP/DOWN soft-keys.




Using the cursor keys you can select the wanted subroutine in the overview display (inverse displayed = selected).


### b) Subroutine selection using the SEARCH softkey

#### Sequence of operation


**Prerequisite:** MDA mode has been selected.



Operation of OPERATOR PROMPTING softkey opens a window listing all subroutines fitted out with operator prompting.



Operate the SEARCH softkey. The following window appears:





Key in the desired subroutine number in the opened entry field.




Operation of INPUT key closes entry field and window.  
Now the wanted subroutine is selected (inverse displayed).

### Parameter assignment for the selected subroutine


**Prerequisite:** The wanted subroutine has been selected.



Operation of PARAMETER softkey opens another window listing all subroutines fitted out with operator prompting.



Use cursor keys for R parameter selection.




Now enter the parameters after description in Section 2.4.4 (Entries in Input fields).




Exist more than 7 parameters for the subroutine they can be displayed by operating PAGE UP/DOWN softkeys.



After operating the ACCEPT DATA softkey the part program accepts the entered R parameter assignments. After all R parameter assignments the subroutine call automatically is entered. The PARAMETER and DIRECTORY windows are closed. You are back in edit mode.



**Note:**

After operation of REPLACE softkey the error message "STOP NOT ALL PARAMETERS ENTRIES" appears when not all parameters are entered. The window is closed by operating  key.

## 4.3.2 Create new program


### Sequence of operation

#### Prerequisite:

The MAIN PROGRAM/SUBROUTINE DIRECTORY has been selected (see Section 4.3.5).

NEW  
PROGRAM


The following window (in the case of main programs) appears when you operate the NEW PROGRAM softkey:





Now key in the program number of the part program to be created.



Operating the INPUT key closes the input field and takes you into the EDIT mode.



You can now enter one block after the other through the keyboard. You must, however, complete every block by pressing the ...  key.



Use the page or cursor keys to move the cursor to the part of the program which is to be modified.



You can delete the character selected by the cursor with the DELETE key.



Insert a new block after the block selected by the cursor.



Delete the block selected by the cursor.



Alternate between insert and overwrite mode.

Insert mode : The keyed in characters are inserted in the part program from the point where the cursor is positioned.

Overwrite mode : The keyed in characters overwrite those already contained in the part program from the point where the cursor is positioned.



Programming support for subroutines (see Section 4.3.1.1).

### 4.3.3 Part program selection for program execution


You can use the SELECT PROGRAM softkey to select a specific main program contained in the program memory for program execution in the AUTOMATIC mode.

#### Sequence of operation

SELECT  
PROGRAM

Press the SELECT softkey.

The program number of the program selected in MAIN PROGRAMS OVERVIEW now appears in the field designated for program numbers (s. Section 2.3).



Now key in the program number in the opened input field.



Operating the INPUT key closes the input field and takes you into the EDIT mode.

#### Note:

You can also select a program for program execution in the basic menu of the AUTOMATIC mode (s. Section 5.3.1).




### 4.3.4 Memory allocation of the part program memory

By operating the MEMORY ALLOCATION softkey in the main program or subroutine directory, you can call up information regarding the memory allocation of the program memory.


Sequence of operation:

**Prerequisite:**

The MAIN PROGRAM or SUBROUTINE DIRECTORY is selected (s. Section 4.2.5).



You open the following window when you press the MEMORY ALLOCATION softkey.



You close the window by pressing the RECALL button. The overview previously selected appears on the screen.

**Note:**

After selecting the DATA TRANSFER basic menu (s. Section 4.6), the available, allocated and free memory space in the part program memory is displayed as above.






### 4.3.6 Selecting a program in the overview

If you wish to select, display or modify a main program or display or modify a subroutine, you can select the required program in the MAIN PROGRAM or SUBROUTINE DIRECTORY manually or by means of the SEARCH softkey as follows:

#### a) Manual program selection

Sequence of operation when selecting a program manually:



Use the PAGE UP/DOWN keys to select the directory display which contains the required main program or subroutine.



Use the cursor keys to select the desired main program or subroutine within one directory display (displayed in reverse video = selected).




b) Program selection using **SEARCH** softkey

Sequence of operation

SEARCH

Operate the SEARCH softkey to open the following window:



Now key in the number of the desired main program or subroutine in the opened input field using the numeric keys.



Use the INPUT key to close the input field and the window. The required program is now selected in the MAIN PROGRAM DIRECTORY or in the SUBROUTINE DIRECTORY (displayed in reverse video).

### 4.3.7 Copy part programs

You can additionally store a part program under a different program number using the COPY softkey.

#### Sequence of operation

#### Prerequisite:

The required program is selected in the MAIN PROGRAM or SUBROUTINE DIRECTORY (Section 4.3.6)

COPY

By operating the COPY softkey, you open the following window:



Now key in the program number by which the copied program is to be known.



Operate the INPUT key to end the entry and execute the copy function.

### 4.3.8 Delete part program

#### Sequence of operation

**Prerequisite:** The MAIN PROGRAM or SUBROUTINE DIRECTORY is selected.



By operating the DELETE softkey, you open the following window:



Now key in the program number of the part program to be deleted.



Operate the INPUT key to end the entry and execute the delete function.

## 4.3.9 Rename part program

You can use the RENAME function to change the program number of a part program.


### Sequence of operation

#### Prerequisite:

The required program has been selected in the MAIN PROGRAM OR SUBROUTINE DIRECTORY.

RENAME

Operate the RENAME key to open the following window:



Now key in the new program number.



Operate the INPUT key to end the entry and execute the function.



### 4.3.10 Relocate part program

You use the **MOVE** function to shift the selected program to the end of the memory. This is necessary in the following cases:

- 1) You wish to edit the program whilst processing another part program. The program to be edited must be shifted with the **MOVE** function.
- 2) You wish to edit the program and extend it by 1500 characters.

#### Sequence of operation

MOVE

Operate the softkey MOVE. The function is executed without a message.

### 4.3.11 Reorganize part program memory

Any memory made available when part programs have been deleted is not taken into account when the memory is allocated. You can use the function **REORG** to reorganize the contents of a program memory. Thus, any memory space made available by deleting programs can be used again for program entries (see also alarm no. 31: No further part program input possible).

#### Sequence of operation

REORGANIZE

Operate the softkey REORGANIZE. The function is executed with the message "Part program is being reorganized."

The free memory space is checked using the MEMORY ALLOCATION function (Section 4.3.1).

## 4.4 Data/Parameters

The following display appears on the screen when the softkey DATA/PARAMETER is operated in the basic display of the data area:

<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%28
					RESET				
<b>R PARAMETER</b>									
R 0	6.0		R 15	220.5					
R 1	0.0		R 16	35.0					
R 2	27.0		R 17	60.0					
R 3	0.0		R 18	6.0					
R 4	3.0		R 19	3.0					
R 5	60.0		R 20	2000.0					
R 6	0.0		R 21	31.0					
R 7	1000.0		R 22	0.5					
R 8	1000.0		R 23	0.0					
R 9	0.0		R 24	0.0					
R 10	0.0		R 25	0.0					
R 11	0.0		R 26	0.0					
R 12	100.0		R 27	0.0					
R 13	48.0		R 28	0.0					
R 14	118.0		R 29	0.0					

R PARAM	SETTING DATA	NC-MD VALUES	NC-MD BITS	PLC-MD	CLEAR AREA	SEARCH
---------	--------------	--------------	------------	--------	------------	--------

Data/parameter basic display

### Short discription of softkeys:

R PARAM	:	} Operate the appropriate softkey to select the desired data type.
SETTING DATA	:	
NC-MD VALUES	:	
NC-MD BITS	:	
PLC-MD	:	
CLEAR AREA	:	Clear an area which can be input.
SEARCH	:	Selection of a particular data parameter.

### Notes:

- The selected data type is displayed in reverse video.
- The R parameter data type is selected in the DATA/PARAMETER display.
- The moveable input field is dark.

### 4.4.1 R parameters


Sequence of operation for the selection of an R PARAMETER using the SEARCH softkey.

**Prerequisite:**


The R PARAM data type is selected (either by selecting the data area or by operating the softkey R PARAM).



You open the following window by operating the SEARCH softkey:



Now key in the number of the desired R PARAMETER in the input field which has already been opened using the numeric keys.



Use cursor and edit keys where necessary.



You enter the value and close the window using the INPUT key.

The following display appears when e.g. R968 is selected:

<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%28	
					RESET					
<b>R PARAMETER</b>										
R 961	0.0	X	R 976	0.0						
R 962	0.0		R 977	0.0						
R 963	0.0		R 978	0.0						
R 964	0.0		R 979	0.0						
R 965	3.0		R 980	0.0						
R 966	0.0		R 981	0.0						
R 967	0.0		R 982	0.0						
R 968	0.0		R 983	0.5						
R 969	0.0		R 984	0.0						
R 970	0.0		R 985	0.0						
R 971	0.0		R 986	0.0						
R 972	0.0		R 987	0.0						
R 973	0.0		R 988	0.0						
R 974	0.0		R 989	0.0						
R 975	0.0		R 990	0.0						
R PARAM			SETTING DATA	NC-MD VALUES	NC-MD BITS	PLC-MD	CLEAR AREA	SEARCH		

The value R968 appears in the darkened R968 input field. You can alter this value as follows.


### Sequence of operation for altering an R PARAMETER value

**Prerequisite:** The input field for the R PARAMETER to be changed has been selected using the SEARCH softkey or manually.

**Notes:**

- R PARAMETER values can be modified as described in section 2.4.4 (Entry in input fields).
- The calculator function (Section 2.4.5) can be applied to R PARAMETERS.

## Sequence of operation when selecting an R PARAMETER manually



You move the dark input field between R PARAMETERS R0 and R999 using these keys.



You move the input field to the parameter situated above left by operating the HOME key.



You page one display at a time forwards or backwards using these keys.


## Sequence of operation when clearing an R PARAMETER area

CLEAR  
AREA

Operate the softkey CLEAR AREA to open the following window:

R PARAMETER	Value
R 961	0.0
R 962	0.0
R 963	0.0
R 964	0.0
R 965	3.0
R 966	0.0
R 967	0.0
R 968	0.0
R 969	0.0
R 970	0.0
R 971	0.0
R 972	0.0
R 973	0.0
R 974	0.0
R 975	0.0
R 976	0.0
R 977	0.0
R 978	0.0
R 979	0.0
R 980	0.0
R 981	0.0
R 982	0.0
R 983	0.0
R 984	0.0
R 985	0.0
R 986	0.0
R 987	0.0
R 988	0.0
R 989	0.0
R 990	0.0

Clear dialog box:  
from 6  
to 181




Now key in the first R PARAMETER to be deleted using the numeric keys in the opened field "from".

Use the cursor and edit keys where necessary.



Transfer the keyed in value using the INPUT key.



Key in the number of the last R PARAMETER to be deleted using the numeric keys in the opened field "to".

Use the cursor and edit keys where necessary.




Enter the keyed in value using the INPUT key.



Operate the softkey START to initiate the delete process of the input R parameter area and close the window. All R parameters of the deleted area now have the value 0.

**Note:**

Before operating the softkey START, you can close the window using the

RECALL  key. The delete process is not executed.

## 4.4.2 Setting data

When you have selected the data type SETTING DATA using the appropriate softkey, the following display appears:

<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%28
RESET									
<b>SETTING DATA</b>									
<b>WORKING AREA</b>					<b>GENERAL DATA</b>				
		MIN.		MAX.	DRY RUN <span style="float: right;">0</span> WORKPIECE RELATED <input type="checkbox"/> ACTUAL VALUE SYSTEM <input type="checkbox"/>				
X		-99999999		99999999	<b>SPINDLE DATA</b>  SPEED LIMIT <input type="checkbox"/> PROG. SPEED LIMIT (G92) <input type="checkbox"/> ORIENTED SPINDLE STOP (M19) <input type="checkbox"/> FEED ACCELERATION RAMP <input type="checkbox"/> TIME FOR THREADS <input type="checkbox"/>				
Y		-99999999		99999999					
Z		-99999999		99999999					
R PARAM	SETTING DATA	NC-MD VALUES	NC-MD BITS	PLC-MD					

### Sequence of operation for altering setting data


To modify or enter setting data, please follow the instructions in Section 2.4.4 (Entry in input fields).



Description	Standard value	Maximum input value	Reference system	Input unit
Dry run	0	24 000	IS	1000 units/min
Feed acceleration ramp time for threads	0	5		-
Min. working area limit	0	+/- 99 999 999	IS	units/min
Max. working area limit	0	+/- 99 999 999	IS	units/min
Prog. speed limit	0	12 000		rev/min
Oriented spindle stop	0	359.9		1/10 degrees
Spindle speed limit	0	12 000		rev/min

1) The "Maximum input value" is defined in MD!  
 2) The "Input unit" is defined in the MD:  
 Instead of rev/min, it can also be 0.1 rev/min

The "workpiece-related actual value system" can be activated or deactivated as follows:



You select the appropriated input field using the cursor keys.

You activate or deactivate the function each time the PLUS/MINUS key is operated. The input field shows you whether the function is active or not.

Workpiece-related actual value system = not active

Workpiece-related actual value system = active

**Note:**

The field situated above left is selected by operating the HOME key. (Min. working area X-axis).

### 4.4.3 NC-MD values

The following display appears after the data type NC-MD VALUES has been selected using the relevant softkey.

<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%28
<b>RESET</b>									
<b>NC-MACHINE DATA VALUES</b>									
MD 0	2000	<input checked="" type="checkbox"/>	MD 100	1					
MD 1	500		MD 101	2					
MD 3	500		MD 102	4					
MD 6	0		MD 103	6					
MD 7	5		MD 104	8					
MD 8	50		MD 105	10					
MD 9	200		MD 106	20					
MD 10	1000		MD 107	30					
MD 11	0		MD 108	40					
MD 14	10000		MD 109	50					
MD 15	10000		MD 110	60					
MD 16	10000		MD 111	70					
MD 17	10000		MD 112	75					
MD 18	0		MD 113	80					
MD 19	0		MD 114	85					
<b>R PARAM</b>		<b>SETTING DATA</b>	<b>NC-MD VALUES</b>	<b>NC-MD BITS</b>	<b>PLC-MD</b>	<b>SEARCH</b>			



**Note:**

A password is requested when NC-MD values are entered or altered.

Sequence of operation when selecting MC-MD values using the SEARCH softkey

SEARCH

Operate the SEARCH softkey to open the following window:



Now key in the required NC-MD number in the input field which has already been opened, using the numeric keys.

Use the cursor and edit keys where necessary.

Operating the INPUT key enters the value and simultaneously closes the window.

**Example:**

When NC-MD 4150 has been selected, the following display appears:

NC-MACHINE DATA VALUES	
MD 4080	4000
MD 4090	4000
MD 4100	4000
MD 4110	50
MD 4120	500
MD 4130	1000
MD 4140	2000
MD 4150	2000
MD 4160	2000
MD 4170	2000
MD 4180	2000
MD 4190	2000
MD 4200	2000
MD 4210	2000
MD 4220	2000
MD 4230	2000
MD 4240	2000
MD 4250	2000
MD 4260	2000
MD 4270	100
MD 4280	100
MD 4290	100
MD 4300	100
MD 4310	100
MD 4320	100
MD 4330	100
MD 4340	100
MD 4350	200
MD 4360	200
MD 4370	200

### Sequence of operation for manual selection of an NC-MD value



You shift the dark input field within the whole NC-MD value area using these keys.

You shift the input field to the NC-MD value situated above left by operating the HOME key.



You page up or down one display at a time using these keys.



## Sequence of operation to alter an NC-MD value

**Prerequisite:**

You have selected the NC-MD manually or by means of the SEARCH softkey.  
 The password has not been entered.



You open the following window when you operate the EDIT key:



Now key in the password for the control in the input field which has already been opened.

Use the cursor and edit keys where necessary.

The keyed in password is checked using the INPUT key. If the password is not correct, the window remains open. Enter a new password. The window will close if the password is correct.

The NC-MD values can now be altered as described in Section 2.4.4 (Entry in input fields).

**Notes:**

- When one password is entered, entries in the data types NC-MD BITS and PLC-MD are also possible.
- the password must be re-entered the next time the control is switched on.
- Effective alterations to the NC-MD values depend on the NC-MD number after POWER ON, RESET, NC-STOP/START or immediately.

**4.4.4 NC-MD BITS**

The data type NC-MD BITS is selected using the appropriate softkey. The following display appears:

AUTOMATIC		SKP	DRY	ROV	DBL	DRF	M01	FST	%28
RESET									
<b>NC-MACHINE DATA BITS</b>									
MD 5000	00000110								
MD 5001	00000011								
MD 5002	00100010								
MD 5003	00000100								
MD 5004	00001101								
MD 5005	00000000								
MD 5006	00000000								
MD 5007	00000100								
MD 5008	00000000								
MD 5009	01100000								
MD 5011	00000000								
MD 5012	00000100								
MD 5013	11000000								
MD 5014	11100000								
MD 5015	00000011								
MD 5016	00000000								
MD 5147	00000000								
MD 5148	00000000								
MD 5149	00000000								
MD 5150	00000011								
MD 5200	00000000								
MD 5210	10010000								
MD 5400	00000101								
MD 5460	00000000								
MD 5480	00000000								
MD 5500	00000001								
MD 5520	00000010								
MD 5540	00000000								
MD 5560	00000000								
MD 5580	00000000								
R PARAM	SETTING DATA	NC-MD VALUES	NC-MD BITS	PLC-MD	SEARCH				


**Note:**

The password is requested when NC-MD BITS are entered or altered.

Sequence of operation when selecting an NC-MD bit using the SEARCH softkey

Proceed as described in Section 4.4.3.

If, for example, NC-MD 5640 is selected, the following display appears:



Sequence of operation for manual selection an NC-MD bit

Proceed as described in Section 4.4.3.


Sequence of operation for altering an NC-MD bit

**Prerequisite:**

You have selected the input field required manually or using the SEARCH softkey.  
 "The password has not been entered".




The following window opens when you operate the EDIT key:



Now key in the password using the numeric keys.  
Operating the INPUT key enters the password and simultaneously closes the window.



Now open the selected input field by operating the EDIT key. The cursor is on bit 7.



Shift the cursor field using these keys onto the bit to be altered and key in the desired value using the numeric keys 0 or 1.



Operating the EDIT key again closes the input field. The original bit pattern remains.



After input of all bits to be altered, enter bit pattern using the INPUT key.




**Notes:**

- If the password is only entered once, it is also possible to make entries in the NC-MD VALUES and PLC-MD data types.
- The password must be re-entered when the control is switched on again.

**4.4.5 PLC-MD**

Select the data type PLC-MD using the appropriate softkey. The following display appears:




**Note:**

The password is requested when a PLC-MD is entered or altered.


## Sequence of operation for selecting a PLC-MD



Use these keys to move the darkened input field within the whole MC-MD area.



You move the input field to the PLC-MD situated above left by operating the HOME key.



You page one display at a time forwards or backwards using these keys.


## Sequence of operation for altering a PLC-MD

### Prerequisites:

You have selected the appropriate input field manually.



Operate the EDIT key to open the following window:



Now key in the password using the numerical keys. By pressing the INPUT key you enter the password and simultaneously close the window.



Operate the EDIT key to open the selected input field.



Now key in the required value using the numerical keys.

Pressing the EDIT key again closes the input field. The original value is maintained.



After keying in the value to be altered, operate the INPUT key to enter the value.



**Notes:**

- If the password is only entered once, it is also possible to make entries in the NC-MD VALUES and PLC-MD bits.
- The password must be re-entered when the control is switched on again.

**4.5 Tool offset**

By operating the appropriate key in the basic menu of the data area, the following display TOOL OFFSET appears:

The screenshot shows the 'TOOL OFFSET' screen with the following data:

OFFSET BLOCK		
TOOL OFFSET NO.	D	1

OFFSET DATA		
TOOL NO.	T	9999
TOOL TYPE		20
	GEOMETRY	WEAR
LENGTH 1	10.23600	0.00000
LENGTH 2	0.00000	0.00000
RADIUS	5.00000	0.00000
	BASE	
	0.00000	

**TOOL TYPE**: Shaft miller

The diagram shows a shaft miller tool with labels for 'L1' and 'Radius'.

**Bottom Menu Bar:** PROGRAM, DATA PARAMETER, TOOL OFFSET, ZERO OFFSET, DATA TRANSFER, DIAGNOSIS

**Notes:**

- The tool offset numbers in SINUMERIK 805 are D1 to D99.
- Each offset number contains the tool parameters P0 to P9 for entering tool identity and data:  
Each of the tool parameters is described in Section 5.2.4.1.
- For each entered tool type a graphic representation appears on which the position of the offset data is shown.

### 4.5.1 Selecting the tool offset numbers

There are two possible ways of selecting the tool offset numbers

#### a) using PAGE UP/DOWN softkeys

Sequence of operation 1



Using the page keys you can move to the next offset number upwards or downwards (D number).



#### b) using the offset number input

Sequence of operation 2



Use the HOME key to select the OFFSET NO. input field.



Operate the EDIT key to open the input field.



Now key in the required offset numbers using the numerical keys.



After keying in the offset numbers, operate the INPUT key. The parameters of the selected offset numbers are displayed.


### 4.5.2 Deleting/altering a tool parameter

Sequence of operation

#### Prerequisite:

You have selected a tool offset number for which you wish to delete/alter a tool parameter.


Proceed as described in Section 2.4.4 (Entry in input fields) to delete/alter a tool parameter.



**The wear parameters P5 to P7 can be declared invalid  
by means of machine data!**

**Additionally, the tool parameters can be extended by  
the base parameters P8 and P9!**

**(Please consult the machine tool manufacturer)**



**Note:**

Values in the range +/- 9.999 are possible for wear parameters P5 to P7.

## 4.6 Zero offset

The following overview of zero offsets for all axes is displayed when the ZERO OFFSET softkey in the basic menu of the data area has been operated:

		X	Y	Z	
<b>ZERO OFFSET</b>					
G54	ZO ZERO OFFSET FINE	0.00000	0.00000	0.00000	
		0.00000	0.00000	0.00000	
G55	ZO ZERO OFFSET FINE	0.00000	0.00000	0.00000	
		0.00000	0.00000	0.00000	
G56	ZO ZERO OFFSET FINE	0.00000	0.00000	0.00000	
		0.00000	0.00000	0.00000	
G57	ZO ZERO OFFSET FINE	0.00000	0.00000	0.00000	
		0.00000	0.00000	0.00000	
G58	ZO ZERO OFFSET PROG.	0.00000	0.00000	0.00000	
G59	ZO ZERO OFFSET PROG.	0.00000	0.00000	0.00000	
	ZO ZERO OFFSET EXTERN	0.00000	0.00000	0.00000	

PROGRAM	DATA PARAMETER	TOOL OFFSET	ZERO OFFSET		DATA TRANSFER	DIAGNOSIS
---------	-------------------	-------------	----------------	--	------------------	-----------

**Notes:**

- Only values for settable zero offsets (G54 to G57) can be entered using the corresponding input fields.
- All zero offsets can be deselected block by block in the part program with G53.

Sequence of operation for entering values for G54 - G57



Use the cursor keys to select the appropriate input field.



You can now enter the required value as described in Section 2.4.4 (Entry in input fields).



**Notes:**


- Use the HOME key to select  the original input field (top left).



- The calculator function (Section 2.4.5) can also be applied to all input fields for G54 to G57.

## 4.7 Data transfer

The following display appears when you operate the softkey DATA TRANSFER:



### Note:

Available, occupied and free part program memory space is shown in the basic menu DATA TRANSFER.

### Explanation of softkeys:


READ-IN START	Prepares the selected interface to receive data.
STOP	Stops data transfer in the read-in/read-out function.
READ-OUT START	Selects the display "data output".
2nd RS232 C	Selection of interface (interface 1 or interface 2 (option)).
PARAMETER	To alter the transfer parameters.


See Section 6, Data Interfaces, for additional information.




## 4.8 Diagnostics

The following display appears when you operate the DIAGNOSIS softkey in the basic menu of the data area:




**Explanation of softkeys:**

All active NC, PLC alarms and PLC messages are displayed.




Only the NC alarms are displayed.



Only the PLC alarms (system alarms and user alarms) are displayed.

**Note:**


See Section 8.3.2 for further details regarding alarms/messages.



Only the PLC user messages are displayed.

**Note:**

PLC user alarms and messages must be stored by the manufacturer as a subroutine (see Programming Guide Section 1.6).



State of inputs, outputs, flags etc in the PLC can be scanned using the PLC STATUS function (Section 4.8.1).



This key is operated by service personnel for an information diagram of the axes and spindles (see Section 4.8.2).

### 4.8.1 PLC status

The PLC STATUS softkey is operated to receive information on the current state of the following memory locations in the PLC and change them where necessary:

Inputs	Input bit	(Ix)	Input byte	(IBx)	Input word	(IWx)
Outputs:	Output bit	(Qx)	Output byte	(QBx)	Output word	(QWx)
Flags:	Flag bit	(Fx)	Flag byte	(FBx)	Flag word	(FWx)
Times:	Time	(Tx)				
Counter:	Counter	(Cx)				
Data:	Data block	(DBx)	Data word	(DWx)		

Operand	E.g.	Read	Write	Format	Value	Area
<b>Inputs</b>		Yes	Yes			0-127
	I 0.0 IB 2  IW 2			B B H D B H D	0 0101 1010 5A 90 0101 1010 1100 0011 5AC3 23235	
<b>Outputs</b>		Yes	Yes			0-127
	Q 0.1 QB 20  QW 20			B B H D B H D	1 1101 0110 D6 214 1101 0110 1100 0011 D6C3 40379	
<b>Flags</b>		Yes	Yes			0-255
	M 0.7 MB 60  MW 60			B B H D B H D	0 1011 0100 B8 180 1011 0100 0100 0000 B880 47232	
<b>Times</b>		Yes	No			0-31
				B H D		

Formats: B=Binary  
H=Hexadecimal  
D=Decimal

Operand	E.g.	Read	Write	Format	Value	Area
<b>Counter</b>		Yes	No			0-31
				B H D		
<b>Data block Data word</b>		Yes	Yes			0-255 0-255
	DB 3 DW 9			H D B	A 10 0000 0000 0000 1010	



Formats: B=Binary  
H=Hexadecimal  
D=Decimal

**Note:**

A maximum of 10 operands can be displayed at the same time.

## Sequence of operation for selecting operands

**Prerequisite:** PLC status has been selected (Section 4.8).



Use the cursor keys to position the cursor on one line. The required operator (e.g. IW 2=^input word 2) is entered in the operator input field as described in Section 2.4.4 (Entry in input fields). The required numerical representation is now entered in the format line as described in Section 2.4.4. A separate numerical representation can be selected for each operand or each line. The operator status is shown in the "Value" field.

**Note:**

The increment/decrement keys can be used to run through an operator field or the format in ascending or descending order and select the desired setting.


**Example:**

The cursor is situated in the "Operator" column on an occupied line, which in this case is QB 100. The operator is increased to QB 101 by operating the increment key.

## Sequence of operation for altering a value (control)


**Prerequisite:**

Operand has been selected.



Using the cursor keys the cursor is positioned on the "Value" field of the operand to be altered.  
The operand contents are now altered in the "Value" field as required, as described in Section 4.2.2 (Entry in input fields).  
(Take note of the selected numerical representation).

## Sequence of operation for clearing the operand




The cursor is moved to the line to be cleared by means of the cursor keys.



Operate the CLEAR softkey. Now the line is without entry.

## 4.8.2 Service

If the SERVICE softkey is operated by service personnel, information regarding the axes and spindles is given.



### Explanation of softkeys:



Operating the appropriate softkey executes a drift compensation on the axis concerned.

**Explanation of service data:**

- Absolute actual value      The actual position of the axis. The position is displayed in the machine reference system (no allowance made for ZO and TO) in position control resolution units.

**Example:**    If 200 000 is displayed at a position control resolution of  $0.5 \cdot 10^{-3}$  mm, this means that the axis is at position 100 (referred to machine zero).
- Following error              The difference between the position controller command value and the absolute value. The following error is displayed in position control resolution units.

**Example:**    If 2 000 is displayed at a position control resolution of  $0.5 \cdot 10^{-3}$ , this means that following error is 1 mm.
- Command value              This is the programmed target position. When the axis is in the target position (with no movement), the command value is equal to the absolute actual value (if there are any discrepancies, these can be removed by drift compensation). The command value is displayed in position control resolution units.

**Example:**    If 208 000 is displayed at a position control resolution of  $0.5 \cdot 10^{-3}$ , this means a command value of 104 mm (referred to machine zero).
- Speed command value      This is the speed command value determined by the control which is supplied to the drive actuator as an analog voltage value.  
Unit:  $1.22 \text{ mV} \hat{=} 1 \text{ VELO}$   
 $8192 \text{ VELO} \hat{=} 10 \text{ V}$

**Example:**    The displayed value 5638 corresponds to a speed command value of 6.87836.
- Part actual value            The pulses generated by the measuring system multiplied by 4 per position controller sampling interval (5 ms). It is necessary to multiply the number by 4 so that the part actual value (sampling interval 5 ms) can be compared to the part command value (sampling interval 20 ms).  
Unit: position control resolution (standard:  $0.5 \mu\text{m}$ )

**Example:**    The displayed value 24 corresponds to a  $12 \mu\text{m}$  path every 20 ms at a position control resolution of  $0.5 \mu\text{m}$ .
- Part command value        Pulses sent to the position control from the interpolator every interpolator cycle (20 ms).  
Unit: position control resolution (standard:  $0.5 \mu\text{m}$ )

**Example:**    Displayed value 18 corresponds to a  $9 \mu\text{m}$  path every 20 ms at a position control resolution of  $0.5 \mu\text{m}$ .



- Contour deviation                      The current contour deviation (fluctuations in the following error caused by adjustments to the speed controller as a result of changes in load).  
Unit: Position control resolution (standard 0.5  $\mu\text{m}$ )  
  
**Example:**    Displayed value 2 at a position control resolution of 0.5  $\mu\text{m}$  corresponds to a contour deviation of 1  $\mu\text{m}$ .

The following data is displayed in the SINUMERIK 805:

- Speed command value (VELO)      The command value sent from the control to the spindle actuator in VELO (1 VELO  $\hat{=}$  1,22 mV).
- Speed command value (rev/min)    The command value sent from the control to the spindle. The speed command value is displayed in rev/min).
- Speed actual value (rev/min)        The actual speed of the spindle. The speed actual value is displayed in rev/min).
- Position actual value (degrees)      Spindle position display in DEGREES. The position is shown in the range 0.1 - 359.9 degrees.
- Cutting speed (m/min)                Instantaneous cutting speed of tool cutting edge in m/min when G96 has been selected.

# 5 Operating Sequences

## 5.1 Preliminary remarks

This Section shows how to use the operating elements in frequently occurring operating sequences.


This Section is divided into two parts:

- In the first part (preparation) operating methods are explained that you use before, during or after **program input** or that you use **only once** before you start the control operation.
- In the second part (operation) the operating methods are explained that occur **during processing**.

## 5.2 Preparation

### 5.2.1 Switching on

When you switch the control and machine tool on:




A system screen appears for the first 5 s after switching on the control, after which on the basic menu for the JOG operating mode appears (see also Section 1.2).

## 5.2.2 Approach reference point ("REFPOINT")

After switching on, approach the reference points for the various axes. This synchronises the control with the machine. Axes can be referenced in different ways, therefore:

**Please follow the machine tool manufacturer's instructions!**



### Sequence of operation

#### Prerequisite:

Operating mode JOG has been selected (see Section 3.2.1).



Operating mode JOG-REF is selected using the softkey.





Using the axis selection key on the hand-held unit, select the axis to be referenced (e.g. axis Y).



Now operate the direction keys to commence the reference point approach of the Y axis.

**Notes:**

- The selected direction of approach is checked by the control before starting:

If you have operated the incorrect direction key (e.g.  instead of  ),

no traverse motion will result as the operation is rejected.




Using the FEED STOP key on the hand-held unit, you can stop the selected axis before the reference point is reached.

Once the reference point has been reached, the position value (referring to machine zero) is displayed as an actual value on the screen. The corresponding axis name is marked dark on the screen.

The same sequence of operation applies to the other axes. The control is now synchronized with the machine.

- The reference point approach operation can be carried out simultaneously on a maximum of two axes.



### 5.2.3 Automatic drift compensation

If a plus or minus sign remains in the screen field (see basic display JOG-REF) after the traversing movement of an axis in the JOG mode, for example, the drift has exceeded the permissible value and drift compensation must be carried out.




#### Sequence of operation

**Prerequisite:**

The machine area has been selected. The control is in the RESET state.



Use the OPERATING AREA key to select the data area.



Operate the DIAGNOSIS and the



SERVICE softkey




Operating the DRIFT COMP. ..., results in the automatic drift compensation of the desired axis.

**Notes:**

- In the case of an excessive drift, a following error remains for the axis in question. After the drift compensation has been executed, the following error tends to zero.
- The drift values are entered in the following NC-MDs:
  - NC-MD 2720            1st axis
  - NC-MD 2721            2nd axis
  - NC-MD 2722            3rd axis
  - NC-MD 2723            4th axis
- Drift values can also be entered manually in NC-MDs 2720 to 2723 (see Section 3.3.3).
- Drift values greater than 500 can no longer be called drift. Alarm 160\* is then given (drift too high).

## 5.2.4 Tool compensation




In the case of SINUMERIK 805, tool offsets can be entered under the tool compensation numbers D1 - D99 and the corresponding WZ parameters P0 - P9. The basic menu TOOL OFFSET can be selected as follows:

### Sequence of operation

**Prerequisite:** You are in the machine area.



Operate the OPERATOR AREA key to select the data area.



The following display appears when you operate the TOOL OFFSET softkey:

OFFSET BLOCK	
TOOL OFFSET NO.	D 1

OFFSET DATA	
TOOL NO.	T 9999
TOOL TYPE	20
LENGTH 1	10.23600
LENGTH 2	0.00000
RADIUS	5.00000



GEOMETRY	WEAR	BASE
10.23600	0.00000	0.00000
0.00000	0.00000	0.00000
5.00000	0.00000	

TOOL TYPE
Shaft miller
L1
Radius

PROGRAM   DATA PARAMETER   TOOL OFFSET   ZERO OFFSET   DATA TRANSFER   DIAGNOSIS

**Notes:**

- The offset numbers can be selected in two different ways:

– manually using keys  and  ,  
 or

– by entering the required number in the  
 OFFSET NUMBER input field.

- Each offset number contains the tool parameters P0 to P9 for entering the tool identification and data.

Tool parameter	Designation	Meaning
P0 P1	Tool number Tool type	Tool identity
P2 P3 P4	Length 1 Length 2 Diameter/radius	Geometry parameters
P5 P6 P7	Length 1 Length 2 Diameter/radius	Wear parameters
P8 P9	Length 1 Length 2	Base parameters


The individual parameters are described in later sections.

- The operating sequence for deleting/altering tool parameters is described in Section 4.5.2.


### 5.2.4.1 Description of tool parameters

#### Tool parameter P0: Tool number



This input field marked "0" is intended for the input of an 8-digit "tool number". You will not usually have to make such an entry; it may, however, be necessary to enter the number in the case of flexible tool management.



*Whether tool numbers are used or not is fixed in the MD!  
(See machine tool manufacturer's documentation)*



#### Tool parameter P1: Tool type




Tool	Tool type P1
1. Lathe tool  Example:  <b>Turning tool, facing tool</b>	  1 ... 9  <b>Note:</b> Input value explanations see: Diagram "Tool nose centre point positions"
2. Lathe tool  Example:  <b>Grooving tool (cutting edge)</b>	  1 ... 9




corresponds to the reference point of the tool clamping device (slide reference point).



**Tool parameter P1: Tool type**

	<b>Tool</b>	<b>Tool type P1</b>
<p>3. Tools with length compensation only</p> <p>Example:</p> <p><b>Drill</b></p>		10
<p>4. Tools with radius compensation and one length compensation</p> <p>Example:</p> <p><b>End mill</b></p>		20
<p>5. Tools with radius compensation and two length compensations</p> <p>Example:</p> <p><b>Angular milling cutter</b></p>		30


 corresponds to the reference point of the tool clamp (slide reference point).

**Diagram: Tool nose centre point positions**

With SINUMERIK 805 (lathe tools) the tool nose centre point "S" (Reference Point: "P") is entered in the "Tool type" input field under the identification "1". The input values "P1 = 1" to "P1 = 9" are available:


This diagram shows you which values you should select for ***machining behind the turning centre.***

P1=9 is valid when the tool nose centre point "S" is the reference point.



This diagram shows which values you should select for ***machining in front of the turning centre.***

P1=9 is valid when the tool nose centre point "S" is the reference point.



**Tool parameter P2: L1 Geometry**

**Tool parameter P3: L2 Geometry**

**Tool parameter P4: Diameter/radius**

Under tool parameters "2" and "3", you enter the geometry values of the tool in the input field.


Under tool parameter "4" you enter the value of the (tool nose) radius.

**Tool parameter P5: L1 Wear**


**Tool parameter P6: L2 Wear**

**Tool paramter P7: Diameter/radius**

Under tool parameters "5" and "7", you can enter the wear data of the tool in the input screen form (not obligatory).




*Geometry and wear data input can be inhibited with a key-operated switch. Please see the machine tool manufacturer's documentation!*




**Tool parameter P8: L1 Basic**

**Tool parameter P9: L2 Basic**

Tool parameters "8" and "9" are reserved for special uses. The "basic dimension" permits and additional tool length compensation.



*The standard TO parameters can be extended by means of machine data by P8 and P9. Please see the machine tool manufacturer's documentation!*




**Note:**

The input and editing of TO values is described in Section 4.5.

## 5.2.5 R parameters

SINUMERIK 805 recognises R parameters R0 to R999.



R parameter no.	Permanently assigned	Function
R0 : R49	As long as cycles are being processed	Standard cycle transfer parameters
R50 : R99	As long as cycles are being processed	Local R parameters Cycle calculations are carried out with these parameters.
R100 : R109	yes	Reserved for Siemens cycles
R110 : R199	yes	Reserved for measuring cycles. This area is user assignable if no measuring cycles are used.
R200 : R499	yes	These R parameters are used internally (e.g. when using CL800).
R500 : R699		Reserved for Siemens Nuremberg
R700 : R999		User assignable

Part programs can be created in a variety of ways with the help of the R parameters (see SINUMERIK 805 Programming Guide for detailed information).

## Sequence of operation

The SINUMERIK 805 machine area has been selected.



Use the OPERATING AREA key to select the SINUMERIK 805 data area.

DATA  
PARAMETER

The following display appears when you operate the DATA PARAMETER softkey:

R	Value	R	Value
R 0	0.0	R 15	220.5
R 1	0.0	R 16	35.0
R 2	27.0	R 17	60.0
R 3	0.0	R 18	6.0
R 4	3.0	R 19	3.0
R 5	60.0	R 20	2000.0
R 6	0.0	R 21	31.0
R 7	1000.0	R 22	0.5
R 8	1000.0	R 23	0.0
R 9	0.0	R 24	0.0
R 10	0.0	R 25	0.0
R 11	0.0	R 26	0.0
R 12	100.0	R 27	0.0
R 13	48.0	R 28	0.0
R 14	118.0	R 29	0.0

### Notes:


- Selecting, modifying and clearing R parameters and/or R parameter areas is described in Section 4.4.1.
- The calculator function can also be applied to R parameters.

## 5.2.6 Zero offset

The actual value memory, and therefore the actual value display, are referred to the machine zero point "**M**" after approaching the reference point.


The machining program for the workpiece is referred to the workpiece zero point "**W**".

Machine zero point "**M**" and workpiece zero point "**W**" are not identical. The dimensions between the machine zero point "**M**" and the workpiece zero point "**W**" can vary, depending upon the type and fixing of the workpiece. This **zero offset** is allowed for during program operation.



*Zero offset with a milling machine*

P	Tool setting point
M	Machine zero point
W	Workpiece zero point
R	Machine reference point
F	Slide reference point
WR	Workpiece reference point
XMR, YMR	Reference point coordinates
XMW, YMW	Zero offset



Zero offset with a turning machine

- |          |                             |
|----------|-----------------------------|
| P        | Tool setting point          |
| M        | Machine zero point          |
| W        | Workpiece zero point        |
| R        | Machine reference point     |
| F        | Slide reference point       |
| WR       | Workpiece reference point   |
| XMR, ZMR | Reference point coordinates |
| ZMW      | Zero offset                 |
| XFP      | Tool geometry L1            |
| ZFP      | Tool geometry L2            |


### 5.2.6.1 Selecting zero point offsets

#### Sequence of operation for selecting zero point offsets

**Prerequisite:** The SINUMERIK 805 machine area has been selected.



Use the OPERATING AREA key to select the data area.



The following display appears when you operate the ZERO OFFSET softkey:

		X	Y	Z					
JOG		SKP	DRY	ROV	DBL	DRF	M01	FST	%28
		RESET							
ZERO OFFSET									
		0.00000	0.00000	0.00000					
G54	ZERO OFFSET	0.00000	0.00000	0.00000					
	ZERO OFFSET FINE	0.00000	0.00000	0.00000					
G55	ZERO OFFSET	0.00000	0.00000	0.00000					
	ZERO OFFSET FINE	0.00000	0.00000	0.00000					
G56	ZERO OFFSET	0.00000	0.00000	0.00000					
	ZERO OFFSET FINE	0.00000	0.00000	0.00000					
G57	ZERO OFFSET	0.00000	0.00000	0.00000					
	ZERO OFFSET FINE	0.00000	0.00000	0.00000					
G58	ZERO OFFSET PROGR.	0.00000	0.00000	0.00000					
G59	ZERO OFFSET PROGR.	0.00000	0.00000	0.00000					
	ZERO OFFSET EXTERN	0.00000	0.00000	0.00000					
PROGRAM		DATA PARAMETER	TOOL OFFSET	ZERO OFFSET		DATA TRANSFER	DIAGNOSIS		

The zero offset affecting one axis is the sum of the following zero offsets:

- Settable zero offset (G54, G55, G56 or G57)
- Programmable zero offset (G58 and/or G59)
- External zero offset (ZERO OFFSET EXTERN)



### **Settable zero offset**

You can activate one of the 4 settable zero offsets in the called part program with G54 to G57. The value of the settable zero offset for each axis is the sum of:

- The coarse offset (ZERO OFFSET) and
- the fine offset (ZERO OFFSET FINE)

#### **Note:**

Input of the values for G54 to G57 is described in Section 4.5.

### **Programmable zero offset**

Using "G58" and "G59" you can program an additional zero offset for all existing axes in the called part program. Details of how to program these zero offsets are to be found in the Programming Guide (User Documentation for SINUMERIK 805).

The programmed zero offsets of a current program can be displayed on the screen by selecting ZERO OFFSETS.

#### **Note:**

The values of the ZERO OFFSETS programmed with G58 and/or G59 are cleared with program end (M02, M30).

### **External zero offset**

The values for the external zero offset (ZERO OFFSET EXTERN) are transferred from the interface control (PLC) to the NC.

These values can also be displayed on the screen by selecting ZERO OFFSETS.

## 5.2.7 Setting data

Using the setting data you can determine and/or activate

- the working area limitation of the individual axes
- the dry run
- the workpiece related actual value display system
- various spindle data

The setting data are entered by you in the SETTING DATA display.

### 5.2.7.1 Setting data selection

#### Sequence of operation for selecting setting data

**Prerequisite:** The SINUMERIK 805 machine area has been selected.



Use the OPERATING AREA key to select the data area.



Operate the DATA PARAMETER softkey.



The following display appears when you operate the SETTING DATA softkey:

<b>AUTOMATIC</b>	SKP	DRY	ROV	DBL	DRF	M01	FST	%28
RESET								
<b>SETTING DATA</b>								
<b>WORKING AREA</b>					<b>GENERAL DATA</b>			
		MIN.		MAX.	DRY RUN <span style="float: right;">0</span> WORKPIECE RELATED ACTUAL VALUE SYSTEM <span style="float: right;">[Pattern]</span>			
X		-99999999		99999999	<b>SPINDLE DATA</b>  SPEED LIMIT <span style="float: right;">[Pattern]</span> PROG. SPEED LIMIT (G92) <span style="float: right;">[Pattern]</span> EXACT SPINDLE STOP (M19) <span style="float: right;">[Pattern]</span> FEED ACCELERATION RAMP TIME FOR THREADS <span style="float: right;">[Pattern]</span>			
Y		-99999999		99999999				
Z		-99999999		99999999				
		0		0				
R PARAM		SETTING DATA	NC-MD VALUES		NC-MD BITS		PLC-MD	

Values within the following ranges can be entered in the input fields:

Designation	Standard value	Maximum input value	Input unit
<b>Working area limitation</b>			
Min. 1. axis	0	± 99999999	0.001 mm <sup>1)</sup>
Min. 1. axis	0	± 99999999	0.001 mm <sup>1)</sup>
Min. 2. axis	0	± 99999999	0.001 mm <sup>1)</sup>
Min. 2. axis	0	± 99999999	0.001 mm <sup>1)</sup>
Min. 3. axis	0	± 99999999	0.001 mm <sup>1)</sup>
Min. 3. axis	0	± 99999999	0.001 mm <sup>1)</sup>
Min. 4. axis	0	± 99999999	0.001 mm <sup>1)</sup>
Min. 4. axis	0	± 99999999	0.001 mm <sup>1)</sup>
<b>General data</b>			
Dry run	0	24000	m/min <sup>2)</sup>
<b>Spindle data</b>			
Speed limitation	0	12000	Rev/min <sup>3)</sup>
Programmed speed limit (G92)	0	12000	Rev/min <sup>3)</sup>
Oriented spindle stop (M 19)	0	359.9	1/10 degrees
Feed acc. ramp time for threads	0	5	–

- 1) The input unit is set in the machine data! It can be 0.0001 mm, 0.001 mm, or 0.01 mm.
- 2) The input unit is set in the machine data! It can be m/min or mm/min.
- 3) The input unit is set via machine data! It can be rev/min or 0.1 rev/min (please refer to the machine tool manufacturer's instructions).

### Workpiece related actual value system

When the workpiece related actual value system has been selected, the actual value display includes the selected zero offsets and tool offset.

The workpiece zero point is used as the zero point for the actual value display (See also Installation Instructions, Section 11.1).

#### Note:

The input of values and activation of the "workpiece related actual value system" is described in Section 4.4.2.

## 5.2.8 Program input

Any existing programs (e.g. on tape) can be read into the control via RS 232 C interfaces (see Section 6.2).

You can also enter a program using the keyboard.

### 5.2.8.1 Program input with the keyboard

#### Sequence of operation for selecting the PROGRAM menu

#### Prerequisite:


The SINUMERIK 805 machine area is selected.



Select the data area by means of the OPERATING AREA key.



The following display appears when you operate the PROGRAM softkey:




#### Notes:

- Program operation and program editing are described in Section 4.3 (softkey function PROGRAM).
- If the OPERATING AREA softkey is operated again the basic menu of the set operating mode in the machine area appears.

### 5.3 Operation

#### 5.3.1 Starting a part program



#### Sequence of operation


**Prerequisite:** The machine area has been selected.




Select the operating mode AUTOMATIC using the appropriate key.



Operate the SELECT PROGRAM softkey.  
 The following display incorporating an empty input field appears:





Now enter the desired program number using the numerical keys.



Use the INPUT key to close the input field and the window. The selected program (e.g % 50) is displayed in the operating mode field.



Operate the FEED START and

and



SPINDLE START keys.



You start the program with the NC start key.

**Notes:**

- NC start is not possible if FEED STOP is active.
- You can call up ACTUAL PROGRAM or ACTUAL BLOCK on the screen whilst the program is running (see Section 5.3.2).
- Programs can also be selected from the main program and subroutine directory (see Section 4.3.6).

### 5.3.2 Calling ACTUAL PROGRAM or ACTUAL BLOCK in AUTOMATIC mode


You can switch between the CURRENT PROGRAM and CURRENT BLOCK display using the softkey.

#### Sequence of operation


The ACTUAL PROGRAM display has been selected. You switch to the ACTUAL BLOCK display by operating the softkey.

<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%50
Stop: AUTO-Interruption					PROGRAM INTERRUPT				
<b>ACTUAL POSITION</b>			<b>REMAINING DIST.</b>			<b>FEED RATE</b>			
X	12.500	0.000	Command		0.000	100%			
Y	-2.500	0.000	Actual		0.000	[mm/min]			
Z	-10.236	0.000					<b>SPINDLE</b>		
		Command		0	%				
		Actual		0					
<b>ACTIVE PROGRAM</b>					<b>TOOL</b>		<b>AUX./MISC. FUNCTIONS</b>		
%50 N110 L200 P60 N10					D	M	10		
					T	H	16		
					<b>CURRENT G-FUNCTION</b>				
G01		G16		G10		G54			
G60		G71		G80		G90 G94			
G50									
OVERSTORE	PRESET	MODIFY PROGRAM	BLOCK SEARCH	ACTUAL BLOCK	SELECT PROGRAM				

**Explanation of ACTUAL PROGRAM display**



Selected program display (program pointer) and block number (processing pointer).



Display of subroutine number L..., the pass count P... as well as the block number within the subroutine (processing pointer) with three levels of nesting.

The display ACTUAL PROGRAM has been selected. The display is switched over by operating the ACTUAL BLOCK softkey.

The screenshot shows the following information:

- Mode:** AUTOMATIC
- Buttons:** SKP, DRY, ROV, DBL, DRF, M01, FST, %50
- Status:** Stop: AUTO-Interruption, PROGRAM INTERRUPT
- ACTUAL POSITION:**

X	12.500	0.000
Y	-2.500	0.000
Z	-10.236	0.000
- REMAINING DIST.:** (Values are 0.000 for X, Y, Z)
- FEEDRATE:**

Set	0.000	100%
Actual	0.000	[mm/min]
- SPINDLE:**

Set	0	%
Actual	0	
- ACTIVE BLOCK:**

%50 L200

(Subroutine no. 4 for %50)

N10 G01 X0 Y0 D1 G54 F24000

N20 M10 H16
- TOOL:**

D		M	10
T		H	16
- AUX/MISC. FUNCTIONS:**

G01	G16	G10	G54
G60	G71	G80	G90
G50			G94
- FUNCTION KEYS:** OVERSTORE, PRESET, MODIFY PROGRAM, BLOCK SEARCH, ACTUAL PROGRAM, SELECT PROGRAM



<b>Explanation of the ACTUAL BLOCK display</b>
--

% 50	L200		
------	------	--	--

(Subroutine no. 4 for % 611) LF

N10 610 X0 Y0 D1 654 F24000 LF

N20 M10 H16 LF

The main program or subroutine (3 levels of subroutine nesting possible) belonging to the actual block is displayed in the top line (program pointer).

The following blocks are displayed in the remaining part of the field (6 lines):

- The block **before** the actual block (program comments here)
- The ACTUAL BLOCK itself (Block N10 here)
- The block after the actual block (Block N20 here)

**Note:**

If lack of space does not permit display of all 3 blocks (block longer than 1 display line), the following are possible:

1. Display of:
  - block before actual block
  - actual block
  - block after actual block (only beginning)
2. Display of:
  - block before actual block
  - actual block
3. Display of:
  - actual block

### 5.3.3 Program interrupt

You can interrupt the program by operating the keys FEED HOLD or SPINDLE HOLD.

#### Operating sequence

##### FEED STOP



You operate the key FEED STOP.  
The feed drives are brought to a standstill following the programmed paths.



Field FST (FEED STOP) is displayed in reverse video.



Now operate the FEED START key. The feed drives are re-enabled. Program processing continues.

#### Notes:

FEED HOLD is also displayed when a traverse inhibit prevents the start, e.g.:

- when a control loop fails
- when a monitoring function is operated
- when the feedrate override is at the 0% and while enables apply

##### SPINDLE STOP



The spindle drive is disabled when the SPINDLE STOP key is operated.



Press the SPINDLE START key to re-enable the spindle drive.  
Program processing continues.

### 5.3.4 BLOCK SEARCH function

The BLOCK SEARCH function allows a program start at any point in the part program. During a block search the same calculations are carried out as during normal program operation, the axes, however, do not move.

**The output of the auxiliary functions during "Block search" is defined as required using machine data. Depending upon the setting made during installation, the H-, M-, S- and T- functions are output either completely or in part, or completely suppressed.**

A block search in a nest of routines is likewise possible. For this purpose, enter in the main program the number of the block in which the subroutine call is programmed. After this, enter the number, the number of passes and the block number of the subroutine.

#### Sequence of operation

**Prerequisites:**

The control is in the RESET state. The basic menu for the AUTOMATIC mode has been selected.




The following window is opened by operating the BLOCK SEARCH key:

Now enter the following data required for the search in the appropriate input fields as described in Section 2.4.4 (Entry in Input fields).

L: Subroutine number  
N: Block number  
P: Search number

**Example:**



You can close the BLOCK SEARCH window by operating the RECALL key. The function is not carried out.



Operate the START key. The program is processed up to the search destination without any axis movement. The BLOCK SEARCH window is closed.



Operate the NC-START key to recommence processing of the program from the search destination onwards.

**Note:**

After a BLOCK SEARCH, you can traverse the difference between the actual position and the calculated set position by means of the axis selection and the direction keys in the JOG-REPOS mode.



Using the HOME key you can select the input field for the block number of the main program in the BLOCK SEARCH window irrespective of the selected input field.

### 5.3.5 PROGRAM CONTROL function

You can select this function by means of softkey in the AUTOMATIC and MDA modes. The following program controls can be activated or deactivated:

- SKP Skip block
- DRY Dry run
- ROV Rapid traverse override
- DBL Decode single block
- DRF DRF offset
- M01 Programmed stop


#### Sequence of operation

**Prerequisite:**

You have selected the AUTOMATIC mode (i.e. MDA) in the machine area using the appropriate key.

PROGRAM  
CONTROL

Operate the softkey PROGRAM CONTROL to open the following window in the basic menu of the AUTOMATIC mode (i.e. MDA):



Use the cursor keys to move the white input field to the desired position.



Use the PLUS/MINUS keys to activate/deactivate the selected function. The input field indicates whether the function is active.

= function not active

= function active




After you have activated/deactivated the functions as required, close the window using the RECALL key.

#### Note:

The program control status display marks the program controls which have been activated (in the example given: RVO).

### Explanation of PROGRAM CONTROL basic menu



The status display is shown irrespective of the menu selected.

<b>Program control</b>	<b>SKP</b>	<b>skip block</b>
------------------------	------------	-------------------

Program blocks which are marked with an oblique in front of the block number, are ignored during the processing of the program (e.g. "/100...").

<b>Program control</b>	<b>DRY</b>	<b>dry run</b>
------------------------	------------	----------------

Traversing is carried out at the feedrate value entered in the "dry run feedrate" setting data.

The programmed feedrate in program blocks G01, G02, G03, G33, G34 and G35 is no longer valid.

The dry run feedrate also applies instead of the programmed feed per revolution in program blocks with G95.

<b>Program control</b>	<b>ROV</b>	<b>rapid traverse override</b>
------------------------	------------	--------------------------------

There are two possible ways of applying this function:

- a) There is a common override switch for the feedrate and rapid traverse override.

ROV  : The value of the feedrate override switch with an override value limit of 100 % is valid for the rapid traverse override.

ROV  : Rapid traverse override is not possible.  
 The override value of 100 % is stipulated.

- b) There is a separate override switch for the rapid traverse override.

ROV  : The values set with the rapid traverse override switch are active.

ROV  : The values set with the rapid traverse override switch are not active. The override value of 100 % is stipulated.

**Example:**

During installation of a new part program, the override switch also affects the traversing blocks with programmed rapid traverse (G00) when a function is activated.

<b>Program control</b>	<b>DBL</b>	<b>decode single block</b>
------------------------	------------	----------------------------

When the function is activated, the part program blocks are processed individually as follows:



Operate the NC-START key to process a decoding single block.



Operating the NC-START key again processes the next program block ...etc.

**Notes:**

- The SINGLE BLOCK function operates similarly.



Operate the SINGLE BLOCK key to activate the function.

SINGLE BLOCK SELECTED appears on the screen.



After the NC-START key has been operated, the program block is processed.



Operate the NC-START key again to process the next program block ...etc.



You deselect the function by operating the SINGLE BLOCK key again.



The following table indicates for which blocks the "Decoding single block active" signal or the "Single block active" signal must be present if a program is to be processed on a block-by-block basis.

Block Type	Single block	Decoding single block
Traversing blocks	X	X
Blocks without path information	X	X
Calculation blocks		X
Switching and auxiliary function blocks	X	X
Internally generated control blocks (CRC...)**)	X	X
Threading blocks without dry run feedrate	*)	
Threading blocks with dry run feedrate	X	X

X "Single block" or "Decoding single block" signal is required.

\*) Single block: The stop is made at the end of the first non-threading block

\*\*)) with cutter radius/tool nose radius compensation

- Blocks which have been "pre-processed" in the buffer memory without the "Decoding single block" signal present but which have not yet been processed cannot be stopped.
- A "Decoding single block" can be influenced using "OVERSTORE" (Cap. 5.3.12).

Program control	DRF	DRF offset
-----------------	-----	------------

Using the "DRF" function (Differential Resolver Function) it is possible to set an additional, incremental zero offset using the handwheel.

This offset is not taken into account in the actual value display.

**Notes:**

- The active zero offset for each axis is only shown in the opened PROGRAM CONTROL window.
- The DRF offset for an axis cannot be deleted. The offset must be "moved back".
- The handwheel incremental dimension is defined as 1.
- See Section 5.3.7, DRF Function, for further information.

<b>Program control</b>	<b>M01</b>	<b>Programmed stop</b>
------------------------	------------	------------------------


When this function is activated, the program is stopped at those blocks in which the additional function M01 is programmed.

STOP: PROGR.STOP M00/M01 is then displayed on the screen.

Processing of the program is restarted using the NC-START key. If the function is not active, the additional function M01 is not taken into consideration.

### 5.3.6 Program control in AUTOMATIC mode

Any program controls activated in the AUTOMATIC mode i.e. as a result of programmed or selected functions, are displayed in the **shaded display field**.



The following displays are possible:



A current program has been interrupted with the NC-STOP key. You can restart the program at the point of interruption using the NC-START key.



This display appears after the processing of each single block in the SINGLE BLOCK function.



An interruption has been programmed with M00 (progr. interruption unconditional) or M01 (progr. interruption conditional) in a part program. This display appears when the block is processed with M00 or, if the program control PROGRAMMED STOP has been activated, with M01. Processing of the program is recommenced by operating the NC-START key.



This display appears during the processing of an NC block with programmed dwell time.

**Stop: Read-in enable**

The interface signal READ-IN ENABLE has been removed. The current NC block is still being processed. Processing of the program with the next block is continued by setting the READ-IN ENABLE signal.

### 5.3.7 DRF function

The DRF function (Differential Resolver Function) makes an additional incremental zero offset using the handwheel possible.


This zero offset is not taken into account in the actual value display.

#### Sequence of operation

**Prerequisites:** The MDA or AUTOMATIC mode basic menu has been selected.

PROGRAM CONTROL

Operate the PROGRAM CONTROL softkey to open the following window:




Now activate the DRF function as described in Section 5.3.5 (Program control).



Now select the axis to which the DRF offset is to be applied (e.g X axis).



Activate the HANDWHEEL function by operating the appropriate key on the handwheel.



Now turn the handwheel in the positive or negative direction according to the desired offset. The DRF offset value is displayed in the opened PROGRAM CONTROL window (X axis in the example).

The same procedure as above applies when altering the other axes.

**Notes:**

- The handwheel incremental dimension in the DRF function is always 1.
- It is not possible to delete the DRF offset of an axis. The axis must be "returned" by the amount of the offset.

### 5.3.8 Traversing in the JOG mode

In this mode, operation is carried out manually. You traverse the axes using the direction keys or using the handwheel.

#### a) Traversing in JOG mode using the direction keys

##### Sequence of operation




To select the JOG mode operate the appropriate key on the operator keyboard or on the hand-held unit.



Now select the axis to be traversed by operating the appropriate selection key (e.g. X axis) on the handheld unit.



Use the JOG PLUS and/or MINUS keys to traverse the selected axis in the required direction.




The traversing speed can be modified using the feedrate override switch. The "0%" setting generally causes FEED STOP in the case of feed and rapid traverse.



The axis is traversed at rapid traverse rate by operating the JOG PLUS or MINUS key together with the RAPID TRAVERSE OVERRIDE key.

**Notes:**


- FEED STOP (FST) must not be on.
- The spindle speed as well as the T, H and M functions are determined by means of the OVERSTORE function.



***The feed and rapid traverse speed is defined in the machine data.***



***The feedrate override switch can also be active for rapid traverse in the 0% to 100% range!***

***(See machine tool manufacturer's documentation)***



**b) Traversing in JOG mode using the handwheel**

## Sequence of operation

When the HANDWHEEL is active, the control traverses the selected axis by the increment selected in INCREMENTAL DIMENSION using the  and  keys (values 1, 10, 100) when 1 impulse is set by the handwheel.





Select the JOG mode using the appropriate key on the operator keyboard or using the hand-held unit.



Use the axis selection keys to specify the axis which is to be traversed (e.g. Z axis).



Activate the HANDWHEEL function by operating the appropriate key on the hand-held unit. The corresponding LED lights up.



Turn the handwheel according to the desired traverse direction.  
 When 1 impulse has been set by the handwheel, the control traverses the selected axis by the increment entered in the INCREMENTAL DIMENSION HANDWHEEL entry field.

**Notes:**

- The values 1, 10 or 100 can be entered in the INCREMENTAL DIMENSION HANDWHEEL input field.
- Operating the HANDWHEEL key again deselects the function. The corresponding LED goes out.

### 5.3.9 Traversing in the JOG-INC mode


In this mode, operation is carried out manually via the control. With each operation of a direction key, you traverse the axis concerned in the selected direction by the set increment. In this mode, traversing can also be carried out using the handwheel.

#### a) Traversing in the JOG-INC mode using the direction keys

Sequence of operation



To select the INC mode operate the appropriate keys on the operator keyboard or on the hand-held unit.



Now operate the JOG-INC softkey.



Using the axis selection keys, specify the axis to be traversed.



Now enter the desired increment (between 1 and 10000) in the JOG-IN INCREMENTAL DIMENSION input field, as described in Section 2.4.4 (Entry in input fields).



By operating the increment/decrement key you can switch through the increment amount in the JOG-INC field in the INCREMENTAL DIMENSION window.

Possible values: 1, 10, 1000, 10000



Operate a direction key to traverse the selected axis by the increment set by you.




#### Note:

The direction keys can have two different characteristics:

- **"Self retentive (modal)"**
- **"JOG operation"**


With **"self retentive"** the axis is always traversed by one increment, depending on the setting, when the key is pressed (irrespective of whether the key is pressed for a short or long time).

In **"Jog operation"** the axis is traversed for as long as the key remains pressed. When the key is no longer being pressed, the traversing movement is stopped - even if the set increment has not yet been reached.



**b) Traversing in the JOG-INC mode using the handwheel**


To select the JOG mode use the appropriate key on the operator keyboard or on the hand-held unit.



Now operate the JOG-INC softkey.


**Sequence of operation****Notes:**

- The continued sequence of operation is described in Section 5.3.8 (Traversing in the JOG mode with the handwheel), in b).
- FEEDRATE STOP must not be on.
- Values between 0 and 10 000 can be entered in the input field for JOG-INC incremental dimension.
- The spindle speed as well as the T, H and M functions are specified using the OVERSTORE function.



***The feedrate is defined as machine data!  
The machine data also defines whether JOG-IN is  
traversed in "self retentive" or "jog operation" mode!***

***(See machine tool manufacturer's documentation.)***




### 5.3.10 Traversing in JOG-REPOS mode

After a program interruption - e.g. after switching from AUTOMATIC operation to JOG or INCREMENTAL DIMENSION, you can traverse away from the contour.

AUTOMATIC operation is not aborted, i.e. the control is not brought to the reset state by a self-generated RESET.

A RESET is not generated when switching from AUTOMATIC mode to:


- JOG or to
- JOG-INC or to
- JOG-REPOS.



When traversing away from the contour, the distance moved is registered by the control. The distance to the interruption point is stored and displayed as the "REPOS offset".

In "Repositioning" JOG-REPOS mode, you can now approach to the interruption point using the direction keys along any path.

The direction key for the opposite direction is inhibited, and overtravel past the start position is not possible.



Otherwise you should use:

- the "block search" method (s. Section 5.3.4).
- the "scratch" method (s. Section 5.3.16).

## Sequence of operation

**Prerequisite:** You have interrupted the program - e.g. by operating the NC-STOP key - and subsequently have traversed away from the contour in the JOG mode.



JOG-REPOS

Operate the JOG-REPOS softkey (selects the JOG-REPOS mode).



X

Select the axis which is to be traversed to the point of interruption.



+

or



-

Operate the direction key to traverse to the point of interruption. Overtravel past the point of interruption is inhibited by the NC. The feedrate override switch is active, the rapid traverse override is inactive.


### Note:

The direction keys can have two different characteristics:


- "Self retentive" (modal)
- "Jog operation"

With "Self retentive" the axis is always traversed by one increment, depending on the setting (1, 10, 100, 1000, 10000  $\mu\text{m}$ ), when the key is pressed (irrespective of whether the key is pressed for a short or long time).

In "Jog operation" the axis is traversed for as long as the key remains pressed. When the key is no longer being pressed, the traversing movement is stopped - even if the set increment has not been reached.



*Machine data defines whether  
"Incremental" is traversed in "self retentive"  
of "jog operation" mode.*



Once all axes have been traversed to the point of interruption, select the AUTOMATIC mode. Operate the NC-START key to continue the program.

### 5.3.11 MDA mode

Single NC blocks can be entered and processed in this mode. After processing the single block is deleted.

#### Sequence of operation

**Prerequisite:** The SINUMERIK 805 machine area has been selected.



Operate this key to select MDA mode. the following display appears:

<b>MDA</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%28
<b>RESET</b>									
<b>ACTUAL POSITION</b>		<b>REMAINING DIST.</b>		<b>FEEDRATE</b>					
X	0.000	0.000	Command 0		100%				
Y	0.000	0.000	Actual 0		[mm/min]				
Z	0.000	0.000	<b>SPINDLE</b>						
				Command 0		100%			
				Actual 0					
<b>MDA block</b>					<b>TOOL</b> <b>AUX/MISC. FUNCTIONS</b>				
 L <sub>F</sub> ==eof==					D    M				
					T    H				
					<b>CURRENT G FUNCTION</b>				
<b>OVERSTORE</b>		<b>PRESET</b>		<b>PROGRAM CONTROL</b>					



...



...



...

Using the keyboard enter the block according to the instructions in the Programming Guide and terminate each entry using the input key.



After operating the NC-START key the entered block is processed by the control and subsequently deleted.

**Note:**

You can process several blocks one after the other. The "retentive input data" (e.g. feedrate) are retained.

They are deleted or reset by:


- changing the operating mode or
- RESET

### 5.3.11.1 OPERATOR PROMPTING in MDA mode



In MDA mode you can call a subroutine in a block. If this subroutine is fitted out with operator prompting (see Programming Guide Section 12), this function supports a comfortable parameter assignment.


#### a) Manual subroutine selection



**Prerequisite::** MDA mode has been selected.



Operation of OPERATOR PROMPTING softkey opens a window listing all subroutines fitted out with operator prompting.





Exist more than 6 subroutines with operator prompting they can be displayed by operating PAGE UP/ DOWN softkeys.



Using the cursor keys you can select the desired subroutine in the overview display (inverse displayed = selected).

## b) Subroutine selection using the SEARCH softkey

Sequence of operation

### Prerequisite:


MDA mode has been selected.

OPERATOR  
PROMPTING

Operating of OPERATOR PROMPTING softkey opens a window listing all subroutines fitted out with operator prompting.

SEARCH

Press the SEARCH softkey and the following window appears:








Key in the desired subroutine number in the opened entry field.




Operation of INPUT key closes entry field and window.  
 Now the wanted subroutine is selected (inverse displayed).

**Parameter assignment for the selected subroutine**


**Prerequisite:** The desired subroutine has been selected.




Operation of PARAMETER softkey opens another window listing all subroutines fitted out with operator prompting.



Use cursor keys for R parameter selection.



Now enter the parameters after description in Section 2.4.4 (Entries in Input fields).



Exist more than 7 parameters for the subroutine they can be displayed by operating PAGE UP/DOWN softkeys.



After operating the ACCEPT DATA softkey the part program accepts the entered R parameter assignments.  
After all R parameter assignments the subroutine call automatically is entered.  
The PARAMETER and DIRECTORY windows are closed.

**Note:**

In case of repeated successive subroutine calls in MDA mode the assignment of all parameters is only necessary at the first call.

At later subroutine calls key in the parameters only if their values have changed.

### 5.3.12 OVERSTORE function

In modes JOG, MDA and AUTOMATIC, you can modify one or more values of the following functions in the buffer memory:


- Auxiliary function           H
- Miscellaneous function    M
- Spindle speed               S
- Tool number                 T

Sequence of operation for entering values

- Prerequisites:**
- The basic menu of the above mentioned modes is selected.
  - To OVERSTORE, the program must be stopped using the NC-STOP key.

OVERSTORE

The following window is opened when you operate the OVERSTORE softkey:



The active functions are entered in the fields on the left. In the fields on the right enter the required values as described in Section 2.4.4 (Entry in input fields).




When the NC-START key is operated, the entered values become active and the input fields are deleted. The active values can be modified using the OVERSTORE function.



Operate the RECALL key to close the window.

### Sequence of operation for deleting an entered value



Use the cursor keys to select the field of which the contents are to be deleted.



Operate the CLEAR key.  
The entered value is deleted.


#### Notes:

- You can close the window with the RECALL key before operating the NC-START key. The OVERSTORE function is then not executed.
- In AUTOMATIC mode the program is now continued by operating the NC-START button with the new values.

### 5.3.13 PRESET function (set actual value)

In the basic menu of modes, JOG, MDA and AUTOMATIC, you can select the PRESET function with the appropriate softkey.


- In the "PRESET" operating mode, you can offset the control zero point to any point within the machine coordinate system.  
You enter the value for the offset in the actual value memory (preset). The actual value memory for all available axes can be preset. This preset results in a "PRESET offset" which is displayed on the screen.
- **No movement** of the axes takes place with "Set actual value". A new value is simply entered for the current axis positions.
- The "PRESET offset" remains stored:
  - after end of program
  - after RESET



***Machine data defines whether the PRESET offset is automatically deleted:***

- *on switching on the control*
- *on approaching reference point*

***(see machine tool manufacturer's documentation)***




## Sequence of operation when entering a PRESET value

### Prerequisite:

One of the following modes has been selected in the machine area: JOG, MDA, AUTOMATIC. The control is in the RESET state.



Operate the PRESET key  
to open the following window:



Now enter for each of the axes as described in Section 2.4.4 (Entry in input fields) the actual value which is to correspond to the present axis position in the future




After operating the RECALL button the window is closed and the actual value in the display altered to the new value.

## Sequence of operation when entering a PRESET value


**Prerequisite:** One of the following modes has been selected in the machine area: JOG, MDA, AUTOMATIC. The control is in the RESET state.



Operate the PRESET key to open the following window:



Using the cursor keys select the axis for which the PRESET value is to be deleted.



Now operate the CLEAR softkey. The PRESET OFFSET value is now deleted.



After operating the RECALL key the actual value display again refers to the machine coordinate system.

### 5.3.14 OVERRIDE BLOCK function

If the control recognizes a programming fault during program run the operation is stopped and a corresponding alarm displayed.

Additionally, the softkey line and the OVERRIDE BLOCK softkey are enlarged.

<b>AUTOMATIC</b>		SKP	DRY	ROV	DDL	DRF	M01	FST	%50
Stop: AUTO-Interruption					PROGRAM INTERRUPT				
3011 one axis double or too many axes programmed									
<b>ACTUAL POSITION</b>			<b>REMAINING DIST.</b>			<b>FEEDRATE</b>			
X	0.000	0.000	Command		0.000	100%			
Y	0.000	0.000	Actual		0.000	[mm/min]			
Z	0.000	0.000	<b>SPINDLE</b>						
		Command		0	100%				
		Actual		0					
<b>ACTUAL PROGRAM</b>					<b>TOOL</b>   <b>AUX./MISC. FUNCTIONS</b>				
%50 N20 1 → 2 → 3 →					D T M H				
<b>CURRENT G FUNCTION</b>									
OVERSTORE   PRESET   PROGRAM CONTROL   BLOCK SEARCH   ACTUAL BLOCK   SELECT PROGRAM <b>OVERRIDE</b>									





Operating the NC stop softkey interrupts the program.



Pressing the OVERRIDE BLOCK softkey opens a window where the cursor position is in the faulty program block.

Now you can change the faulty program block according to Section 4.3.1 "Program editing".





After correction of the faulty block the QUIT softkey **must** be operated to delete the current alarm.




Operating NC START softkey closes the window and continues the program run with the corrected program part.

### 5.3.15 SPEED OVERLAY VIA HANDWHEEL PULSES function



This function generates a speed overlay for an individual programmed axis in a block in AUTOMATIC and MDA mode.

Turning the handwheel in the positive or negative direction increases the programmed speed of the NC axis. The higher the handwheel speed resp. the incremental dimension of the handwheel are (Section 3.2.2) the higher is the speed overlay.



#### Sequence of operation

##### Prerequisite:


One individual NC axis has been programmed in the actual block.



Operate the axis selection key also programmed in the actual block (in this case X axis).



Operating the handwheel key activates the handwheel.



Turning the handwheel can preset a special speed overlay for the programmed axis.

### 5.3.16 Scratch

If a tool breaks during program processing, you must leave the contour by changing to the "JOG" or "JOG INC" operating mode in order to change the tool.

After entry of the new tool length compensation (the tool nose radius remains unchanged) you traverse the new tool to any point on the contour within the interrupted block ("Scratch").

#### Sequence of operation

##### Prerequisite:

A tool change has been carried out and the appropriate correction data entered.

Using the direction keys, now traverse to any point within the interrupted block.  
The axes can be traversed in the JOG or JOG-INC mode:


- using the direction keys
- using the handwheel




Select the AUTOMATIC mode using the appropriate key on the operator keyboard or the hand-held unit.



Resume program processing by operating the NC-START key on the hand-held unit.



***In a block with circular interpolation (G02, G03) scratch must take place within a very narrow range. This range is fixed with machine data. (Standard definition via MD "9"; see also the machine tool manufacturer's documentation.)***  
***If the range is exceeded: alarm 3018 !***




## 6 Data Interfaces

### 6.1 General

Two interfaces are available for data transfer with the SINUMERIK 805.

- Interface 1 (RS 232 C/20mA) is variable with regard to the possibilities for connecting different devices.
- Interface 2 (RS 232 C) is normally set aside for the connection of a particular device.



#### Notes:

- Interface 2 can also be operated with an RS 422 adaptor.
- The interface parameters (interface characteristics) for interfaces 1 and 2 can be set in the PARAMETER menu (See Section 4.8).

The following data types can be read-in/read-out via RS 232 C interfaces:

Data type	Meaning
CLF	Delete statement ( <b>C</b> lear <b>F</b> ile), during read-in
MPF	Part program ( <b>M</b> ain <b>P</b> rogram <b>F</b> ile)
RPA	R parameter with value assignment ( <b>R</b> -Parameter <b>A</b> ctive)
SEA	Addresses with value assignments ( <b>S</b> etting <b>D</b> ata <b>A</b> ctive)
SPF	Subroutine ( <b>S</b> ub <b>P</b> rogram <b>F</b> ile)
TEA 1	NC machine data ( <b>T</b> esting <b>D</b> ata <b>A</b> ctive)
TEA 2	PLC machine data ( <b>T</b> esting <b>D</b> ata <b>A</b> ctive)
TOA	Tool offsets ( <b>T</b> ool <b>O</b> ffset <b>A</b> ctive)
ZOA	Zero point offset ( <b>Z</b> ero <b>O</b> ffset <b>A</b> ctive)

## 6.2 Data read-in via RS 232 C interface

### Sequence of operation



**Prerequisite:** The SINUMERIK 805 machine area has been selected.




Select the SINUMERIK 805 machine area using the OPERATING AREA key.



Operate the DATA TRANSFER softkey. The following screen display appears:



Select the desired interface by operating the appropriate softkey.



## Sequence of operation when setting interface parameters

**Prerequisite:** The basic menu DATA TRANSFER has been selected.

PARAMETER


Operate the PARAMETER softkey to set or control the interface parameters. The following display appears:

<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%50
					RESET				
<b>INTERFACE PARAMETRIZATION 1</b>									
<b>PARAMETER</b>					<b>SPECIAL FUNCTION:</b>				
TERMINAL TYPE		RTS-LINE		<input checked="" type="checkbox"/>	START USING Xon				
BAUD RATE		9600		<input type="checkbox"/>	PROGRAM START USING LF				
STOP BITS		2		<input checked="" type="checkbox"/>	END OF BLOCK USING CR LFF				
PARITY		NONE		<input checked="" type="checkbox"/>	DATA OUTPUT IN EIA-CODE				
Xon (HEX)		00		<input type="checkbox"/>	STOP USING END OF TEXT (ETX)				
Xoff (HEX)		00		<input checked="" type="checkbox"/>	EVALUATE DSR-SIGNAL				
EIA-CODE FOR @ (HEX)		00		<input checked="" type="checkbox"/>	HEADER AND END				
EIA-CODE FOR : (HEX)		00		<input type="checkbox"/>	PROGRAM FROM SYSTEM 3/8				
EIA-CODE FOR = (HEX)		00		<input checked="" type="checkbox"/>	REORGANISATION USING INTERFACE				
END OF TEXT (ETX) (HEX)		03		<input checked="" type="checkbox"/>	TIME MONITORING				
DEVICE TYPE	BAUD RATE	STOP BITS	PARITY	2nd RS232					

Each time one of the four softkeys is operated, the corresponding setting is changed. The following settings are possible:



Device type: PLC-PROG, RTS-LINE, Xon/Xoff, PTR und PD/PF



Baud rate: 110, 150, 300, 600, 1200, 2400, 4800 and 9600



Stop bits: 1/1, 5/2



Parity: none, odd, even



To input characters for Xon, Xoff, EIA code for @, : and = as well as for transfer end, select the corresponding input field using the cursor keys.



Now enter the desired value as described in Section 2.4.4 (Entry in input fields).



To alter any of the special functions, select the appropriate input field using the cursor keys.



The special function is activated/deactivated each time the PLUS/MINUS key is operated. The input field indicates whether the function is active or not.



≙ not active



≙ active



Operate this key to return to the DATA TRANSFER basic menu.




When this key has been operated, the control is ready to receive. The display "data transfer active" appears on the screen.

The data type sent by the transmitter (tape reader, programming unit) is characterized by its initial code.

The data type is displayed (e.g. TOA) during read-in.



Data input can be interrupted at any time using the STOP softkey. READ-IN start is continued when the softkey is operated again.



#### Notes:

In the case of tape input, the data input is checked for simple errors. All characters in a tape code have a common identifier.

- The number of punched holes in an ISO code is always even.
- The number of punched holes in an EIA code is always odd.

The control automatically recognizes the correct code as soon as the first "%" (ISO) or "EOR" (EIA) has been read!

The criterion "number of punched holes even" or "number of punched holes odd" is used for a character parity check as from the second character.

As a further check, a program being read-in which is already contained in the program memory is compared thoroughly with its counterpart.

If an error is detected, the read-in process is halted and the error displayed on the screen.




### 6.3 Data read-out via RS 232 C interface

#### Operating sequence


**Prerequisite:** The SINUMERIK 805 machine area has been selected.




Use the OPERATING AREA key to select the SINUMERIK 805 data area.



The following display appears when you operate the DATA TRANSFER softkey:



Select the desired interface by operating the appropriate softkey.



PARAMETER

Operate the PARAMETER softkey to set or control the interface parameters. The following display appears:

<b>AUTOMATIC</b>		SKP	DRY	ROV	DBL	DRF	M01	FST	%50
					RESET				
<b>INTERFACE PARAMETRIZATION 1</b>									
<b>PARAMETER</b>					<b>SPECIAL FUNCTION:</b>				
TERMINAL TYPE		RTS-LINE		<input checked="" type="checkbox"/>		START USING Xon			
BAUD RATE		9600		<input type="checkbox"/>		PROGRAM START USING LF			
STOP BITS		2		<input checked="" type="checkbox"/>		END OF BLOCK USING CR LFF			
PARITY		NONE		<input checked="" type="checkbox"/>		DATA OUTPUT IN EIA-CODE			
Xon (HEX)		00		<input type="checkbox"/>		STOP USING END OF TEXT (ETX)			
Xoff (HEX)		00		<input checked="" type="checkbox"/>		EVALUATE DSR-SIGNAL			
EIA-CODE FOR @ (HEX)		00		<input checked="" type="checkbox"/>		HEADER AND END			
EIA-CODE FOR : (HEX)		00		<input type="checkbox"/>		PROGRAM FROM SYSTEM 3/8			
EIA-CODE FOR = (HEX)		00		<input checked="" type="checkbox"/>		REORGANISATION USING INTERFACE			
END OF TEXT (ETX) (HEX)		03		<input checked="" type="checkbox"/>		TIME MONITORING			
DEVICE TYPE		BAUD RATE		STOP BITS		PARITY		2nd RS232	

**Notes:**


- The setting of interface parameters for various peripheral devices is described in Section 6.5.
- The input and modification of interface parameters is described in Section 6.2, "Data read-in via RS 232 C interface".



After you have entered the interface parameters, operate this key to return to the DATA TRANSFER basic menu.

READ-OUT

The following display appears when you operate the READ-OUT softkey.



You can use the cursor keys to select the data type which is to be read out.



In the case of MAIN PROGRAMS, SUBROUTINES, TOOL OFFSETS and R PARAMETERS you can enter the area which is to be transferred. Enter the desired values in the appropriate input fields as described in Section 2.4.4 (Entry in input fields).

READ-OUT START

Operate the READ-OUT START softkey to initiate data output. The data being read out is displayed on the screen.

**Note:**

Use the STOP softkey to halt data output at any time and the READ-OUT START softkey to continue.


## 6.4 PLC program read-in/read-out

### Sequence of operation



**Prerequisite:** The SINUMERIK 805 machine area is selected.



Use the OPERATING AREA softkey to select the SINUMERIK 805 data area.



The following display appears when you operate the DATA TRANSFER softkey:



PARAMETER

Operate the PARAMETER softkey to set or control the interface parameters. The following display appears:

<b>AUTOMATIC</b>	SKP	DRY	ROV	DBL	DRF	M01	FST	%50									
RESET																	
<b>INTERFACE PARAMETRIZATION</b>																	
<b>PARAMETER</b>				<b>SPECIAL FUNCTIONS</b>													
TERMINAL TYPE		RTS-LINE		<input checked="" type="checkbox"/>	START USING Xon												
BAUD RATE		9600		<input type="checkbox"/>	PROGRAM START USING LF												
STOP BITS		2		<input checked="" type="checkbox"/>	END OF BLOCK USING CR LFF												
PARITY		NONE		<input checked="" type="checkbox"/>	DATA OUTPUT IN EIA-CODE												
Xon	(HEX)	00		<input type="checkbox"/>	STOP USING END OF TEXT (ETX)												
Xoff	(HEX)	00		<input checked="" type="checkbox"/>	EVALUATE DSR-SIGNAL												
EIA-CODE FOR @	(HEX)	00		<input checked="" type="checkbox"/>	HEADER AND END												
EIA-CODE FOR :	(HEX)	00		<input type="checkbox"/>	PROGRAM FROM SYSTEM 3/8												
EIA-CODE FOR =	(HEX)	00		<input checked="" type="checkbox"/>	REORGANISATION USING INTERFACE												
END OF TEXT (ETX)	(HEX)	00		<input checked="" type="checkbox"/>	TIME MONITORING												
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center;">DEVICE TYPE</td> <td style="text-align: center;">BAUD RATE</td> <td style="text-align: center;">STOP BITS</td> <td style="text-align: center;">PARITY</td> <td style="text-align: center;">2nd RS232</td> <td></td> <td></td> <td></td> <td></td> </tr> </table>									DEVICE TYPE	BAUD RATE	STOP BITS	PARITY	2nd RS232				
DEVICE TYPE	BAUD RATE	STOP BITS	PARITY	2nd RS232													

The following settings can be selected using softkeys:

DEVICE  
TYPE

Device type: PLC-PROG

BAUD RATE

Baud rate: 9600

STOP BITS

Stop bits: 2

PARITY

Parity: none



After entering the interface parameters, operate the return key to return to the DATA TRANSFER basic menu.

READ-IN  
START

Operate the READ-IN START key. The message "data transfer active" appears on the screen.

The interface is activated for PLC operation.

## 6.5 Interface parameters for various peripheral devices

For the purposes of data transfer between the SINUMERIK 805 and a peripheral device, the selected SINUMERIK 805 interface must be adapted to the device. This is done by altering the interface parameters in the PARAMETER menu as described in Section 4.7. The table below shows the interface parameters to be set for each of the peripheral devices:

Parameters	Siemens programmer unit PG 750/685/675 20 mA Interface AG S5	Siemens programmer unit PG 750/685/675 RS 232 C Interface printer	Siemens programmer unit PG 615 U 20 mA	Siemens page printer PT 80 RS 232 C/20 mA	Siemens page printer PT 88 RS 232 C
TERMINAL TYPE	PLC-PROG	RTS-LINE	PLC-PROG.	RTS-LINE	RTS-LINE
BAUD RATE	9600	9600	9600	300	9600
DATA BITS	8	8	8	8	8
STOP BITS	2	2	2	2	2
PARITY	NONE	NONE	NONE	NONE	NONE
X <sub>ON</sub>					
X <sub>OFF</sub>					
EIA-Code for:					
EIA-Code for:					
EIA-Code for:					
EIA-Code for end of text		03		03	03
Start with X <sub>ON</sub>					
Program start using LF					
End of block using CRLF		X		X	X
Data output in EIA code					
Stop using end of text		X		X	X
Evaluate DSR signal					
Header and end		X		X	X
Program from system 3/8					
REORG using interface		X		X	X
Time monitoring		X		X	X

X = Parameter is active

## 6.5 Interface parameters for various peripheral devices

Parameters	Per device	Siemens programming workstation PD..., PG RS 232 C	SINUMERIK System 800 NC-NC coupling RS 232 C	SINUMERIK reader, T 40, T 50, T 60/RS 232 C	SINUMERIK WS 800 RS 232 C	Teletype ASR 33 full duplex	Sanyo cassette M2502V-ZE-601 RS 232 C
TERMINAL TYPE		PD/PF	RTS-LINE	RTS-LINE	RTS-LINE	RTS-LINE	RTS-LINE
BAUD RATE		4800	9600	9600	9600	110	1200
DATA BITS		8	8	8	8	8	8
STOP BITS		2	2	2	2	2	1
PARITY		NONE	NONE	NONE	NONE	NONE	NONE
X <sub>ON</sub>		11					
X <sub>OFF</sub>		93					
EIA-Code for:							
EIA-Code for:							
EIA-Code for:							
EIA-Code for end of text							
Start with X <sub>ON</sub>							
Program start using LF							
End of block using CRLF			X				
Data output in EIA code							
Stop using end of text							
Evaluate DSR signal							
Header and end							
Program from system 318							
REORG using interface							
Time monitoring							

X = Parameter is active



## 6.5 Interface parameters for various peripheral devices

Per device Parameters	Facit 4040, 4042 Reader/punch RS 232 C	Facit 4030 Reader RS 232 C	Sommer terminal MDE-3 SNC Cassette unit RS 232 C
TERMINAL TYPE	RTS-LINE	RTS-LINE	RTS-LINE
BAUD RATE	1200	1200	9600
DATA BITS	8	8	8
STOP BITS	2	2	2
PARITY	NONE	NONE	NONE
X <sub>ON</sub>			
X <sub>OFF</sub>			
EIA-Code for:			
EIA-Code for:			
EIA-Code for:			
EIA-Code for end of text			
Start with X <sub>ON</sub>			
Program start using LF			
End of block using CRLF			
Data output in EIA code			
Stop using end of text			
Evaluate DSR signal			
Header and end			
Program from system 318			
REORG using interface			
Time monitoring			

X = Parameter is active

## 6.6 Setting data for defining interfaces

Interfaces 1 and 2 are defined using setting data.

An alteration of interface parameters for interface 1 or 2 in the PARAMETER menu corresponds to an alteration in the following setting data areas:

SD area:	Interface
SD no. 5010 to 5017	1
SD no. 5018 to 5025	2
SD no. 5026 to 5029	1 and 2

The setting data of both interfaces can be changed by reading in data using the data type SEA (see Section 5.2.12.1). The alteration only becomes active once the interfaces are started and is shown in the PARAMETER menu in plain text.

The tables below show the allocation of interface parameters to setting data bits as well as the setting data bits for the connection of peripheral devices.

Only those setting data numbers (SD no.) which are decisive for the connection of the device concerned to interface 1 or 2 are listed.

**Note:**

The setting data areas listed above are not displayed in a table on the screen, but are contained in the data read-out (see Section 5.2.12.2).

## 6.6 Setting data for defining interfaces

SD no.		Setting data function							
Inter- face 1	Inter- face 2								
5010	5018	Device encoding input							
5011	5019	Transfer format input							
		Bit no. 7	Bit no. 6	Bit no. 5	Bit no. 4	Bit no. 3	Bit no. 2	Bit no. 1	Bit no. 0
		Stop bit	Stop bit	Parity bits	Parity bits	Baud rate	Baud rate	Baud rate	Baud rate
5012	5020	Device encoding output							
5013	5021	Transfer format output							
		Bit no. 7	Bit no. 6	Bit no. 5	Bit no. 4	Bit no. 3	Bit no. 2	Bit no. 1	Bit no. 0
		Stop bit	Stop bit	Parity bits	Parity bits	Baud rate	Baud rate	Baud rate	Baud rate
5014	5022	X <sub>ON</sub> characters (DC start character)							
5015	5023	X <sub>OFF</sub> characters (DC stop character)							
5016	5024	Special functions:							
		Bit no. 7	Bit no. 6	Bit no. 5	Bit no. 4	Bit no. 3	Bit no. 2	Bit no. 1	Bit no. 0
		Output without first Xon character	Progr. start using LF	Block end CR LF	Output in EIA code	Stop using end of text	Ready to start evaluate DSR signal	Output without header and end	Read in programs from SINU- MERIK systems 3,8
5017	5025	Special functions:							
		Bit no. 7	Bit no. 6	Bit no. 5	Bit no. 4	Bit no. 3	Bit no. 2	Bit no. 1	Bit no. 0
									Time monitor- ing switched off
5026	5026	EIA code for "@"							
5027	5027	EIA code for ":"							
5028	5028	EIA code for "end of text"							
5029	5029	EIA code for "="							

Description of interfaces

## 6.7 Assignment of the setting data for the connection of peripheral devices

Peripheral device	Ident. of the device type (CRT display)	SD no.		Required setting data bits (binary code)
		Inter- face 1	Inter- face 2	
SINUMERIK Reader: T40, T50, T60 RS 232 C, 9600 baud	RTS-LINE	5010 5011	5018 5019	0000 0000 1100 0111
SINUMERIK WS 800 RS 232 C, 20 mA 9600 baud	RTS-LINE	5010 5011 5012 5013	5018 5019 5020 5021	0000 0000 1100 0111 0000 0000 1100 0111
Siemens Programmer unit PG 685/675/670 20 mA, 9600 baud Interface AG S5	PLC-PROG.	5010 5011	5018 5019	0000 0100 0000 0111
Siemens Programmer unit PG 675 RS 232 C, 1200 baud Interface printer	RTS-LINE	5010 5011 5012 5013 5016 5028	5018 5019 5020 5021 5024 5028	0000 0000 1100 0100 0000 0000 1100 0100 0010 1000 0000 0011
Siemens Programmer unit PG 615 U 20 mA, 9600 baud	PLC-PROG.	5010 5011	5018 5019	0000 0100 0000 0111
Siemens page printer PT80 20 mA RS 232 C, 300 baud	RTS-LINE	5010 5011 5012 5013	5018 5019 5020 5021	0000 0000 1100 0010 0000 0000 1100 0010

Setting Data number (SD no.) and setting data bits, dependent on type of peripheral device

## 6.7 Assignment of the setting data for the connection of peripheral devices

Peripheral device	Ident. of the device type (CRT display)	SD no.		Required setting data bits (binary code)
		Interface 1	Interface 2	
Siemens Printer PT 88 RS 232 C, 9600 baud	RTS-LINE	5012 5013	5020 5021	0000 0000 1100 0111
SINUMERIK System 800, NC-NC Coupling, RS 232 C, 9600 baud	RTS-LINE	5010 5011 5012 5013	5018 5019 5020 5021	0000 0000 1100 0111 0000 0000 1100 0111
Siemens Programming Workstation PD..., PG... RS 232 C, 4800 baud	PD/PF	5010 5011 5012 5013 5014 5015	5018 5019 5020 5021 5022 5023	0000 0011 1100 0110 0000 0011 1100 0110 0001 0001 1001 0011
Sanyo cassette M2502U-ZE601 RS 232 C, 1200 baud	RTS-LINE	5010 5011 5012 5013	5018 5019 5020 5021	0000 0000 1100 0100 0000 0000 1100 0100
Teletype, ASR33 Full duplex  20 mA, 110 baud	RTS-LINE	5010 5011 5012 5013	5018 5019 5020 5021	0000 0000 1100 0000 0000 0000 1100 0000
Facit reader 4040, 4042 Reader/punch RS 232 C, 1200 baud	RTS-LINE	5010 5011 5012 5013	5018 5019 5020 5021	0000 0000 1100 0011
Facit reader 4030 RS 232 C, 1200 baud	RTS-LINE	5010 5011	5018 5019	0000 0000 1100 0100
Sommer terminal MDC-3 SNC cassette unit, RS 232 C, 9600 baud	RTS-LINE	5010 5011 5012 5013	5018 5019 5020 5021	0000 0000 1100 0111 0000 0000 1100 0111

## 6.8 Device connection data

<b>SINUMERIK reader T40 and T50</b>	<b>SINUMERIK reader T60 (Hand-held unit) Type GNT 2910</b>
Cable Order No.: 6FC9 340-8S.	Cable Order No.: 6FC9 344-2C.
<b>Device data</b> Transfer rate            9600 baud Character format        1 start bit 8 data bits 2 stop bits	<b>Device data</b> Transfer rate            9600 baud Character format        1 start bit 8 data bits 2 stop bits
<b>Settings on T40 reader</b>  Switch block A: 1   2   3   4   5   6   7   8 ON  ON  -  OFF OFF OFF OFF OFF  Switch block B: 1   2   3   4   5   6   7   8 ON  OFF OFF OFF OFF OFF OFF OFF	<b>Settings</b>  DIP switch in unit 1   2   3   4   5   6   7   8 OFF OFF OFF OFF OFF OFF ON  OFF
<b>Settings on T50 reader</b>  Jumper assignment at 27 PO1: not allocated  Jumper assignment at 27 PO2: Jumpers 2 and 5 closed  Jumper assignment at 27 SO2: Jumpers 1, 2, 3, 4 open	<b>Operating notes</b> Before switching the device on, ensure that the paper tape has been inserted. If there is a fault, the green LED flashes. Acknowledge by switching the device off and on. Read-in start is controlled by the SINUMERIK.
<b>Operating notes</b>  To automatically start from the SINUMERIK, the reader must be ready to start, the "Reader Start" LED must be lit. An exact character stop is not possible. If programs are produced externally, and several programs punched onto one tape, about 20 blanks must be left between programs. When punching programs from the SINUMERIK, these blank characters are automatically generated, provided that the "Output without leading and trailing tape" setting data bit is not set (SD no. 5016, bit 1 for interface 1 or SD no. 5024, bit 1 for interface 2).	<b>Further operating conditions</b> The device stops on a precise character.
	<b>SINUMERIK WS 800</b>  Cable Order No.: 6FC9 344-1B. (RS 232(V.24)) 6FC9 344-1Q. (20 mA)
	<b>Device data</b> Interface RS 232 (V.24) or 20 mA current loop (TTY) Transfer rate            9600 baud  Character format        1 start bit 8 data bits 2 stop bits
	<b>Settings on the interface module DF 20</b> Interface SS2 RS 232 (V. 24): no hardware setting TTY:            passive Socket X9 Jumper 2 - 14 Receiver 3 - 13  6 - 10 Transmitter 7 - 9

**Siemens Programmer Unit  
PG 685 / 675 / 670**

Interface **S5 PLC**

Cable Order No.: 6FC9 340-8G

**Device data**

Interface: 20 mA  
current loop  
Transfer rate: 9600 baud  
Character format: 1 start bit,  
8 data bits,  
1 parity bit  
(even parity),  
2 stop bits

**Operating conditions**

For PLC programming the PG 685 / 675 / 670 is connected directly to Interface 1 (20 mA current-loop interface) on the SINUMERIK.

**Siemens Programmer Unit PG 675**

Interface **Printer**

Cable Order No.: 6FC9 344-1A.

**Device data**

Interface RS 232 C  
Transfer rate 1200 baud  
Character format 1 start bit  
8 data bits  
2 stop bits

**Operating conditions**

Archiving of NC cycles and programs onto disk, and transfer to and from the NC and the creation of programs is possible with the PG 675. For data transfer, the PG 675 should be connected from the **printer** interface to an RS 232 C interface on the SINUMERIK.

**Siemens Programmer Unit PG 615 U  
with PG 615 adapter and power pack**

Interface **PLC**

Cable Order No.: 6FC9 340-8H.

**Device data**

Interface 20 mA  
current loop  
Transfer rate 9600 baud  
Character format 1 start bit  
8 data bits

**Siemens page printer PT80**

Cable Order No.: 6FC9 340-8C .  
RS 232 (V. 24)  
6FC9 340-8T .  
(20mA)

**Device data**

Transfer rate 300 baud  
Character format 1 start bit  
8 data bits  
2 stop bits

Order No. for PT80 to SINUMERIK  
specification:

Type RS 232 C: L22751-A80-D442  
(Interface module  
STT104)

Type 20mA L22751-A80-D441  
(Interface module  
STT104 + LAT101)

Additional cable for  
terminal connection:  
6FC9340-4KA

An NC-controlled read operation  
(start/stop) is possible on the device with  
a 20mA interface.

**Siemens printer PT88**

Cable Order No.: 6FC9 340-8D.

**Device data**

Interface connection SAP-S1  
(RS 232 C)

**Setting of the operating mode  
switches**

Switch S1

1	2	3	4	5	6
ON	ON	ON	OFF	OFF	OFF

(with this setting, the printer has a  
transfer rate of 9600 baud)

Switch S2

1	2	3	4	5	6
OFF	ON	OFF	ON	OFF	ON

(this setting denotes:  
BUSY (X2.10) line is switched to BUSY  
(X1.25) line, with negative potential)



# 7 Maintenance

## 7.1 Operating data



Modules/components carrying this warning symbol (yellow hand on a black triangle, with line through) are endangered by electrostatic charge.

Therefore, please pay attention to the following guidelines:

- Electronics modules should not be touched unless it is absolutely vital for work to be done.

- Before touching a module, any static in the body must be discharged. The easiest way to do this is by touching a conductive, earthed part of the structure (e.g. bare metal parts of the cabinet, socket earth contact).

- Modules should not be brought into contact with materials that are good insulators (e.g. plastic foil, insulated desk tops, clothing made from synthetic fibres).

- Modules should only be laid on conductive surfaces.

- Modules should only be plugged in or unplugged with the power off.

- The power supply should be switched on before any signal voltages are applied.

- Modules and components should always be stored and carried in conductive packing (e.g. metallised plastic boxes, metal containers).


- If the packing is not conductive, the modules should be wrapped in conductive material prior to packing. For example, conductive foam rubber or aluminium foil can be used.

## 7.2 Battery submodule

If the voltage is switched off, the RAM is backed up by a battery voltage. The following data are maintained in the memory:

- Part programs
- Tool offsets
- Setting data
- Zero offsets
- Machine data (NC-MD and PLC-MD)
- R Parameter
- PLC user program
- User texts (PLC alarm texts and PLC message texts)

A battery submodule which is connected to the central processing unit via X321 backs up the RAM memory.




*Battery submodule slot*

## 7.2.1 Replacing the battery

- The back-up time of the battery submodule is 1 year.
- Alarm 1 (battery alarm) is displayed when the battery should be replaced.
- Once alarm 1 has responded, the battery must be changed within 1 week!

### Note:

The battery submodule uses 3 miniature cells (usual in trade) as shown below:



- 1) The battery may only be replaced when the control is switched on!**
- 2) When replacing the battery, ensure that the polarity is correct!**
- 3) Please follow the regulations regarding the disposal of old batteries.  
If in doubt consult the appropriate authorities.**

### **7.3 CRT display**

The pictures on the CRT display can oscillate when the monitor is exposed to electromagnetic fields. Devices which generate electromagnetic fields, such as transformers, fans, electromagnetic switches, a.c. cables under power, etc. must be more than 300 mm away from the CRT display unit.

### **7.4 Cleaning**

The front of the monitor and the surface of the operating panel can be cleaned. For dirt that is relatively easy to remove, standard household washing-up liquid, or an industrial cleaner (such as "Spezial Swipe") can be used. These cleaners will also remove dirt containing graphite.

Cleaning agents which contain one or more of the following ingredients can be used for short periods of time:

- diluted mineral acids
- bases
- alcohol
- organic hydrocarbons
- detergent solutions
- greases and oils

## 8 Monitoring

### 8.1 General

The control contains constantly active monitoring functions which can recognize faults in the NC, the interface control and the machine early enough for damage to the workpiece, tool or machine to be largely eliminated.

If a fault does occur, first of all machining is interrupted and the drives brought to a standstill and the reason for the fault is stored and displayed as an alarm. At the same time the PLC is informed that an NC alarm exists.

Monitoring functions exist for the following areas:

- Read-in
- Format
- Measuring circuit cables
- Encoders and drive
- Contour
- Spindle speed
- Enable signals
- Voltage
- Temperature
- Microprocessors
- Serial interfaces
- Transfer between NC and PLC
- Voltage level of the backup battery
- System program memory
- User program memory

In addition, 64 PLC alarms and 64 PLC messages as well as 100 user cycle alarms are available to the PLC user. The texts for these are transferred via RS 232 C interface into the buffered memory area of the control.

### 8.2 Alarm numbers and groups/clearing alarms

The SINUMERIK 805 features the following alarm groups:

- NC alarms:
  - POWER ON alarms
  - RS 232 C alarms
  - RESET alarms (axis-specific)
  - RESET alarms (general)
  - Acknowledge alarms
- PLC alarms:
  - PLC system and programming alarms
  - PLC user alarms
- PLC messages:
  - PLC user messages

## 8.2 Alarm numbers and groups/clearing alarms

Type	Numbers	Groups		Acknowledged by:
NC alarms	1...15 40...99 132* 1)	Power On alarms		Switching the control off and on
	16 : 39	RS 232 C alarms		1. Selecting data area 2. Operating DATA TRANSFER softkey 3. Operating STOP softkey
	100* : 196*	axis- spec.	Reset alarms	Operating the RESET key on the operator keyboard
	2000 : 2999	gen.		
	3000 : 3081	Acknowledge alarms		Operating the QUIT softkey
	4000 : 4999	Standard cycle alarms		
	5000 : 5099	User cycle alarms		
PLC alarms	6000 : 6063	User alarms		Operating the QUIT softkey
	6100 : 6163	PLC system and programming alarms		Switching the control off and on
PLC messages	7000 : 7063	User messages		No acknowledgement/clear necessary


1): the asterisk \* represents:

- "0" for alarms in axis 1
- "1" for alarms in axis 2
- "3" for alarms in axis 3
- "3" for alarms in axis 4

## 8.3 Monitoring display on the screen

### 8.3.1 Message line for NC and PLC alarms and messages

Only the alarm with the lowest alarm number is displayed in the message line for NC or PLC alarms and messages.



Message line for NC or PLC alarms and messages

An alarm is displayed in the message line along with its alarm number and accompanying text (in example: alarm no. 3 (PLC-STOP)).

### 8.3.2 List of active alarms and signals


In the event of an alarm, several different alarms and/or messages can be recorded by the NC. A listing of all active alarms and messages can be selected as follows:



**Prerequisite:** The SINUMERIK 805 machine area has been selected.



Operate the OPERATING AREA key to select the data area.




Operate the DIAGNOSIS softkey.

**Note:**

Explanations to display and DIAGNOSE softkey in Section 4.8.

## 8.3.2 List of active alarms and signals

**Notes:**

- When you operate the OPERATING AREA key, you return to the basic menu of the set operating mode in the machine area.
- The sequence no (SEQ.) shows the order in which the alarms have appeared. The sequence numbers start at 1 and finish at 99. The sequence number returns to 1 each time the control is turned on.
- In the case of alarms which occur whilst a program is being processed, the block number concerned is also displayed.
- The alarm number of the active alarm is displayed at the beginning of the line.

For a separate overview of the active NC alarms, PLC alarms or PLC messages, operate the following softkeys:

Softkey      NC-ALARMS  
 Softkey      PLC-ALARMS  
 or  
 Softkey      PLC-MESSAGES in the MESSAGES basic menu



**8.3.3 List of alarms**

<b>1</b>	<b>Battery alarm! Do not switch off! Change battery!</b>
Cause: Scan: Explanation: Remedy: <b>Caution!</b>	Back-up battery voltage too low – On POWER ON – Cyclic Replace battery (see Section 7.2.1). Battery voltage has dropped so low that backup of the user memory can only guaranteed for a short time. Replace battery (see Instruction Manual), old batteries must be disposed of separately. Do <b>not switch off</b> the control, otherwise data will be lost.
<b>2</b>	<b>Operator panel error</b>
Cause: Scan:	Keyboard is not ready, cable damaged Cyclic
<b>3</b>	<b>PLC stop</b>
Cause: Scan: Effect: Explanation: Remedy:	PLC not operational Cyclic – Interlocking of NC START – Setpoint relay drop (setpoint 0) – Removal of NC READY 2. – Servo enable is removed in MD 156 after delay has elapsed (servo enable relays drop out) – NC/PLC interface is put into the inactive state Cyclic and alarm-controlled operation of PLC interrupted. It is not possible to traverse the machine. Use the programmer to read out the cause of the interruption (USTACK).
<b>4</b>	<b>Invalid unit system</b>
Scan: Effect: Explanation: Remedy:	– On POWER ON – After modification of MD – Conversion factor taken as 1 In MD NC 5002 an illegal combination of measuring system unit (position resolution) and input unit system (conversion factor greater than 10) was selected. Correct MD bit 5002 and switch control on/off.

<b>7</b>	<b>EPROM error</b>
Scan: Effect:	Cyclic – Interlocking of NC-START – Setpoint relay drop (setpoint 0) – Removal of NC READY 2 – Servo enable is removed in MD 156 after delay has elapsed (servo enable relays drop out)
Explanation: Remedy:	– An error was detected whilst checking totals – Notify service

<b>8</b>	<b>Incorrect axis/spindle assignment</b>
Scan: Effect:	After modification of MD – Interlocking of NC START – Setpoint relay drop (setpoint 0)
Explanation:	Removal of NC READY 2. An illegal assignment had been made in MD 200* or MD 400*. <b>Correct:</b> (0000) Axis/spindle not available at machine (only permissible with NC-MD bit 564*.7 = "0" (for axes)  0100 0200 0300 0400 0500
Remedy:	See Section 8 (MD description for MD 200* and MD 400*)

<b>12</b>	<b>Part program memory wrongly formatted</b>
Scan: Effect:	On POWER ON – Fault in RAM area – The part program memory size falls below minimum size permitted.
Remedy:	Format part program memory in initialization mode

<b>13</b>	<b>RAM error</b>
Scan: Effect: Remedy:	On POWER ON Error in module RAM area – Format user memory and format part program memory in initialization mode – Change CC

<b>16</b>	<b>Parity error RS 232 C</b>
Effect:	<ul style="list-style-type: none"> <li>– RS 232 C transmission interrupted</li> <li>– Last block declared invalid</li> </ul>
Explanation:	<p>Alarm can only occur if parity is selected. The character commenced has incorrect parity. The alarm has nothing to do with character parity errors RS 232 C in ISO or EIA punched tapes (alarm 23)</p>
Remedy:	<ul style="list-style-type: none"> <li>– Check RS 232 C parameters</li> <li>– Check external device</li> </ul>
<b>17</b>	<b>Overflow error RS232 C</b>
Effect:	<ul style="list-style-type: none"> <li>– RS232 C transfer interrupted</li> <li>– Last block declared as invalid</li> </ul>
Explanation:	The external device has sent a new character although the CNC has not yet processed the old one.
Remedy:	<ul style="list-style-type: none"> <li>– Check RS 232 C interface parameters</li> <li>– Test external device</li> </ul>
<b>18</b>	<b>Frame error RS 232 C</b>
Effect:	<ul style="list-style-type: none"> <li>– RS 232 C transfer is interrupted</li> <li>– Last block declared invalid</li> </ul>
Explanation:	<ul style="list-style-type: none"> <li>– Number of stop bits is incorrect</li> <li>– Incorrect baud rate</li> <li>– Number of data bits is incorrect</li> </ul>
Remedy:	<ul style="list-style-type: none"> <li>– Check RS 232 C interface parameters</li> <li>– Test external device</li> <li>– Number of data bits: 7 data bits + 1 parity bit (set external device)</li> </ul>
<b>19</b>	<b>I/O device not ready RS232 C</b>
Effect:	No files are read in
Explanation:	The DSR signal from the external device is LOW
Remedy:	<ul style="list-style-type: none"> <li>– Start external device</li> <li>– Do not use DSR</li> </ul>

<b>22</b>	<b>Time monitoring RS232 C</b>
Explanation:	<ul style="list-style-type: none"> <li>- The CNC cannot output a signal for 60 sec.                             <ul style="list-style-type: none"> <li>-- The external device blocks the CTS (clear to send) signal for longer than 60 sec</li> <li>-- The external device does not send DC1 within 60 sec when control signals (DC1 to DC4) are used.</li> </ul> </li> <li>- The CNC has not received a signal for 60 sec.</li> </ul>
Remedy:	<ul style="list-style-type: none"> <li>- Check external device and switch on</li> <li>- Check cable and plug in.</li> <li>- Switch off time monitoring in parameter menu.</li> </ul>

<b>23</b>	<b>Character parity error RS 232 C</b>
Cause:	Punched tape soiled or damaged
Effect:	<ul style="list-style-type: none"> <li>- RS 232 C transmission interrupted</li> <li>- Last block declared invalid</li> </ul>
Explanation:	<p>Depending on definition of start of program "%" or "EOR", the NC automatically establishes the ISO or EIA code upon receipt of this character and thus character parity.</p> <p>When checking the following characters, it was established that one character does not have the set parity.</p>
Remedy:	Check punched tape or data on diskette

<b>24</b>	<b>Invalid EIA character RS 232 C</b>
Effect:	<ul style="list-style-type: none"> <li>- Data transfer interrupted</li> <li>- Last block declared invalid</li> </ul>
Explanation:	EIA character was read in with the correct parity, however, the character is not defined in the EIA code.
Remedy:	<p>Check punched tape:</p> <p>check EIA code for "@" and                  EIA code for ":-"</p>
Caution:	<p>As the ":-" character is not defined in the EIA code, the following data cannot be read in:</p> <ul style="list-style-type: none"> <li>- %TEA1 (NC machine data)</li> <li>- %RPA (R parameter)</li> <li>- %TOA (tool offsets)</li> <li>- %TEA2 (PLC machine data)</li> <li>- %ZOA (zero offset)</li> <li>- main programs and subroutines with R parameter calculations</li> </ul>

<b>26</b>	<b>Part prog. block &gt; 120 characters RS 232 C</b>
Cause:	The part program block that has been read in contains more than 120 characters. Only the actual stored characters are counted (no spaces, no CR, ...)
Effect:	<ul style="list-style-type: none"> <li>– Data transfer interrupted</li> <li>– Last block is not stored</li> </ul>
Remedy:	Divide block into 2 or more blocks
<b>27</b>	<b>Data input disabled RS 232 C</b>
Cause:	"Cycle lock" interface signal is active: NC, PLC machine data texts have been read in without password input.
Effect:	No data has been stored
Remedy:	<ul style="list-style-type: none"> <li>– Reset Q 78.3 via PLC status</li> <li>– Enter password (scan appears when machine data is altered)</li> </ul>
<b>28</b>	<b>Ring buffer overflow RS 232 C</b>
Effect:	<ul style="list-style-type: none"> <li>– RS232 (V.24) transfer is interrupted</li> <li>– The last blocks are declared as invalid</li> </ul>
Explanation:	Data transfer speed so high that more characters are transferred than can be processed by the NC. If the program is transferred again, the faulty program must be deleted beforehand
Remedy:	<ul style="list-style-type: none"> <li>– RTS signal has no effect on the input device (RTS causes the input device to STOP)</li> <li>– Transmission speed (baud rate) too high</li> </ul>
<b>29</b>	<b>Block &gt; 254 characters RS 232 C</b>
Cause:	The read-in block has more than 254 characters. All read-in characters (e.g. spaces) are included in the count.
Effect:	<ul style="list-style-type: none"> <li>– RS 232 C transfer interrupted</li> <li>– Last block is not stored</li> </ul>
Remedy:	Divide block into two or more blocks.
<b>30</b>	<b>Part program memory full RS 232 C</b>
Cause:	The maximum part program memory is full
Effect:	<ul style="list-style-type: none"> <li>– RS 232 C transfer interrupted</li> <li>– Last block is not stored</li> </ul>
Remedy:	Delete old programs and reorganize memory

<b>31</b>	<b>No further part program input possible (RS 232 C)</b>
Cause:	The maximum number of programs stipulated by machine data has been reached.
Remedy:	<ul style="list-style-type: none"> <li>– Delete old programs and reorganize memory</li> <li>– Modify MD 8 and reformat part program memory</li> </ul> Order: <ul style="list-style-type: none"> <li>a. "INITIALIZATION" mode</li> <li>b. "Format user data" softkey</li> <li>c. "Format part program memory" softkey</li> </ul> Old programs are also deleted!

<b>32</b>	<b>Data format error (RS 232 C)</b>
Cause:	<ul style="list-style-type: none"> <li>– The permissible number of decades after an address is not correct</li> <li>– The decimal point occurs in the wrong place</li> <li>– Part programs and subroutines are not correctly defined or concluded (check heading!)</li> <li>– NC expecting an "=" character, which is however not correctly defined in the EIA code.</li> </ul>
Effect:	Data transfer interrupted. Last block is not stored
Remedy:	Check the program to be read in

<b>33</b>	<b>Programs differ (RS 232 C)</b>
Cause:	Read-in and stored program not identical with program with same number
Effect:	No data is stored
Remedy:	Delete old program or rename old program
Explanation:	If a new program is read in which has the same program number as one already stored, both programs are compared. If the programs are different, an alarm is given.

<b>34</b>	<b>Operator error (RS 232 C)</b>
Cause:	Data transfer in NC has started and the PLC gives second signal
Effect:	No data is read in
Remedy:	Stop data input and restart

<b>35</b>	<b>SIEMENS reader error (RS 232C)</b>
Cause: Scan: Effect: Remedy:	Error message output from SIEMENS tape reader Only when parameters for SIEMENS reader have been set – Data transfer interrupted – Last block not stored – Restart data transfer – If error reoccurs: replace SIEMENS reader.

<b>104*</b>	<b>DAC limitation</b>
Scan: Effect: Explanation: Remedy:	Cyclic No direct effect. Absorbed by the following error alarm 156* The DAC setpoint entered is higher than in MD 268* (max. DAC setpoint). It is not possible to increase the setpoint any further! – Traverse more slowly – Check the actual values (encoder) – Check MD 268* – Check the drive actuator – Check MD 364* and MD 368*

<b>108*</b>	<b>Actual part position overrun</b>
Scan: Effect: Explanation: Remedy:	At each axis movement (also follow-up mode) – Interlocking of NC START – Setpoint relay drop (setpoint 0) – Removal of NC READY 2. – Servo enable is removed in MD 156 after delay has elapsed (servo enable relays drop out) – NC/PLC interface is put into the inactive state – Follow-up mode – Actual value of the machine is lost (incorrect position). The actual part value is multiplied by the control. With rapid traverse of the axis the register overflows in the case of the fault. The reference point is lost. – Reduce maximum speed – Check MD for variable incremental weighting (MD* 364 and MD 368*)


<b>112*</b>	<b>Standstill monitoring</b>
Cause:	<ul style="list-style-type: none"> <li>- Incorrect position control direction</li> <li>- Mechanically clamped axis has been pushed out of position.</li> <li>- Fault on control device (actuator), at the tacho, motor, in the mechanics or NC measuring circuit hardware</li> </ul>
Scan:	<ul style="list-style-type: none"> <li>- On standstill</li> <li>- On clamping</li> <li>- On deceleration</li> </ul>
Effect:	<ul style="list-style-type: none"> <li>- Interlocking of NC START</li> <li>- Setpoint zero</li> <li>- Servo enable is removed in MD 156 after delay has elapsed (servo enable relays drop out)</li> <li>- Follow-up mode</li> </ul>
Explanation:	The following error could not be cleared faster than the time entered MD 156. On clamping the limit defined in MD 212* was exceeded.
Remedy:	<ul style="list-style-type: none"> <li>- MD 212* (clamping tolerance) must be greater than MD 204* (exact stop limit coarse)</li> <li>MD 156 (switch-off delay control enable) must be large enough to allow the following error of the axis entered to be cleared within the period entered.</li> </ul>

<b>116*</b>	<b>Contour monitoring</b>
Scan:	<p>When machining in AUTOMATIC, but <b>not</b></p> <ul style="list-style-type: none"> <li>- when accelerating</li> <li>- when decelerating</li> <li>- at speeds lower than that in NC MD 336* (contour speed)</li> <li>- Interlocking of NC START</li> </ul>
Effect:	<ul style="list-style-type: none"> <li>- Setpoint 0</li> <li>- The control enable is removed after the time stored in MD 156 -- has elapsed (control enable relay drops out)</li> <li>- Follow-up operation</li> </ul>
Explanation:	<p>The tolerance band NC MD 332* was exceeded at a speed greater than MD 336*</p> <p>When accelerating or decelerating the axis has not reached the new speed within the time defined by the <math>K_v</math> factor</p>
Remedy:	<ul style="list-style-type: none"> <li>- Increase the tolerance band in NC MD 332*</li> <li>- Check the KV factor</li> <li>- Check the optimization of the speed controller</li> <li>- Check drive actuator</li> </ul>



<b>132*</b>	<b>Control loop hardware</b>
Scan: Effect:	Cyclic – Interlocking of NC START – removal of NC READY 2 – Setpoint relay drops out (setpoint 0) – The control enable is removed after the time delay MD 156 has elapsed (control enable relay drops out) – Follow-up operation
Explanation:	The measuring circuit differential signals – are not in phase – have a short-circuit to earth – are missing
Remedy:	– Check that the measuring circuit connector is inserted – By plugging in the measuring circuit short-circuit connector it can be checked whether the measuring circuit module is in working order – Check the differential signals with an oscilloscope – Replace the measuring sensors
<b>136*</b>	<b>Measuring system dirty</b>
Scan: Effect:	Cyclic Interlocking of NC START
Explanation:	The processing of the current program is completed In measuring systems with contamination signal (e.g. EXE), the measuring system signals a fault to the NC.
Remedy:	Check the measuring system
<b>144*</b>	<b>Zero mark monitoring</b>
	(available soon)
<b>148*</b>	<b>Software limit switch plus</b>
<b>152*</b>	<b>Software limit switch minus</b>
Scan: Effect:	At each axis movement – Interlocking of NC START – Setpoint 0
Explanation:	The alarm is only active after reference point approach Depending upon the PLC Interface Signal "2nd Software Limit Switch Active", the 1st or 2nd software limit switch has been approached
Remedy:	– Traverse away from the end limit switch in the opposite direction – Check MD 224*, 228*, 232*, 236*


<b>156*</b>	<b>Speed command value</b>
Scan: Effect:  Explanation:  Remedy:	Cyclic – Interlocking of NC START – Setpoint 0 – The control enable is removed after the delay in NC MD 156 has elapsed (control enable relay drops out) – Follow-up operation – A higher set speed has been output in the control than that specified in NC MD 264* – The motor cannot follow the speed command value – Check whether the value in NC MD 264* is higher than the value in NC MD 268* – Check the drive – Check the measuring system – NC neutral earthing? – Check drive actuator – Check the position control direction (command value/actual value reversed?)

<b>160*</b>	<b>Drift too high</b>
Scan: Effect:  Explanation:  Remedy:	Cyclic – Interlocking of NC START – "+" or  "-" sign is in the field – No traverse movement possible The drift to be compensated by the NC itself has risen to over approx. 500 mV – Execute drift compensation Operation: -- Select Service menu in data area -- Operate DRIFT COMPENSATION softkey for the axis concerned – Check that the drift has been correctly calibrated on the drive unit – Check drive actuator – Check earthing concept

<b>168*</b>	<b>servo enable for traver. axis not received</b>
Scan: Effect:  Explanation:  Remedy:	At each axis movement – Interlocking of NC START – Setpoint 0 – The control enable is removed after the time stored in MD 156 has elapsed (control enable relay drops out) – Follow-up operation The axis-specific control enable signal was removed by the PLC user program during traversing Check the PLC program

<b>172*</b>	<b>Working area limit plus</b>
<b>176*</b>	<b>Working area limit minus</b>
Scan: Effect: Explanation: Remedy: Note:	<ul style="list-style-type: none"> <li>– When machining in AUTOMATIC</li> <li>– When traversing axes in JOG mode</li> </ul> <p>Interlocking in NC START</p> <ul style="list-style-type: none"> <li>– Setpoint 0</li> </ul> <p>The working area limit in the setting data has been reached</p> <ul style="list-style-type: none"> <li>– Check the working area limitation in the setting data</li> <li>– Check the program</li> </ul> <p>Working area limitation in JOG is only active when NC MD 5003 bit 6 is set</p>
<b>184*</b>	<b>stop behind reference point cam</b>
Scan: Effect: Explanation: Remedy:	<p>On reference point approach</p> <ul style="list-style-type: none"> <li>– Interlocking of NC START</li> <li>– Setpoint 0</li> <li>– Reference point not reached</li> </ul> <p>During reference point approach the axis between the reference cams and measuring system zero mark was stopped</p> <p>Restart reference point approach</p>
<b>2000</b>	<b>Emergency stop</b>
Scan: Effect: Explanation: Remedy: Caution:	<p>Cyclic</p> <ul style="list-style-type: none"> <li>– Interlocking of NC START</li> <li>– Setpoint 0</li> <li>– Servo enable is removed in MD 156 after delay has elapsed (servo enable relays drop out)</li> <li>– Follow-up mode</li> </ul> <p>The emergency stop signal is transmitted by the PLC to the NC</p> <ul style="list-style-type: none"> <li>– PLC-STATUS check that Q 78.1 = 0</li> <li>– Check whether EMERGENCY STOP cams have been approached or whether EMERGENCY STOP keys have been operated</li> <li>– Check PLC program:</li> </ul> <p>According to the regulations, the EMERGENCY STOP state must be selected not only from the control (software) but also from the hardware (using relay).</p>

<b>2031</b>	<b>Evaluation factor too high (MD 356*)</b>
Scan: Effect: Remedy:	At each axis movement – Interlocking of NC START – Setpoint zero – Machining stop Check MD 388*
<b>2032</b>	<b>Stop during threading</b>
Effect: Explanation:	– Setpoint 0 – Interlocking of NC START During thread cutting, the feedrate per revolution was stopped and the thread destroyed.
<b>2034</b>	<b>Speed reduction area</b>
Explanation: Remedy:	The software pre-limit switch was overshoot and the axis decelerated to the reduction speed – Check the program – MD 0 - pre-limit switch – MD 1 - speed beyond pre-limit switch (reduction speed)
<b>2035</b>	<b>Programmed speed too high</b>
Explanation: Remedy:	The programmed speed is higher than the contouring speed based on the maximum speed of the axes – Program lower contouring speed – Check MD 280* maximum contouring speed – Check MD 296* during reference point approach

<b>2036</b>	<b>G35 thread lead decr. error</b>
Scan: Explanation:  Remedy:	<p>On thread cutting The pitch decrease in threading is so high that at the end of the thread a diameter of 0 would arise.</p>  <p>Program a lower pitch decrease or a shorter thread</p>

<b>2037</b>	<b>Progr. S value too high</b>
Explanation: Remedy:	<p>The programmed spindle speed "S" is greater than "12 000" Program a lower spindle speed (S value is limited to "12000" in the control)</p>

<b>2039</b>	<b>Reference point not reached</b>
Scan: Effect: Explanation:  Remedy:	<p>In AUTOMATIC/MDA after NC START Interlocking of NC START</p> <p>The reference point was not traversed to by all defined axes</p> <ul style="list-style-type: none"> <li>- Approach reference point with axes concerned</li> <li>- Set NC-MD 5004 bit 3 (NC START without reference point) <b>Caution:</b> Software limit switch not effective</li> <li>- Set NC-MD 560* bit 4</li> </ul> <p>It is thus possible to disable the reference point approach axis-specifically for one or more specific axes. <b>Caution:</b> No software limit switches are active with these axes.</p>

<b>2040</b>	<b>Block not in memory</b>
Effect: Explanation:	Interlocking of NC START – The block number sought in program with block search is not in the memory. – The programmed block number could not be found with the jump function in the given direction.

<b>2041</b>	<b>Program not in memory</b>
Effect: Explanation:  Remedy:	Interlocking of NC START – The preselected program is not in the memory – The subroutine called in the main program is not in the memory Look at "Main programs" and "Subroutines" overview.

<b>2042</b>	<b>Parity error in memory</b>
Scan: Explanation:  Effect: Remedy:	During machining in AUTOMATIC mode One or more characters have been deleted in the memory so that they can no longer be recognized (these characters are output as "?") Interlocking of NC START – Correct program in EDITOR or delete the complete block and re-enter it – If a large number of "?" appear, it could mean that the whole memory has been deleted in which case the battery should be checked and the part program memory reformatted

<b>2046</b>	<b>Block &gt; 120 characters</b>
Scan: Effect: Explanation:  Remedy:	During machining in AUTOMATIC Interlocking of NC START An "LF" has been corrupted in the memory, so that a block with more than 120 characters has arisen Insert "LF" without deleting the complete block

<b>2047</b>	<b>Option not available</b>
Effect: Explanation:  Remedy:	Interlocking of NC START A function was programmed that is not included in the function set of the control Correct the program, check MD

<b>2048</b>	<b>Circle endpoint error</b>
Effect: Explanation: Remedy:	Interlocking of NC START <ul style="list-style-type: none"> <li>– The programmed circle endpoint does not lie on the circle</li> <li>– The endpoint is out by more than the value entered in MD 7</li> <li>– No geometry in 1st block of the contour subroutine with L95 stock removal cycle</li> </ul> Correct program
<b>2057</b>	<b>Option not available</b>
Explanation: Remedy:	<ul style="list-style-type: none"> <li>– A thread was programmed in the memory using G33, G34 and G35, but this function has <b>not</b> been implemented in the control</li> <li>– Rev. feedrate G95 has been programmed</li> </ul> Correct program Check MD
<b>2058</b>	<b>Option not available</b>
Explanation: Remedy:	<ul style="list-style-type: none"> <li>– Three axes have been programmed simultaneously in the memory</li> <li>– A block has been programmed which causes the movement of three axes</li> </ul> Correct program Check MD
<b>2059</b>	<b>Program error G92</b>
Explanation: Remedy:	<ul style="list-style-type: none"> <li>– An invalid address character has been used</li> <li>– G92 programmed with address "P"</li> </ul> G92 is only permissible with address "S" (programmed spindle speed limit)
<b>2060</b>	<b>T0, Z0 program error</b>
Meaning:	<ul style="list-style-type: none"> <li>– A non-existent tool compensation number has been selected</li> <li>– The values in the selected zero offsets or tool compensations are too large</li> <li>– Tool offset type (P1) defined with 0</li> </ul>
<b>2061</b>	<b>General program error</b>
Effect: Remedy:	Interlocking of NC START Select "Current block display" display and check block <b>after</b> current block.

<b>2062</b>	<b>Feed missing/not programmed</b>
Ursache:	<ul style="list-style-type: none"> <li>– No F value programmed</li> <li>– F value too small (machine data)</li> <li>– Feed per rev. G95 programmed greater than 50 mm/min</li> <li>– No feed per rev. programmed</li> </ul>
Remedy:	Programm feedrate correctly
<b>2063</b>	<b>Thread lead too high</b>
Effect:	Interlocking of NC START
Explanation:	A thread lead of more than 400 mm/rev (16"/rev) has been programmed
Remedy:	<ul style="list-style-type: none"> <li>– Program lower thread leads</li> <li>– If necessary, run program on a machine with SINUMERIK 850 (max. speed 2000 mm/rev)</li> </ul>
<b>2064</b>	<b>Rounding err. for rotary axis wrongly prog.</b>
Scan:	On traversing in AUTOMATIC/MDA mode
Explanation:	If you round to either a half or full degree on a rotary axis, the control will monitor whether the programmed positions correlate with the rounding.
Effect:	<ul style="list-style-type: none"> <li>– Interlocking of NC START</li> <li>– Programmed path in block is <b>not</b> executed</li> </ul>
Remedy:	<ul style="list-style-type: none"> <li>– Program correct rotary axis position</li> <li>– Check MD 560* bits 2 and 3</li> </ul>
Note:	In the JOG and JOG INC modes, the control automatically rounds to valid values. In the AUTOMATIC or MDA modes, the control only monitors the programmed positions without rounding itself
<b>2065</b>	<b>Programmed position behind SW limit switch</b>
Scan:	On traversing in AUTOMATIC/MDA mode
Effect:	<ul style="list-style-type: none"> <li>– Interlocking of NC START</li> <li>– Programmed path <b>not</b> executed</li> </ul>
Explanation:	The programmed block end point lies behind the software limit switch
Remedy:	<ul style="list-style-type: none"> <li>– Correct program</li> <li>– Check MD 224*, 228*, 232*, 236* in dependence on PLC interface signal, "2nd software limit switch valid"</li> </ul>



<b>2066</b>	<b>Thread lead increase/decrease too high</b>
Scan: Effect: Explanation: Remedy:	On traversing in AUTOMATIC/MDA mode Interlocking of NC START A thread lead or pitch increase or decrease of more than 16 mm/rev (0.6"/rev) has been programmed Program a smaller thread lead increase/decrease
<b>2067</b>	<b>Max. speed of one axis = 0</b>
Scan: Effect: Explanation: Remedy:	On traversing in AUTOMATIC/MDA Interlocking of NC START An axis with a maximum speed of zero has been programmed in the block Check MD
<b>2068</b>	<b>Prog. position behind working area limit</b>
Scan: Effect: Explanation: Remedy:	On traversing in AUTOMATIC/MDA mode – Interlocking of NC START – The programmed path has <i>not</i> been executed The programmed block end point is in one or several axes behind the working area limit – Check working area limit (plus and minus) – After working area limit in the program with G25/G26
<b>2072</b>	<b>Incorrect input value (Blue print prog.)</b>
Explanation:	Input for contour definition cannot be calculated
<b>2073</b>	<b>No intersection point (Blue print prog.)</b>
Explanation:	Calculation of the contour definition gives no intersection point with the values programmed
<b>2074</b>	<b>Incorrect angle value (Blue print prog.)</b>
Explanation:	– Angle 360° programmed – Angle value for the contour described not logical

<b>2075</b>	<b>Incorrect radius value (Blue print prog.)</b>
Explanation:	<ul style="list-style-type: none"> <li>- Radius value too large</li> <li>- Radius value not allowed for the contour described</li> </ul>

<b>2076</b>	<b>Incorrect G02/G03 (Blue print prog.)</b>
Explanation:	Direction of circle for the described contour <i>not</i> possible

<b>2077</b>	<b>Incorrect block sequence (Blue print prog.)</b>
Explanation:	<p>Several block are needed for the calculation of the contour definition:</p> <ul style="list-style-type: none"> <li>- Block sequence not correct</li> <li>- Insufficient information (underdefined)</li> </ul> <p><b>Example:</b> N10...B15 LF N20...G3 I20 LF</p>

<b>2078</b>	<b>Incorr. input parameter (Blue print prog.)</b>
Explanation:	<ul style="list-style-type: none"> <li>- Programmed parameter sequence not allowed</li> <li>- Parameter sequence not complete for described contour</li> </ul> <p><b>Example:</b> N10...X60 B15 LF (Z axis missing) N20...X90 B10 LF</p>

<b>2081</b>	<b>Program block with TRC/CRC not allowed</b>
Explanation:	The following functions cannot be programmed with TRC/CRC (G41/G42) selected: G33, G34, G35, G58,G59, G92, M19 S...,
Remedy:	<ul style="list-style-type: none"> <li>- Pre-program G40</li> <li>- Cancel with G41/G42 D00 (FRK/SRK)</li> </ul>

<b>2082</b>	<b>CRC not determinable</b>
Explanation:	Axes for the selected CRC plane do not exist
Remedy:	<ul style="list-style-type: none"> <li>- Check MD 548*, 550*, 552* (basic setting of G16)</li> <li>- Select correct plane with G16</li> </ul>

<b>2152</b>	<b>Spindle speed too high</b>
Scan: Explanation: Remedy:	Only when MD 520* bit 2 is set (encoder available) The spindle speed is higher than fixed in the machine data <ul style="list-style-type: none"> <li>- Program lower S value</li> <li>- MD 403* - 410* (max. spindle speed for the first to eighth gear stage)</li> <li>- MD 445* (tolerance band for max. spindle speed)</li> <li>- MD 451* (max. spindle speed)</li> <li>- Gear stage correctly selected by PLC?</li> <li>- G92 S... if v constant is incorrectly programmed</li> </ul>
<b>2153</b>	<b>Control loop error (spindle)</b>
Scan: Effect:  Explanation: Remedy:	Cyclic <ul style="list-style-type: none"> <li>- Interlocking of NC START</li> <li>- Drop out of setpoint relay Setpoint 0</li> <li>- Removal of NC READY 2</li> <li>- Servo enable of spindles is removed in MD 4470 after delay has elapsed</li> </ul> As for alarm 132* As for alarm 132*
<b>2154</b>	<b>Measuring system dirty (spindle)</b>
Scan: Explanation: Effect: Remedy:	Cyclic In the case of measuring systems with a contamination signal, a fault is transmitted to the NC Interlocking of NC START Check the measuring system
<b>2155</b>	<b>Option not available</b>
Scan: Effect: Explanation: Remedy:	On traversing in AUTOMATIC/MDA mode Interlocking of NC START "M19 S..." is programmed in the part program although this function is not available <ul style="list-style-type: none"> <li>- Correct program</li> <li>- Retrofit M19</li> </ul>

<b>2171</b>	<b>Approach not possible</b>
Explanation:	The control adds max. 1 axis per programmed plane. Approach is not possible if two axes are to be added.
Remedy:	<ul style="list-style-type: none"> <li>– Check in the NC program that axis programming in approach block is complete</li> <li>– It is not possible to program a deselection block immediately after a selection block (tangent cannot be calculated).</li> </ul>

<b>2172</b>	<b>Retract not possible</b>
Explanation:	See alarm 2171
Remedy:	<ul style="list-style-type: none"> <li>– Check in the NC program that axis programming in approach block is complete</li> <li>– An approach movement must be programmed in G48 deselection movement (approach and withdrawal)</li> </ul>

<b>2173</b>	<b>Wrong approach/retract plane</b>
Explanation:	The movements resulting from the selection/deselection of the function soft approach to and exit from contour refer to the selected plane
Remedy:	G16, G17, G18, G19 Check whether a plane change is programmed in the block after selection or in the deselection block

<b>3000</b>	<b>General program error</b>
Explanation:	In one block of the program, a general, not precisely definable programming error has been made
	<b>Example:</b>
	<ul style="list-style-type: none"> <li>– An axis has been programmed which does not exist in the program</li> <li>– Incorrect interpolation number has been programmed</li> </ul>
Remedy:	Check the faulty block in the part program The block number appears in the "Signals" display.

<b>3001</b>	<b>More than 5 geometry parameters programmed</b>
Explanation:	More than 5 geometry parameters, such as axes, interpolation parameters, radii, angles have been programmed in the block.
Remedy:	As for alarm 3000



<b>3006</b>	<b>Wrong block structure</b>
Explanation:	<ul style="list-style-type: none"> <li>– More than 3 M functions programmed in the block</li> <li>– More than 1 S function programmed in the block</li> <li>– More than 1 T function programmed in the block</li> <li>– More than 1 H function programmed in the block</li> <li>– More than 4 auxiliary functions programmed in the block</li> <li>– More than 3 axes with G00 / G01 programmed in the block</li> <li>– More than 2 axes with G02 / G03 programmed in the block</li> <li>– G04 has been programmed with other addresses as "X" or "F"</li> <li>– M19 has been programmed with other address as "S"</li> <li>– Incorrect or no interpolation parameters for G02/G03 (MD 304*)</li> </ul>
Remedy:	As for alarm 3000

<b>3007</b>	<b>Error in programming setting data</b>
Explanation:	<ul style="list-style-type: none"> <li>– G25/G26 has been programmed</li> <li>– G92 has been programmed with another address as "S"</li> <li>– M19 has been programmed with another address as "S"</li> </ul>
Remedy:	As alarm 3000

<b>3008</b>	<b>Subroutine error</b>
Explanation:	<ul style="list-style-type: none"> <li>– Subroutine call without number of passes "P"</li> <li>– M30 has been programmed as program end</li> <li>– M17 at program end is missing</li> <li>– The fourth nesting level has been called (Only 3 subroutine levels are possible with 805)</li> <li>– M17 has been programmed in main program</li> </ul>
Remedy:	As for alarm 3000

<b>3009</b>	<b>Program disabled</b>
Explanation:	Not applicable to SINUMERIK 805

<b>3010</b>	<b>Intersection error</b>
Bedeutung:	<p>This error can appear in connection with the stock removal cycle L95 when:</p> <ul style="list-style-type: none"> <li>– The contour program is programmed without G0, G1, G2, G3</li> <li>– @ 714 is programmed in contour program</li> <li>– Incorrect plane in contour program</li> <li>– No intersection found</li> <li>– More than a quadrant programmed in contour program</li> <li>– No geometry in 1st block of contour program of L95 stock removal cycle</li> </ul>
Remedy:	As for alarm 3000

<b>3011</b>	<b>Too many axes progr./axes programmed twice</b>
Explanation:	<ul style="list-style-type: none"> <li>– An axis has been programmed twice in the same block</li> <li>– More axes have been programmed than exist in the machine</li> </ul>
Remedy:	As for alarm 3000
<b>3012</b>	<b>Block not in memory</b>
Explanation:	<ul style="list-style-type: none"> <li>– The program has not been terminated with M02/M03/M17</li> <li>– The block number stated in the jump (@ 100, 11x, 12x, 13x) has not been found in the specified direction</li> </ul>
Remedy:	As for alarm 3000
<b>3016</b>	<b>External data input error</b>
Effect:	Data transfer interrupted
Explanation:	For external data input from PLC to NC: <ul style="list-style-type: none"> <li>– the code is incorrect</li> <li>– the value is too large</li> <li>– the dimension identifier is invalid</li> <li>– the option is not available</li> </ul>
Remedy:	<ul style="list-style-type: none"> <li>– Check PLC program</li> <li>– check NC-MD, PLC-MD</li> </ul>
<b>3018</b>	<b>Distance from contour too large</b>
Scan:	After NC-START (Automatic)
Effect:	<ul style="list-style-type: none"> <li>– Machining stops</li> </ul>
Explanation:	The distance to circle contour is too large after repositioning (MD 9)
Remedy:	Observe MD 9, move closer to contour
<b>3019</b>	<b>Option not available</b>
Explanation:	The 2nd RS 232 C interface has been started either using the softkey or from the PLC even though no option is available for it.
Remedy:	<ul style="list-style-type: none"> <li>– Data transfer via the 1st RS 232 C interface</li> <li>– Retrofit option C62 (2nd RS 232 C interface)</li> </ul>

<b>3020</b>	<b>Option not available</b>
Explanation:	A function has been programmed which is not implemented in the control
Remedy:	<ul style="list-style-type: none"> <li>- As for alarm 3000</li> <li>- Retrofit option</li> </ul>

<b>3021</b>	<b>TRC/CRC contour error</b>
Scan:	When TRC/CRC is selected <b>NOT:</b> <ul style="list-style-type: none"> <li>- in selection block</li> <li>- in deselection block</li> </ul>
Explanation:	The compensation calculation results in a traversing movement which is opposite to the one programmed

<b>3072</b>	<b>Alarm text not available</b>
	(Available soon)

<b>3081</b>	<b>CRC not selected for approach</b>
Explanation:	The function "soft approach to and exit from contour" is only possible when cutter radius compensation has been selected. G41/G42 D0 understood as selected.
Remedy:	Select CRC

<b>4100</b>	<b>No D number active</b>
Explanation:	CRC/TRC selected without a D number being specified within a standard cycle
Remedy:	Check part program

<b>4101</b>	<b>Tool radius = 0</b>
Explanation:	The cutter radius is given as 0 In the case of standard cycles, this leads to errors
Remedy:	Enter radius in D number



<b>4102</b>	<b>Cutting radius too large</b>
Explanation:	Using this cutter would lead to contour errors with some of the standard cycles
Remedy:	Program other cutter
<b>4103</b>	<b>Tool too wide</b>
Explanation:	The width of the grooving tool is too large for the standard grooving cycle
<b>4120</b>	<b>Spindle direction not programmed</b>
Explanation:	No spindle direction was programmed before the standard cycle was called up
Remedy:	Changing of part program
<b>4121</b>	<b>Spindle not in tolerance range</b>
Explanation:	In case the spindle speed fluctuation is too great when standard cycles are used
Remedy:	Check drive actuator, MDs
<b>4140</b>	<b>Machined part diameter too small</b>
Explanation:	The value given for the machined part diameter in the standard cycle parameter setting is too small
Remedy:	Check part program
<b>4180</b>	<b>Option not available</b>
Explanation:	The standard cycle which has been called up requires an option which is not available in the control
Remedy:	Retrofit option
<b>4200</b>	<b>Check definition R (Nxxx)</b>
Explanation:	A parameter setting has been incorrectly defined
Remedy:	Define parameter setting correctly

<p><b>5000</b>          ⋮  <b>5099</b></p>	<p><b>User cycle alarm</b></p>
<p>Explanation:          Remedy:</p>	<p>The alarm has been called using @ 4c0 in the user cycle          Check the cycle</p>
<p><b>6000</b>          ⋮  <b>6063</b></p>	<p><b>PLC user alarms</b></p>
<p>Explanation:          Remedy:</p>	<p>Initiation bit has been set in PLC user program          Defined by manufacturer</p>
<p><b>6100</b></p>	<p><b>Signal converter missing</b></p>
<p>Cause:          Effect:          Remedy:</p>	<p>Load and transfer command for I/O device which is not available, e.g.          L PB, T PB          PLC-STOP          Check I/O address and/or STEP 5 program</p>
<p><b>6101</b></p>	<p><b>Illegal MC5 mode</b></p>
<p>Cause:          Effect:          Remedy:</p>	<p>STEP 5 command cannot be interpreted          PLC-STOP          – Check and/or reload PLC program          – Evaluate U-STACK</p>
<p><b>6102</b></p>	<p><b>Illegal MC5 parameter</b></p>
<p>Cause:          Effect:          Remedy:</p>	<p>Parameter type illegal (I, O, T, C, T) or parameter value illegal          PLC-STOP          – Check PLC program          – Evaluate U-STACK</p>

<b>6103</b>	<b>Transfer to missing DB</b>
Cause: Effect: Remedy:	L DW and/or T DW without previously calling a data block (A DB) PLC-STOP Check PLC program, U-STACK
<b>6104</b>	<b>Substitution error</b>
Cause: Effect: Remedy:	Error whilst substituting a PLC command PLC-STOP Check PLC program (U-STACK)
<b>6105</b>	<b>Missing MC5 block</b>
Cause: Effect: Explanation: Remedy:	Calling a block which is not in the control (OB, PB, SB, FB) PLC-STOP e.g. OB 2 not available Enter missing block.
<b>6106</b>	<b>Missing data block</b>
Cause: Effect: Remedy:	Calling a data block which is not in the control PLC-STOP Enter missing data block
<b>6107</b>	<b>Invalid segment LIR/TIR</b>
Cause: Effect: Explanation: Remedy:	LIR: segment nos. 0-A valid TIR: segment nos. 0-6 valid PLC-STOP See LIR/TIR Programming Instructions Correct program
<b>6108</b>	<b>Invalid segment TNB/TNW</b>
Cause: Effect: Explanation: Remedy:	Source: segment nos. 0 to A valid Destination: segment nos. 0 to 6 valid PLC-STOP See TNB/TNW Programming Instructions Correct program

<b>6109</b>	<b>Overflow block stack</b>
Cause: Effect: Explanation: Remedy:	Nesting depth > 12 PLC-STOP When a block calls itself Correct program

<b>6110</b>	<b>Overflow interrupt stack</b>
Cause: Effect: Explanation: Remedy:	More than two U-STACK entries PLC-STOP Cyclic program (OB 1) is interrupted by alarm program (OB 2) and alarm program interrupts itself See processing delay OB 2, alarm 6162

<b>6111</b>	<b>MC5 command STS</b>
Cause: Effect: Explanation:	STS command programmed in FB PLC-STOP Immediate termination of STEP 5 program processing

<b>6112</b>	<b>MC 5 command STP</b>
Cause: Effect: Explanation:	STP command programmed PLC-STOP PLC-STOP after termination of STEP 5 program processing

<b>6113</b>	<b>Illegal MC5 time/counter</b>
Cause: Effect: Remedy:	STEP 5 time or counter not available or not enabled by MD PLC-STOP – Correct program – alter PLC-MD 6

<b>6114</b>	<b>Function macro</b>
Cause: Effect: Remedy:	Error in an assembler function block (basic program) PLC-STOP See Programming Instructions Function Macros

<b>6115</b>	<b>System commands disabled</b>
Cause: Effect: Remedy:	Programmed command LIR, TIR, TNB, TNW PLC-STOP Set PLC-MD 2003 bit 4
<b>6116</b>	<b>MD 0000: Alarm byte no.</b>
Cause: Effect: Remedy:	PLC-MD > 31 set PLC-STOP Correct MD
<b>6117</b>	<b>MD 0001: CPU load</b>
Cause: Effect: Remedy:	PLC-MD 1 > 20 % PLC-STOP Correct MD
<b>6118</b>	<b>MD 0003: Alarm run time</b>
Cause: Effect: Remedy:	PLC-MD 3 > 2500 $\mu$ s PLC-STOP Correct MD
<b>6119</b>	<b>MD 0005: Cycle time</b>
Cause: Effect: Remedy:	PLC-MD 5 > 320 ms PLC-STOP Correct M
<b>6121</b>	<b>MD 0006: Last MC5 time</b>
Cause: Effect: Remedy:	PLC-MD 6 > 31 PLC-STOP Correct MD

<b>6123</b>	<b>Invalid servo sampling interval</b>
Cause: Effect: Remedy:	NC-MD 155 > 10 PLC-STOP Correct MD
<b>6124</b>	<b>Gap in MC5 memory</b>
Cause: Effect: Remedy:	No smooth follow on from valid to invalid blocks PLC-STOP General reset and reload program
<b>6125</b>	<b>Dual assignment of inputs</b>
Cause: Effect: Remedy:	An input address has been used twice (overlapping of two DMP submodule input areas) PLC-STOP dependent on PLC-MD 2003 bit 2 Check PLC-MD 10 - 19
<b>6126</b>	<b>Dual assignment of outputs</b>
Cause: Effect: Remedy:	An output address has been used twice (overlapping of two DMP submodule output areas) PLC-STOP dependent on PLC-MD 2003 bit 2 Check PLC-MD 10 - 19
<b>6127</b>	<b>Alarm byte missing</b>
Cause: Effect: Remedy:	Selected alarm input byte not available in hardware PLC-STOP – Alter PLC-MD 0 – Set alarm routing for alarm byte
<b>6130</b>	<b>Syncro error basic program</b>
Cause: Effect: Remedy:	Synchronization pattern for assembler function blocks no longer correct PLC-STOP PLC GENERAL RESET, reload PLC program, if necessary

<b>6131</b>	<b>Syncro error MC5 program</b>
Cause: Effect: Remedy:	Synchronization pattern for STEP 5 program blocks no longer correct PLC-STOP PLC GENERAL RESET, reload PLC program
<b>6132</b>	<b>Synchro error MC5 data</b>
Cause: Effect: Remedy:	Synchronization pattern for STEP 5 data blocks no longer correct PLC-STOP PLC GENERAL RESET, reload PLC program
<b>6133</b>	<b>Illegal block basic program</b>
Effect: Remedy:	PLC-STOP Replace system software
<b>6134</b>	<b>Illegal block MC5 program</b>
Effect: Remedy:	PLC-STOP PLC GENERAL RESET, reload PLC program
<b>6135</b>	<b>Illegal block MC5 data</b>
Effect: Remedy:	PLC-STOP PLC GENERAL RESET, reload PLC program
<b>6136</b>	<b>Summing error MC5 block</b>
Effect: Remedy:	PLC-STOP PLC GENERAL RESET, reload PLC program
<b>6137</b>	<b>Summing error basic program</b>
Effect: Remedy:	PLC-STOP Replace system software

<b>6138</b>	<b>No response from MPC</b>
Cause: Effect: Remedy:	Cable break, incorrect submodule no. set or similar PLC-STOP dependent on PLC-MD 2003 bit 2 Check cable and rack
<b>6139</b>	<b>MPC transfer error</b>
Cause: Effect: Remedy:	Same submodule no. set for 2 DMP submodules PLC-STOP dependent on PLC-MD 2003 bit 2 Check submodule no.
<b>6140</b>	<b>PLC-MD 10...19: DMP start address wrong</b>
Cause: Effect: Remedy:	Incorrect input in PLC-MD 10 -19 PLC-STOP dependent on PLC- MD 2003 bit 2 Check PLC-MD 10 - 19
<b>6149</b>	<b>Stop using softkey PG</b>
Cause: Effect: Remedy:	Stop command using PG PLC-STOP – PLC-START using PG – power on.
<b>6150</b>	<b>Timeout: User memory</b>
Effect: Explanation: Remedy:	PLC-STOP (S5 progr.) Evaluate detailed error coding, see Programming Instructions
<b>6152</b>	<b>Timeout: LIR/TIR</b>
Cause: Effect: Explanation: Remedy:	Access to addresses which are not available PLC-STOP See Programming Instructions Check segment and offset address. Hardware available?



<b>6153</b>	<b>Timeout: TNB/TNW</b>
Cause: Effect: Explanation: Remedy:	Incorrect programming or use of TNB/TNW PLC-STOP – See Programming Instructions – Check source and destination address for validity – Do addresses exist?
<b>6154</b>	<b>Timeout: L PB/L PW/T PB/ T PW</b>
Cause: Effect: Remedy:	Load and transfer command to I/O which has failed PLC-STOP Check I/Os and/or replace modules
<b>6155</b>	<b>Timeout: Substitution command</b>
Effect: Remedy:	PLC-STOP Check PLC program
<b>6156</b>	<b>Timeout: Not interpretable</b>
Cause: Effect: Remedy:	Acknowledgement timeout of system program not definable PLC-STOP – Evaluate detailed error diagnostics – PLC GENERAL RESET, reload PLC program
<b>6157</b>	<b>Timeout: IN FB/JC FB</b>
Cause: Effect: Remedy:	In the memory resident function macros, addresses are being accessed which are not available PLC-STOP Check hardware!
<b>6158</b>	<b>Timeout on I/O transfer</b>
Cause: Effect: Explanation: Remedy:	Central I/O no longer signalling PLC-STOP Central I/O recorded on start-up. No alarm when the + 24 V supply fails! Replace central controller

<b>6159</b>	<b>Runtime exceeded step 5 program</b>
Cause: Effect: Explanation: Remedy:	The max. runtime in PLC-MD 1 has been exceeded PLC-STOP, dependent on PLC-MD 2003 bit 1 Evaluate DB diagnostics! – Increase MD 1                      CPU load increases – Set MD 2003 bit 6                      Cycle time increases – Time optimization of PLC program
<b>6160</b>	<b>Runtime exceeded OB 2</b>
Cause: Effect: Explanation: Remedy:	The max. runtime in PLC-MD has been exceeded PLC-STOP, dependent on PLC-MD 2003 bit 0 Evaluate DB diagnostics! – Increase MD 3 – Time optimization of OB 2
<b>6161</b>	<b>Cycle time exceeded</b>
Cause: Effect: Explanation: Remedy:	The max. runtime in PLC-MD 5 has been exceeded PLC-STOP <b>Note:</b> bit commands only have a processing time of approx. 1 µs! – Increase MD 5 – Time optimization of PLC program
<b>6162</b>	<b>Processing delay OB 2</b>
Cause: Effect: Explanation: Remedy:	The alarm program (OB 2) has interrupted itself PLC-STOP, dependent on PLC-MD 2003 bit 0 Evaluate DB diagnostics Time optimization of OB 2, i.e. reduce the processing time of the alarm program!
<b>6164</b>	<b>DMP protec. function output (short-circuit)</b>
Cause: Remedy:	Short-circuit at a DMP submodule output Evaluate DB 1 diagnostics

<b>6165</b>	<b>DMP 24V supply for logic not OK</b>
Cause: Remedy:	Failure of 24V supply or shortfall of other operating point (15V) Check power supply

<b>6166</b>	<b>DMP overtemperature (&gt; 63 °C)</b>
Cause: Remedy:	Overtemperature in DMP submodule Evaluate DB 1 diagnostics

<b>7000</b> ⋮ <b>7063</b>	<b>PLC user operating message</b>
Cause:	Initiation bit has been set in PLC user program

## 9 Appendix

### 9.1 Softkey function dictionary

Softkey	Significance	Section
2.V24	Interface selection (Interface 1 and 2 (option))	4.7
ACCEPT DATA	Alternate between insert and overwrite mode	4.3.1
ACTIVE BLOCK	Display of the active block contents	5.3.2
ALL MESSAGES	Display of all active NC resp. PLC alarms and PLC messages	4.8
BAUD RATE	Set baud rate	6.2
BLOCK SEARCH	Block search manages the operation start at a user selectable part of the the program. During block search the same calculations like in normal operation run are made but there is no axis movement.	5.3.4
CLEAR	The program selected by cursor or by entering the program number can be deleted.	4.3.8
CLEAR AREA	Clear an area which can be input	4.3.1
COPY	Copy the selected program onto a new program number	4.3.7
DATA PARAMETER	Display of R parameters	5.2.5
DATA TRANSFER	Selection of data transfer menu	4.7
DELETE BLOCK	Delete a block selected by cursor	4.3.1
DEVICE TYPE	Set interface type	6.2
DIAGNOSIS	Selection of NC recorded alarms and messages	4.8
DRIFT COMP.	Drift compensation for the selected axis	4.8.2
INITIALISATION	Selection of initialisation mode for installation	see Installation Guide
INSERT BLOCK	Insert a new block after the block selected by cursor	4.3.1

Softkey	Significance	Section
JOG	Selection of JOG mode	3.2.1
JOG-INC	Selection of JOG-INC submode	3.3
JOG-REF	Selection of JOG-REF submode	3.5
JOG-REPOS	Selection of JOG-REPOS submode	3.4
MAIN PROGRAM	Display of "MAIN PROGRAM DIRECTORY"	4.3.5
MEMORY ALLOCATION	Display of the user program memory (part program memory), the free and allocated memory	4.3.4
MODIFY PROGRAM	Edit the program selected by cursor	4.3.1
NC ALARMS	Display of the active NC alarms	4.8
NC-MD BITS	Selection of the desired data type	4.4.4
NC-MD VALUES	Selection of the desired data type	4.4.3
NEW PROGRAM	Create a new part program	4.3.2
OPERATOR PROMPTING	Parameter support for subroutine programs	4.3.1.1 5.3.11.1
OVERRIDE BLOCK	Display of part program block with possibility to edit	5.3.14
OVERSTORE	Entry of auxiliary or additional functions, spindle speed and tool number into temporary storage	5.3.12
PARAMETER	Selection of the menu for interface parameter assignment	6.2
PARITY	Set parity selection for data transfer	6.2
PLC ALARMS	Display of active PLC alarms	4.8
PLC MESSAGES	Display of active PLC user messages <b>Note:</b> PLC user alarms resp. messages must have been stored by the manufacturer as a sub-routine program.	4.8

<b>Softkey</b>	<b>Significance</b>	<b>Section</b>
PLC STATUS	Information about PLC current state of inputs, output, flags etc.	4.8.1
PLC-MD	Selection of the desired data type	4.4.5
PRESET	Set actual value	5.3.13
PROGRAM	Branch into area "part programs"	5.2.8.1
PROGRAM CONTROL	Modify the sequence of a part program	5.3.5
R PARAM	Selection of the desired data type	4.4.1
READ-IN START	Start of data input via selected interface	4.7
READ-OUT	Selection of "data output" display	4.7
RELOCATE	The selected program is pushed to the end of the memory for editing	4.3.10
RENAME	The selected program is given another number	4.3.9
REORGANISE	Reorganisation of the part program memory	4.3.11
SEARCH	Key in a particular data parameter	4.4.1
SEARCH	Key in the program number of a particular part program	4.3.6
SELECT PROGRAM	Selection of part program for execution	5.3.1
SERVICE		4.8.2
SETTING DATA	Selection of the desired data type	4.4.2
START	Activation of the selected softkey function	5.3.4
STOP	Interrupts the data transfer during read-in/read-out	4.7
STOP BITS	Set the stop bit number	6.2
SUBROUTINE PROGRAMS	Alternate to "SUBROUTINE DIRECTORY"	4.3.5

<b>Softkey</b>	<b>Significance</b>	<b>Section</b>
TOOL OFFSET	Display of the tool offset window	5.2.4
UNDO MOD.	Reverse the recent modifications in the block. This is only possible if the INPUT key has not yet been operated.	4.3.1
VERSION	Display of system screen	1.2
ZERO OFFSET	Display of an input window for zero offset	5.2.6.1

## 9.2 Index

### 9.2.1 Abbreviations

Abbreviations	Significance
ASM	User memory module
BCD	Decimal numbers in binary code ( <b>B</b> inary <b>C</b> oded <b>D</b> ecimales)
CLF	Delete statement ( <b>C</b> lear <b>F</b> ile), during read-in
CPU	<b>C</b> entral <b>P</b> rocessing <b>U</b> nit
DAU	Digital-analog converter
DBL	Decoding single block
DIO	Data transfer display ( <b>D</b> ata <b>I</b> nput/ <b>O</b> utput)
DRF	DRF shift
DRY	Test run feedrate
EIA-Code	Special tape code, hole number per character always odd
EOB	Block end mark for EIA code data
EOR	Mark for Program number (for EIA code)
EPROM	Program memory with resident program
EZS	Input temporary storage
FRK	Cutter compensation
H	Auxiliary function
INC	Operation mode "Increment" ( <b>I</b> ncrement)
ISO-Code	Special tape code, hole number per character always even
K1	Channel 1, main channel
K2	Channel 1, auxiliary channel
L	Subprogram no.
LED	Light emitting diode display ( <b>L</b> ight <b>E</b> mitting <b>D</b> iode)
LF	Block end mark for ISO code data
M	Additional function
M01	Programmed stop
MD	Machine data



Abbreviations	Significance
MDA	Manual data automatic
MPF	Part program ( <b>MainProgram File</b> )
N	Block number
NC	<b>Numerical Control</b>
NV	Zero offset
P	Pass count
PCA	PLC alarms
PCP	PL program in machine code ( <b>Programmable Control Program</b> )
PLC	Interface control ( <b>Programmable Logic Control</b> )
Pr. Halt	Display of a programmed run interruption
RAM	Program memory with read and write accesses
ROV	Rapid traverse override
RPA	R parameter with value assignment ( <b>R Parameter Active</b> )
S	Spindle speed
SD	Setting data
SEA	Addresses with value assignments ( <b>Setting Data Active</b> )
SKP	Skip block
SPF	Subroutine ( <b>Sub Program File</b> )
SRK	Cutter radius compensation
SW-Endschalter	Software position switch
T	Tool number
TEA1	NC machine data ( <b>Testing Data Active</b> )
TEA2	PLC machine data ( <b>Testing Data Active</b> )
TOA	Tool offsets ( <b>Tool Offset Active</b> )
WZK	Tool offset
ZOA	Zero offset ( <b>Zero Offset Active</b> )

**9.2.2 Useful definitions**

<b>Definitions</b>	<b>Section</b>
Absolute actual value	4.8.2
Absolute actual value	4.8.2
Actual position	2.1.1
Actual value system	4.4.2
Block search	2.1.1
Block search	5.3.4
Cleaning	7.4
Command value	4.8.2
Contour deviation	4.8.2
Cutting speed	4.8.2
Data area	2.4.3
Data input/output	4
Delete block	4.3.8
Delete input	4.3.8
Device setting data	6.7
Device-connection data	6.8
Differential resolver function (DRF)	5.3.7
Edit key	2.1.1
Entry field	2.1.1
Feedrate offset	2.2.1
Feedrate start/stop	2.2.1
Following error	4.8.2
Handwheel	2.2.1/3.3.2
Insert mode	4.3.1
Installation	see Installation Guide
Interfaces	6
Jog operation	5.3.10
Key in block/key in character	4.3.1
Machine area	2.4
Maintenance	7

<b>Definitions</b>	<b>Section</b>
Manual input/Automatic	3.6
MDA	3.6
Menu tree	2.4
Mode menu trees	2.4.2
Modify block	4.3.2
Monitoring	8.3.3
Operating mode overview	3.1.1
Operating mode selection	3.1.2
Operating modes	3
Operating sequences, operation	5.3
Operating sequences, preparation	5.2
Part actual value	4.8.2
Part command value	4.8.2
Position actual value	4.8.2
Program control	5.3.5
Program editing	4.3.1
Program interruption	5.3.3
Program management	4.3.11
Program memory	4.3.4
Program stop/Program start	5.3.3/5.3.1
R parameter	4.4.1
Reference point start	5.2.2
Replace mode	4.3.1
Repositioning	5.3.10
RESET	3.1.3
Scratch	5.3.17
Search	4.3.6/4.4.1
Self retentive	5.3.10
Set actual value	5.3.13
Setting data	4.4.2
Single block	2.1.1

<b>Definitions</b>	<b>Section</b>
Softkey functions	9.1
Softkeys	2.3
Speed actual value	4.8.2
Speed command value	4.8.2
Spindle speed	2.2.1
Spindle stop/Spindle start	2.2.1
Switch off	1.2
Switch on	1.2
Tool offset	4.5
Tool parameter	5.2.4
Tools	5.2.4.1
WZ parameter	5.2.4
Zero offset	4.6

Siemens AG

AUT V230  
P.O. Box 48 48  
W-8500 Nuremberg 1  
Federal Republic of Germany

**Suggestions**

**Corrections**

For Publication/Manual:

SINUMERIK 805  
Software Version 3

Operator's Guide

Order No.: 6ZB5 410-0EE02-0BA1  
Edition: January 1991

**From:**

Name \_\_\_\_\_

Company/Dept. \_\_\_\_\_

Address \_\_\_\_\_

Telephone / \_\_\_\_\_

Should you come across any printing errors when reading this publication, please notify us on this sheet. Suggestions for improvement are also welcome.

**Suggestions and/or corrections**

Siemens AG  
Automation Group  
Automation Systems  
for Machine Tools, Robots  
and Special-Purpose Machines  
P.O. Box 48 48, W-8500 Nuremberg 1  
Federal Republic of Germany

© Siemens AG 1990 All Rights Reserved  
Subject to change without prior notice

Siemens Aktiengesellschaft

Order No.: 6ZB5 410-0EE02-0BA1  
Printed in the Federal Republic of Germany  
251/211248 BA 05910.3

